

SUZUKI

PARTS CATALOGUE

DF300AP/250AP

DF300AP

DF250AP



OUTBOARD MOTOR

E01/E40

2014-7

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF250A/300A production start 2014.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: With
LH(PORT)	: Left hand side	X, XX	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 30002P-123456	PTT	: Power trim and tilt
123456~	: From E. NO. 30002P-123456		
12 x 34 x 5.6	 Figures in the description column		
	show the dimensions of parts.		
ID OD T	(or W, L)		

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE No.
DF250AP	E01, E40	25003P	X, XX	25003P-510001~
DF300AP	E01, E40	30002P	X, XX	30002P-510001~

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




DKBDA_EPL_016_1114
CYLINDER HEAD

FIG.113A




DKBDA_EPL_016_1134
CYLINDER HEAD

FIG.116A




DKBDA_EPL_016_1164
CAMSHAFT

FIG.119A




DKBDA_EPL_016_1194
CAMSHAFT

FIG.121A




DKBDA_EPL_016_1214
CAMSHAFT

FIG.122A




DKBDA_EPL_016_1224
PILANE SHAFT

FIG.136A




DKBDA_EPL_016_1364
RING GEAR COVER

FIG.136B




DKBDA_EPL_016_136B
RING GEAR COVER

FIG.136C




DEKRA EPT 016, 140C
FUEL INJECTOR

FIG.136D




DEKRA EPT 016, 140D
FUEL INJECTOR

FIG.140A




DEKRA EPT 016, 140A
FUEL INJECTOR

FIG.144A




DEKRA EPT 016, 144A
FUEL INJECTOR

FIG.144B




DEKRA EPT 016, 144B
FUEL INJECTOR

FIG.144C



DEKRA EPT 016, 144C
FUEL INJECTOR

FIG.144D



DEKRA EPT 016, 144D
FUEL INJECTOR

FIG.147A






FIG.163A




DCRBA, EPL 016, 1634
TURBULENCE

FIG.175A




DCRBA, EPL 016, 1754
OL 248P

FIG.180A




DCRBA, EPL 016, 1804
OL 240

FIG.204A




DCRBA, EPL 016, 2044
CLUTCH SHFT

FIG.206A




DCRBA, EPL 016, 2064
CLUTCH RED

FIG.220A




DCRBA, EPL 016, 2204
TRANSMISSION

FIG.301A




DCRBA, EPL 016, 3014
STARTING MOTOR

FIG.303A




DCRBA, EPL 016, 3034
MAGNETO

FIG.310A




DKR04A_EPL_016.1104
SEC 70-20020410010202

FIG.315A




DKR04A_EPL_016.1104
SS30020

FIG.322A




DKR04A_EPL_016.3304
14400230

FIG.326A




DKR04A_EPL_016.3304
PIT SWITCH-MEMOIRE CONTROL UNIT

FIG.326B




DKR04A_EPL_016.3369
PIT SWITCH-MEMOIRE CONTROL UNIT

FIG.326C




DKR04A_EPL_016.336C
PIT SWITCH-MEMOIRE CONTROL UNIT

FIG.326D




DKR04A_EPL_016.336D
PIT SWITCH-MEMOIRE CONTROL UNIT

FIG.335A




DKR04A_EPL_016.3304
CLAMP BRACKET

FIG.336A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.337A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.340A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.401A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.405A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.407A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.410A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.420A




DISBA, EPL 016, 404
ENGINE SHAFT

FIG.420B




DCRDA, EPL 016, 430B
ENGINE COVER

FIG.420C




DCRDA, EPL 016, 430C
ENGINE COVER

FIG.420D




DCRDA, EPL 016, 430D
ENGINE COVER

FIG.430A




DCRDA, EPL 016, 430A
FUEL HOSE

FIG.430B




DCRDA, EPL 016, 430B
FUEL HOSE

FIG.430C




DCRDA, EPL 016, 430C
FUEL HOSE

FIG.430D




DCRDA, EPL 016, 430D
FUEL HOSE

FIG.502A




DCRDA, EPL 016, 502A
OPTIMIZER (1)

FIG.503A




DCR00A, EPTL 016, S004
OPT:60200 (2)

FIG.520A




DCR00A, EPTL 016, S004
OPT:GL000-RC000T-5000X000

FIG.522A




DCR00A, EPTL 016, S004
OPT:60200 (2)

FIG.523A




DCR00A, EPTL 016, S004
OPT:60200 (2)

FIG.530A




DCR00A, EPTL 016, S004
OPT:50000

FIG.540A




DCR00A, EPTL 016, S004
OPT:PARMITE CONTROL ASSY DUAL

FIG.543A




DCR00A, EPTL 016, S004
OPT:PARMITE CONTROL ASSY SINGLE

FIG.585A



DCR00A, EPTL 016, S004
OPT:G000007-SET

FIG.588A



DESIGN 121 118 804
OPTICAL DISTANCE GAUGE

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11101-98J03	HEAD ASSY, CYLINDER STBD	1	
2	11128-90J00	.BOLT, CAM SHAFT HOUSING	16	
3	09206-08001	.PIN (8X11)	14	
4	01550-06207	.BOLT	4	
5	11103-98J03	HEAD ASSY, CYLINDER PORT	1	
6	11128-90J00	.BOLT, CAM SHAFT HOUSING	16	
7	09206-08001	.PIN (8X11)	14	
8	01550-06207	.BOLT	2	
9	11116-93J01	PLUG	4	
10	11141-98J10	GASKET, CYL HEAD STBD	1	
11	11142-98J10	GASKET, CYL HEAD PORT	1	
12	09168-16009	GASKET (16X22X0.8)	4	
13	11261-93J00	COVER, PROTECTION ANODE	4	
14	09280-22019	O RING (D:1.9,ID:21.8)	4	
15	55321-87J00	ANODE, PROTECTION	4	
16	09103-06281	BOLT (6X14)	4	
17	01550-08207	BOLT	4	
18	01550-08607	BOLT	5	
19	01550-08607	BOLT	4	
20	09206-14004	PIN (14X11.4X23)	4	
21	11170-93J01	COVER, CYL HEAD STBD	1	
22	11180-98J01	COVER, CYLINDER HEAD PORT	1	
23	11173-93J00	PLATE, BREATHER STBD	1	
24	11183-93J00	PLATE, BREATHER PORT	1	
25	11179-93J00	GASKET, CYL HEAD COVER STBD	1	
26	11189-93J00	GASKET, CYL HEAD COVER PORT	1	
27	09206-08001	PIN (8X11)	1	
28	02112-0612A	SCREW	14	
29	01547-06257	BOLT	16	
30	01547-06507	BOLT	6	
31	11382-93J00	CAP, OIL FILLER	1	
32	09280-26006	O RING (D:3.1,ID:26.4)	1	
33	09482-00427	SPARK PLUG (BKR6E)	6	NGK
34	11291-93J00	HOOK, ENGINE	2	

FIG.111A




FIG.111A (1-B-3) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	01550-08207	BOLT	4	
36	11115-93J10-001	GUIDE, VALVE (OS:0.5)	24	OPT
37	11291-98J00	HOOK, ENGINE	1	OPT

FIG.113A




FIG.113A (1-B-4) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11293-98J00	HOOK, ENGINE FRONT	1	
2	01550-08207	BOLT	2	
3	11301-98J30	BLOCK SET, CYLINDER	1	
4	11112-93J00	.PLUG, OIL VENTURI	2	
5	11117-93J10	.BOLT, CRANKCASE	12	
6	11117-98J10	.BOLT, CRANKCASE STUD	4	
7	11119-93J00	.BOLT, CYLINDER HEAD	16	
8	11217-85FA0	.GASKET, M26 PLUG	3	
9	09248-26001	.PLUG (26X11)	3	
10	09160-18031	.WASHER (18.5X28X2.6)	2	
11	09248-18006	.PLUG (18X8)	2	
12	09159-10116	.NUT	4	
13	09206-13019	.PIN (10.4X13X16)	5	
14	16700-93J00	.VALVE, PISTON JET	1	
15	09280-10009	..O RING (D:1.3,ID:9.8)	1	
16	09280-10016	..O RING (D:1.9,ID:9.8)	1	
17	07130-0616A	.BOLT	1	
18	07130-0510A	.BOLT	6	
19	11390-98J00	.JET, PISTON COOLING	6	
20	09280-06005	..O RING (D:1.9,ID:5.7)	6	
21	09246-05006	.PLUG (1/8PT,H:5.5)	1	
22	11330-93J01	COVER, CRANKCASE WTR JKT	1	
23	11332-93J00	GASKET, CRANKCASE WTR JKT COV	1	
24	01550-06207	BOLT	12	
25	16430-93J00	COVER, OIL GALLERY	1	
26	16431-93J00	PLATE, OIL GALLERY	1	
27	16433-93J00	GASKET, OIL GALLERY	2	
28	01550-0835A	BOLT	9	
29	01550-08457	BOLT	8	
30	16510-96J00	FILTER ASSY, OIL	1	

FIG.116A




FIG.116A (1-B-5) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-98J00-0B0	PISTON	6	
2	12140-98J00	RING SET, PISTON	6	
3	12151-02F00	PIN, PISTON	6	
4	09381-22010	CIRCLIP	12	
5	12160-98J00	CONNROD ASSY	6	
6-1	12100-98810-0A0	BEARING SET, CONNROD (GREEN)	6	
6-2	12100-98810-025	BEARING SET, CONNROD (US:0.25)	6	OPT
7	12220-98J00	CRANKSHAFT	1	
8-1	12340-98J00-0A0	BEARING SET, CRANKSHAFT (BLACK)	4	
8-2	12340-98J00-0B0	BEARING SET, CRANKSHAFT (NON)	4	
8-3	12340-98J00-0C0	BEARING SET, CRANKSHAFT (YELLOW)	4	
8-4	12340-98J00-0D0	BEARING SET, CRANKSHAFT (BLUE)	4	
8-5	12340-98J00-0E0	BEARING SET, CRANKSHAFT (PINK)	4	
8-6	12300-98810-0AA	BEARING SET, CRANKSHAFT (RED/BLACK)	4	OPT US:0.25
8-7	12300-98810-0BA	BEARING SET, CRANKSHAFT (RED)	4	OPT US:0.25
8-8	12300-98810-0CA	BEARING SET, CRANKSHAFT (RED/YELLOW)	4	OPT US:0.25
8-9	12300-98810-0DA	BEARING SET, CRANKSHAFT (RED/BLUE)	4	OPT US:0.25
8-10	12300-98810-0EA	BEARING SET, CRANKSHAFT (RED/PINK)	4	OPT US:0.25
9-1	12300-98821	BEARING SET, CRANK THRUST	1	
9-2	12300-98821-012	BEARING SET, CRANK THRUST	1	OPT OS:0.12
10	12242-98J00	GEAR, DRIVE (NT:32)	1	
11	09160-10104	WASHER (10.5X50X3.2)	1	
12	01550-1025A	BOLT	1	
13	09283-91001	OIL SEAL (91X109X10)	1	
14	12100-98J00-050	PISTON SET (OS:0.50)	6	OPT
15	12140-98J00-050	.RING SET, PISTON (OS:0.50)	6	OPT

FIG.119A




FIG.119A (1-B-6) TIMING CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12730-98J01	GEAR, DRIVEN (NT:40)	1	
2	09262-40018	BEARING (40X80X18)	1	LOWER
3	09262-40017	BEARING (40X80X18)	1	UPPER
4	09283-32044	OIL SEAL (32X47X6)	1	
5	12734-93J00	HOLDER, DRIVEN GEAR	1	
6	09280-70012	O RING (D:5.7,ID:69.6)	1	
7	01550-0855A	BOLT	4	
8	12761-93J00	CHAIN, TIMING 1ST	1	
9	12762-93J00	CHAIN, TIMING 2ND	2	
10	12770-93J00	BASE, TIMING CHAIN GUIDE NO.1	1	
11	12778-93J00	GASKET, GUIDE BASE	1	
12	04211-13149	PIN	2	
13	01550-0830A	BOLT	2	
14	12771-93J00	SHOE, TIMING CHAIN UPPER	1	
15	12775-93J00	SHOE, TIMING CHAIN LOWER	1	
16	12772-93J00	GUIDE, TIMING CHAIN NO.2	1	
17	01550-0830A	BOLT	2	
18	12810-93J00	TENSIONER ASSY, TIMING CHAIN	1	
19	12813-73G00	.PAD, TIMING CHAIN TENSIONER	1	
20	12812-90J00	SPACER, TIMING CHAIN TENSIONER	1	
21	01550-0830A	BOLT	1	
22	12831-93J01	ADJUSTER ASSY, TENSIONER	1	
23	12832-93J00	TENSIONER ASSY, STBD	1	
24	12833-93J00	TENSIONER ASSY, PORT	1	
25	01550-0620A	BOLT	2	
26	01550-0620A	BOLT	4	

FIG.121A




FIG.121A (1-B-7) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-98J10	CAMSHAFT, INTAKE STBD	1	
2	12705-98J10	CAMSHAFT, INTAKE PORT	1	
3	12721-98J10	CAMSHAFT, EXH STBD	1	
4	12729-98J20	CAMSHAFT, EXH PORT	1	
5	12740-93J00	SPROCKET ASSY, CAM TIMING (NT:22/32)	2	
6	12748-93J00	SPROCKET, EXH CAMSHAFT (NT:22)	2	
7	12753-93J00	BOLT, INTAKE CAMSHAFT	2	
8	12749-93J00	BOLT, CAMSHAFT EXHAUST	2	
9	09202-05032	PIN (5X12)	3	
10	09261-05006	PIN (5X18)	1	
11	16550-93J00	VALVE, OIL CONTROL	2	
12	16555-93J00	GASKET, VALVE	2	
13	01550-06257	BOLT	8	
14	12891-93J00	TAPPET	24	
15-1	12892-93J00-218	SHIM, TAPPET (T:2.175)	AR	
15-2	12892-93J00-220	SHIM, TAPPET (T:2.200)	AR	
15-3	12892-93J00-223	SHIM, TAPPET (T:2.225)	AR	
15-4	12892-93J00-225	SHIM, TAPPET (T:2.250)	AR	
15-5	12892-93J00-228	SHIM, TAPPET (T:2.275)	AR	
15-6	12892-93J00-230	SHIM, TAPPET (T:2.300)	AR	
15-7	12892-93J00-233	SHIM, TAPPET (T:2.325)	AR	
15-8	12892-93J00-235	SHIM, TAPPET (T:2.350)	AR	
15-9	12892-93J00-238	SHIM, TAPPET (T:2.375)	AR	
15-10	12892-93J00-240	SHIM, TAPPET (T:2.400)	AR	
15-11	12892-93J00-243	SHIM, TAPPET (T:2.425)	AR	
15-12	12892-93J00-245	SHIM, TAPPET (T:2.450)	AR	
15-13	12892-93J00-248	SHIM, TAPPET (T:2.475)	AR	
15-14	12892-93J00-250	SHIM, TAPPET (T:2.500)	AR	
15-15	12892-93J00-253	SHIM, TAPPET (T:2.525)	AR	
15-16	12892-93J00-255	SHIM, TAPPET (T:2.550)	AR	
15-17	12892-93J00-258	SHIM, TAPPET (T:2.575)	AR	
15-18	12892-93J00-260	SHIM, TAPPET (T:2.600)	AR	
15-19	12892-93J00-263	SHIM, TAPPET (T:2.625)	AR	

FIG.121A




FIG.121A (1-B-8) CAMSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-20	12892-93J00-265	SHIM, TAPPET (T:2.650)	AR	
15-21	12892-93J00-268	SHIM, TAPPET (T:2.675)	AR	
15-22	12892-93J00-270	SHIM, TAPPET (T:2.700)	AR	
15-23	12892-93J00-273	SHIM, TAPPET (T:2.725)	AR	
15-24	12892-93J00-275	SHIM, TAPPET (T:2.750)	AR	
15-25	12892-93J00-278	SHIM, TAPPET (T:2.775)	AR	
15-26	12892-93J00-280	SHIM, TAPPET (T:2.800)	AR	
15-27	12892-93J00-283	SHIM, TAPPET (T:2.825)	AR	
15-28	12892-93J00-285	SHIM, TAPPET (T:2.850)	AR	
15-29	12892-93J00-288	SHIM, TAPPET (T:2.875)	AR	
15-30	12892-93J00-290	SHIM, TAPPET (T:2.900)	AR	
15-31	12892-93J00-293	SHIM, TAPPET (T:2.925)	AR	
15-32	12892-93J00-295	SHIM, TAPPET (T:2.950)	AR	
15-33	12892-93J00-298	SHIM, TAPPET (T:2.975)	AR	
15-34	12892-93J00-300	SHIM, TAPPET (T:3.000)	AR	
16	12911-98J00	VALVE, INTAKE	12	
17	12915-93J50	VALVE, EXHAUST	12	
18	12921-93J10	SPRING, VALVE	24	
19	12931-78G00	RETAINER, VALVE SPRING	24	
20	12932-24400	COTTER, VALVE	48	
21	12933-69G10	SEAT, VALVE SPRING	24	
22	09289-05012	OIL SEAL (5.5X11.5X9.3)	24	

FIG.122A




FIG.122A (1-B-9) INTAKE MANIFOLD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13110-98J10	MANIFOLD, INTAKE	1	
2	13119-98J00	GASKET, INTAKE MANIFOLD	2	
3	09108-08282	STUD BOLT	4	
4	09103-08437	BOLT (8X65)	4	
5	09159-08136	NUT	4	
6	09160-08161	WASHER (8.2X23X3.2)	8	

FIG.136A




FIG.136A (1-B-10) RING GEAR COVER (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J02	COVER, RING GEAR	1	
2	11174-98J00	.HOSE, BREATHER	1	
3	11176-98J00	.UNION, BREATHER	1	
4	11514-98J00	.PLATE, RING GEAR COVER	1	
5	13710-98J00	.ARRESTER, FLAME	1	
6	13811-98J00	.SILENCER, UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE, RING GEAR COVER	1	
12	13841-98J10	GUARD, AIR DUCT STBD	1	
13	13851-98J10	GUARD, AIR DUCT PORT	1	
14	01550-06207	BOLT	4	
15	01550-06207	BOLT	2	
16	01550-06407	BOLT	1	
17	01550-08357	BOLT	2	
18	61472-93E40	LABEL, MAG COVER	1	
19	69711-93E10	LABEL (S.I.G.P)	1	
20	61493-93J00	LABEL, CLEARANCE	1	
21	61494-96J00	LABEL, OIL	1	

FIG.136B




FIG.136B (1-B-11) RING GEAR COVER (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J02	COVER, RING GEAR	1	
2	11174-98J00	.HOSE, BREATHER	1	
3	11176-98J00	.UNION, BREATHER	1	
4	11514-98J00	.PLATE, RING GEAR COVER	1	
5	13710-98J00	.ARRESTER, FLAME	1	
6	13811-98J00	.SILENCER, UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE, RING GEAR COVER	1	
12	13841-98J10	GUARD, AIR DUCT STBD	1	
13	13851-98J10	GUARD, AIR DUCT PORT	1	
14	01550-06207	BOLT	4	
15	01550-06207	BOLT	2	
16	01550-06407	BOLT	1	
17	01550-08357	BOLT	2	
18	61472-93E32	LABEL, MAG COVER	1	
19	69711-93E10	LABEL (S.I.G.P)	1	
20	61493-93J00	LABEL, CLEARANCE	1	
21	61494-96J00	LABEL, OIL	1	

FIG.136C




FIG.136C (1-B-12) RING GEAR COVER (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J02	COVER, RING GEAR	1	
2	11174-98J00	.HOSE, BREATHER	1	
3	11176-98J00	.UNION, BREATHER	1	
4	11514-98J00	.PLATE, RING GEAR COVER	1	
5	13710-98J00	.ARRESTER, FLAME	1	
6	13811-98J00	.SILENCER, UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE, RING GEAR COVER	1	
12	13841-98J10	GUARD, AIR DUCT STBD	1	
13	13851-98J10	GUARD, AIR DUCT PORT	1	
14	01550-06207	BOLT	4	
15	01550-06207	BOLT	2	
16	01550-06407	BOLT	1	
17	01550-08357	BOLT	2	
18	61472-93E40	LABEL, MAG COVER	1	
19	69711-93E10	LABEL (S.I.G.P)	1	
20	61493-93J00	LABEL, CLEARANCE	1	
21	61494-96J00	LABEL, OIL	1	

FIG.136D




FIG.136D (1-B-13) RING GEAR COVER (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11510-98J02	COVER, RING GEAR	1	
2	11174-98J00	.HOSE, BREATHER	1	
3	11176-98J00	.UNION, BREATHER	1	
4	11514-98J00	.PLATE, RING GEAR COVER	1	
5	13710-98J00	.ARRESTER, FLAME	1	
6	13811-98J00	.SILENCER, UPPER COVER	1	
7	09401-18410	.CLIP	2	
8	01550-06127	.BOLT	4	
9	01550-06207	.BOLT	5	
10	11517-98J00	.SCREW	3	
11	11515-93J00	BRACE, RING GEAR COVER	1	
12	13841-98J10	GUARD, AIR DUCT STBD	1	
13	13851-98J10	GUARD, AIR DUCT PORT	1	
14	01550-06207	BOLT	4	
15	01550-06207	BOLT	2	
16	01550-06407	BOLT	1	
17	01550-08357	BOLT	2	
18	61472-93E32	LABEL, MAG COVER	1	
19	69711-93E10	LABEL (S.I.G.P)	1	
20	61493-93J00	LABEL, CLEARANCE	1	
21	61494-96J00	LABEL, OIL	1	

FIG.140A





FIG.140A (1-B-14) EXHAUST COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14141-93J01	COVER, EXHAUST STBD	1	
2	14140-98J01	COVER, EXHAUST PORT	1	
3	14151-93J00	GASKET, EXHAUST COVER STBD	1	
4	14152-93J00	GASKET, EXHAUST COVER PORT	1	
5	11261-93J00	COVER, PROTECTION ANODE	2	
6	55321-87J00	ANODE, PROTECTION	2	
7	09103-06281	BOLT (6X14)	2	
8	09280-22019	O RING (D:1.9,ID:21.8)	2	
9	01550-08207	BOLT	2	
10	01550-06257	BOLT	23	



FIG.144A




DF300A_E01_015_144A
FUEL INJECTOR

FIG.144A (1-B-15) FUEL INJECTOR (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J01	HOSE, FUEL (3WAY TO DLVY PIPE)	1	
2	15710-96J00	INJECTOR ASSY, FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR, DELIVERY PIPE	4	
5	15751-93J00	PIPE, DELIVERY	2	
6	15756-93J01	HOSE, FUEL (DLVY TO DLVY)	1	
7	15762-93J00	GASKET, DELIVERY PIPE	5	
8	15830-77EA0	UNION, DELIVERY PIPE	1	
9	15831-93J00	UNION, DELIVERY PIPE	2	
10	18498-93J00	PROTECTOR, FUEL HOSE (L:340)	1	
11	09247-14041	PLUG (14X14)	1	
12	09320-08062	CUSHION	6	
13	09360-14009	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP	1	
17	09408-00155	CLAMP	1	
18	01550-08407	BOLT	4	
19	15680-93J21	HOSE, FUEL (PUMP TO FILTER)	1	
20	09401-13423	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE, FUEL HOSE	1	
23	01550-06127	BOLT	2	

DF300A_E01_015


DF300A_E01_015_144B
FUEL INJECTOR



DF300A_E01_015

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	15681-93J01	HOSE, FUEL (3WAY TO DLVY PIPE)	1	
2	15710-96J00	INJECTOR ASSY, FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR, DELIVERY PIPE	4	
5	15751-93J00	PIPE, DELIVERY	2	
6	15756-93J01	HOSE, FUEL (DLVY TO DLVY)	1	
7	15762-93J10	GASKET, DELIVERY PIPE	5	
8	15832-93J00	UNION, DELIVERY PIPE	1	
9	15831-93J00	UNION, DELIVERY PIPE	2	
10	18498-93J00	PROTECTOR, FUEL HOSE (L:340)	1	
11	09247-14042	PLUG (14X14)	1	
12	09320-08062	CUSHION	6	
13	09360-14014	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP	1	
17	09408-00155	CLAMP	1	
18	01550-08407	BOLT	4	
19	15680-93J21	HOSE, FUEL (PUMP TO FILTER)	1	
20	09401-13423	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE, FUEL HOSE	1	
23	01550-06127	BOLT	2	

FIG.144C



DF300A_E01_015_144C
FUEL INJECTOR

FIG.144C (1-C-3) FUEL INJECTOR (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J01	HOSE, FUEL (3WAY TO DLVY PIPE)	1	
2	15710-96J00	INJECTOR ASSY, FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR, DELIVERY PIPE	4	
5	15751-93J00	PIPE, DELIVERY	2	
6	15756-93J01	HOSE, FUEL (DLVY TO DLVY)	1	
7	15762-93J00	GASKET, DELIVERY PIPE	5	
8	15830-77EA0	UNION, DELIVERY PIPE	1	
9	15831-93J00	UNION, DELIVERY PIPE	2	
10	18498-93J00	PROTECTOR, FUEL HOSE (L:340)	1	
11	09247-14041	PLUG (14X14)	1	
12	09320-08062	CUSHION	6	
13	09360-14009	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP	1	
17	09408-00155	CLAMP	1	
18	01550-08407	BOLT	4	
19	15680-93J21	HOSE, FUEL (PUMP TO FILTER)	1	
20	09401-13423	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE, FUEL HOSE	1	
23	01550-06127	BOLT	2	

DF300A_E01_015

FIG.144D





FIG.144D (1-C-4) FUEL INJECTOR (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-93J01	HOSE, FUEL (3WAY TO DLVY PIPE)	1	
2	15710-96J00	INJECTOR ASSY, FUEL	6	
3	15717-16G00	.O RING	6	
4	15735-58B00	INSULATOR, DELIVERY PIPE	4	
5	15751-93J00	PIPE, DELIVERY	2	
6	15756-93J01	HOSE, FUEL (DLVY TO DLVY)	1	
7	15762-93J10	GASKET, DELIVERY PIPE	5	
8	15832-93J00	UNION, DELIVERY PIPE	1	
9	15831-93J00	UNION, DELIVERY PIPE	2	
10	18498-93J00	PROTECTOR, FUEL HOSE (L:340)	1	
11	09247-14042	PLUG (14X14)	1	
12	09320-08062	CUSHION	6	
13	09360-14014	UNION	1	
14	09401-11425	CLIP	4	
15	09403-16307	CLAMP	1	
16	09408-00105	CLAMP	1	
17	09408-00155	CLAMP	1	
18	01550-08407	BOLT	4	
19	15680-93J21	HOSE, FUEL (PUMP TO FILTER)	1	
20	09401-13423	CLIP	1	
21	09408-00135	CLIP	2	
22	15684-98J00	GUIDE, FUEL HOSE	1	
23	01550-06127	BOLT	2	

FIG.147A




DF300A_E01_015_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147A (1-C-5) FUEL PUMP/FUEL VAPOR SEPARATOR (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-94900	PUMP ASSY, FUEL (L)	1	
2	15410-93J10	FILTER, FUEL (L)	1	
3	15411-93J10	.CAP, FILTER	1	
4	15415-93J10	.SEAL, NO.1	1	
5	15412-93J10	.FILTER ASSY, FUEL	1	
6	15413-93J10	.CASE ASSY, FILTER	1	
7	15644-93J00	COVER, FUEL FILTER	3	
8	15633-93J20	HOSE, FUEL (H)	1	
9	15646-93J00	CLAMP, FUEL FILTER	1	
10	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
11	15440-93J00	FILTER, FUEL (EPI)	1	
12	09320-08501	CUSHION	2	
13	15773-90J00	UNION, FUEL HOSE (H)	1	
14	15830-93J00	UNION, 3 WAY	1	
15	09169-06062	WASHER	4	
16	15770-93J00	COOLER, FUEL	1	
17	09168-12013	GASKET (11.8X22X1.2)	3	
18	09360-12008	UNION	1	
19	09363-08004	UNION	1	
20	15600-98J00	SEPARATOR ASSY, FUEL VAPOR	1	
21	13370-93J00	.VALVE ASSY, NEEDLE	1	
22	15626-93J00	.GASKET, SEPARATOR	1	
23	15650-93J00	.FLOAT ASSY	1	
24	15200-98J00	.PUMP ASSY, FUEL (H)	1	
25	15647-93J00	.BUSH, FUEL PUMP	1	
26	15641-90J00	.SPACER, FUEL PUMP	1	
27	15642-90J00	.FILTER, FUEL PUMP	1	
28	15654-99E00	.PIN, FLOAT	1	
29	02142-0408B	.SCREW	1	
30	02112-05107	.SCREW	1	
31	15760-93J00	.REGULATOR, FUEL PRESSURE	1	
32	15628-99E00	.SCREW	6	
33	15627-93J00	.SCREW	1	
34	09320-12072	CUSHION	3	

DF300A_E01_015

FIG.147A



DF300A_E01_015_147A
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147A (1-C-6) FUEL PUMP/FUEL VAPOR SEPARATOR (DF300A E01)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	15675-93J00	BOLT, COOLER BRACKET	3	
36	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->50
37	09401-11414	CLIP (ID:11.5)	14	
38	15636-98J20	HOSE, FUEL (L)	1	
39	15686-93J00	CLIP	1	
40	15685-93J00	CLIP	3	
41	15672-93J00	BRACKET, FUEL COOLER	1	
42	01500-06167	BOLT	4	
43	15635-93J20	HOSE, FUEL (H)	1	
44	15632-93J20	HOSE, FUEL (H)	1	
45	15673-98J00	BRACKET, FUEL FILTER	1	
46	01550-06257	BOLT	2	
47	15643-93J00	FILTER, FUEL (L)	1	
48	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
49	15634-93J20	HOSE, FUEL (H)	1	
50	01570-06357	BOLT	2	
51	15674-93J00	BRACKET, CHECK VALVE	1	
52	15645-93J00	VALVE, CHECK	1	
53	15637-93J20	HOSE, FUEL (L)	1	
54	15629-99E10	SCREW, DRAIN	2	
55	15683-87J00	HOSE, DRAIN	1	
56	02112-0406B	SCREW	3	
57	09401-08412	CLIP	1	
58	18498-93J10	PROTECTOR, EVAP HOSE (L:1130)	1	
59	09160-06084	WASHER (6.5X18X1.6)	2	
60	09169-06062	WASHER	2	
61	01500-06257	BOLT	2	
62	15671-93J00	BRACKET, VAPOR SEPARATOR	1	
63	01550-06357	BOLT	2	
64	09169-08042	WASHER	6	
65	01550-08407	BOLT	3	
66	18417-93J00	BRACKET, PURGE VALVE	1	
67	01550-06127	BOLT	2	
68	09352-50823-00B	HOSE (5X8.2X2000)	1	

DF300A_E01_015

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
69	09320-08086	CUSHION	1	
70	09403-14304	CLAMP	1	
71	09408-00043	CLAMP	1	

FIG.147B




DF300A_E01_015_147B
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147B (1-C-8) FUEL PUMP/FUEL VAPOR SEPARATOR (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-94900	PUMP ASSY, FUEL (L)	1	
2	15410-93J10	FILTER, FUEL (L)	1	
3	15411-93J10	.CAP, FILTER	1	
4	15415-93J10	.SEAL, NO.1	1	
5	15412-93J10	.FILTER ASSY, FUEL	1	
6	15413-93J10	.CASE ASSY, FILTER	1	
7	15644-93J00	COVER, FUEL FILTER	3	
8	15633-93J20	HOSE, FUEL (H)	1	
9	15646-93J00	CLAMP, FUEL FILTER	1	
10	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
11	15440-93J10	FILTER, FUEL (EPI)	1	
12	09320-08501	CUSHION	2	
13	15773-90J00	UNION, FUEL HOSE	1	
14	15830-93J00	UNION, 3 WAY	1	
15	09169-06062	WASHER	4	
16	15770-93J00	COOLER, FUEL	1	
17	15762-90J00	GASKET, FUEL COOLER UNION	3	
18	09360-12013	UNION	1	
19	15830-90J00	UNION, FUEL COOLER	1	
20	15600-98J10	SEPARATOR ASSY, FUEL VAPOR	1	
21	13370-93J00	.VALVE ASSY, NEEDLE	1	
22	15626-93J10	.GASKET, SEPARATOR	1	
23	15650-93J00	.FLOAT ASSY	1	
24	15200-98J10	.PUMP ASSY, FUEL (H)	1	
25	15647-93J10	.BUSH, FUEL PUMP	1	
26	15641-90J10	.SPACER, FUEL PUMP	1	
27	15642-90J00	.FILTER, FUEL PUMP	1	
28	15654-99E00	.PIN, FLOAT	1	
29	13614-93J00	.SCREW	1	
30	15631-99E10	.SCREW, REGULATOR	1	
31	15760-93J00	.REGULATOR, FUEL PRESSURE	1	
32	15628-99E00	.SCREW	6	
33	15627-93J00	.SCREW	1	
34	09320-12072	CUSHION	3	

DF300A_E01_015

FIG.147B




DF300A_E01_015_147B
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147B (1-C-9) FUEL PUMP/FUEL VAPOR SEPARATOR (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	15675-93J00	BOLT, COOLER BRACKET	3	
36	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->50
37	09401-11414	CLIP (ID:11.5)	14	
38	15636-98J20	HOSE, FUEL (L)	1	
39	15686-93J00	CLIP	1	
40	15685-93J00	CLIP	3	
41	15672-93J00	BRACKET, FUEL COOLER	1	
42	01500-06167	BOLT	4	
43	15635-93J20	HOSE, FUEL (H)	1	
44	15632-93J20	HOSE, FUEL (H)	1	
45	15673-98J00	BRACKET, FUEL FILTER	1	
46	01550-06257	BOLT	2	
47	15643-93J00	FILTER, FUEL (L)	1	
48	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
49	15634-93J20	HOSE, FUEL (H)	1	
50	01570-06357	BOLT	2	
51	15674-93J00	BRACKET, CHECK VALVE	1	
52	15645-93J10	VALVE, CHECK	1	
53	15637-93J20	HOSE, FUEL (L)	1	
54	15629-99E10	SCREW, DRAIN	2	
55	15683-87J00	HOSE, DRAIN	1	
56	02112-0406B	SCREW	3	
57	09401-08412	CLIP	1	
58	18498-93J10	PROTECTOR, EVAP HOSE (L:1130)	1	
59	09160-06084	WASHER (6.5X18X1.6)	2	
60	09169-06062	WASHER	2	
61	01500-06257	BOLT	2	
62	15671-93J00	BRACKET, VAPOR SEPARATOR	1	
63	01550-06357	BOLT	2	
64	09169-08042	WASHER	6	
65	01550-08407	BOLT	3	
66	18417-93J00	BRACKET, PURGE VALVE	1	
67	01550-06127	BOLT	2	
68	09352-50823-00B	HOSE (5X8.2X2000)	1	

DF300A_E01_015

FIG.147B




DF300A_E01_015_147B
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147B (1-C-10) FUEL PUMP/FUEL VAPOR SEPARATOR (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
69	09320-08086	CUSHION	1	
70	09403-14304	CLAMP	1	
71	09408-00043	CLAMP	1	

DF300A_E01_015

FIG.147C




DF300A_E01_015_147C
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147C (1-C-11) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-94900	PUMP ASSY, FUEL (L)	1	
2	15410-93J10	FILTER, FUEL (L)	1	
3	15411-93J10	.CAP, FILTER	1	
4	15415-93J10	.SEAL, NO.1	1	
5	15412-93J10	.FILTER ASSY, FUEL	1	
6	15413-93J10	.CASE ASSY, FILTER	1	
7	15644-93J00	COVER, FUEL FILTER	3	
8	15633-93J20	HOSE, FUEL (H)	1	
9	15646-93J00	CLAMP, FUEL FILTER	1	
10	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
11	15440-93J00	FILTER, FUEL (EPI)	1	
12	09320-08501	CUSHION	2	
13	15773-90J00	UNION, FUEL HOSE (H)	1	
14	15830-93J00	UNION, 3 WAY	1	
15	09169-06062	WASHER	4	
16	15770-93J00	COOLER, FUEL	1	
17	09168-12013	GASKET (11.8X22X1.2)	3	
18	09360-12008	UNION	1	
19	09363-08004	UNION	1	
20	15600-98J00	SEPARATOR ASSY, FUEL VAPOR	1	
21	13370-93J00	.VALVE ASSY, NEEDLE	1	
22	15626-93J00	.GASKET, SEPARATOR	1	
23	15650-93J00	.FLOAT ASSY	1	
24	15200-98J00	.PUMP ASSY, FUEL (H)	1	
25	15647-93J00	.BUSH, FUEL PUMP	1	
26	15641-90J00	.SPACER, FUEL PUMP	1	
27	15642-90J00	.FILTER, FUEL PUMP	1	
28	15654-99E00	.PIN, FLOAT	1	
29	02142-0408B	.SCREW	1	
30	02112-05107	.SCREW	1	
31	15760-93J00	.REGULATOR, FUEL PRESSURE	1	
32	15628-99E00	.SCREW	6	
33	15627-93J00	.SCREW	1	
34	09320-12072	CUSHION	3	

DF300A_E01_015

FIG.147C




DF300A_E01_015_147C
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147C (1-C-12) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	15675-93J00	BOLT, COOLER BRACKET	3	
36	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->50
37	09401-11414	CLIP (ID:11.5)	14	
38	15636-98J20	HOSE, FUEL (L)	1	
39	15686-93J00	CLIP	1	
40	15685-93J00	CLIP	3	
41	15672-93J00	BRACKET, FUEL COOLER	1	
42	01500-06167	BOLT	4	
43	15635-93J20	HOSE, FUEL (H)	1	
44	15632-93J20	HOSE, FUEL (H)	1	
45	15673-98J00	BRACKET, FUEL FILTER	1	
46	01550-06257	BOLT	2	
47	15643-93J00	FILTER, FUEL (L)	1	
48	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
49	15634-93J20	HOSE, FUEL (H)	1	
50	01570-06357	BOLT	2	
51	15674-93J00	BRACKET, CHECK VALVE	1	
52	15645-93J00	VALVE, CHECK	1	
53	15637-93J20	HOSE, FUEL (L)	1	
54	15629-99E10	SCREW, DRAIN	2	
55	15683-87J00	HOSE, DRAIN	1	
56	02112-0406B	SCREW	3	
57	09401-08412	CLIP	1	
58	18498-93J10	PROTECTOR, EVAP HOSE (L:1130)	1	
59	09160-06084	WASHER (6.5X18X1.6)	2	
60	09169-06062	WASHER	2	
61	01500-06257	BOLT	2	
62	15671-93J00	BRACKET, VAPOR SEPARATOR	1	
63	01550-06357	BOLT	2	
64	09169-08042	WASHER	6	
65	01550-08407	BOLT	3	
66	18417-93J00	BRACKET, PURGE VALVE	1	
67	01550-06127	BOLT	2	
68	09352-50823-00B	HOSE (5X8.2X2000)	1	

DF300A_E01_015

FIG.147C




DF300A_E01_015_147C
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147C (1-C-13) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
69	09320-08086	CUSHION	1	
70	09403-14304	CLAMP	1	
71	09408-00043	CLAMP	1	

DF300A_E01_015

FIG.147D




DF300A_E01_015_147D
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147D (1-C-14) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-94900	PUMP ASSY, FUEL (L)	1	
2	15410-93J10	FILTER, FUEL (L)	1	
3	15411-93J10	.CAP, FILTER	1	
4	15415-93J10	.SEAL, NO.1	1	
5	15412-93J10	.FILTER ASSY, FUEL	1	
6	15413-93J10	.CASE ASSY, FILTER	1	
7	15644-93J00	COVER, FUEL FILTER	3	
8	15633-93J20	HOSE, FUEL (H)	1	
9	15646-93J00	CLAMP, FUEL FILTER	1	
10	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
11	15440-93J10	FILTER, FUEL (EPI)	1	
12	09320-08501	CUSHION	2	
13	15773-90J00	UNION, FUEL HOSE	1	
14	15830-93J00	UNION, 3 WAY	1	
15	09169-06062	WASHER	4	
16	15770-93J00	COOLER, FUEL	1	
17	15762-90J00	GASKET, FUEL COOLER UNION	3	
18	09360-12013	UNION	1	
19	15830-90J00	UNION, FUEL COOLER	1	
20	15600-98J10	SEPARATOR ASSY, FUEL VAPOR	1	
21	13370-93J00	.VALVE ASSY, NEEDLE	1	
22	15626-93J10	.GASKET, SEPARATOR	1	
23	15650-93J00	.FLOAT ASSY	1	
24	15200-98J10	.PUMP ASSY, FUEL (H)	1	
25	15647-93J10	.BUSH, FUEL PUMP	1	
26	15641-90J10	.SPACER, FUEL PUMP	1	
27	15642-90J00	.FILTER, FUEL PUMP	1	
28	15654-99E00	.PIN, FLOAT	1	
29	13614-93J00	.SCREW	1	
30	15631-99E10	.SCREW, REGULATOR	1	
31	15760-93J00	.REGULATOR, FUEL PRESSURE	1	
32	15628-99E00	.SCREW	6	
33	15627-93J00	.SCREW	1	
34	09320-12072	CUSHION	3	

DF300A_E01_015

FIG.147D




DF300A_E01_015_147D
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147D (1-C-15) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	15675-93J00	BOLT, COOLER BRACKET	3	
36	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->50
37	09401-11414	CLIP (ID:11.5)	14	
38	15636-98J20	HOSE, FUEL (L)	1	
39	15686-93J00	CLIP	1	
40	15685-93J00	CLIP	3	
41	15672-93J00	BRACKET, FUEL COOLER	1	
42	01500-06167	BOLT	4	
43	15635-93J20	HOSE, FUEL (H)	1	
44	15632-93J20	HOSE, FUEL (H)	1	
45	15673-98J00	BRACKET, FUEL FILTER	1	
46	01550-06257	BOLT	2	
47	15643-93J00	FILTER, FUEL (L)	1	
48	09343-75001-600	HOSE (7.5X13.5X600)	1	L:600->65
49	15634-93J20	HOSE, FUEL (H)	1	
50	01570-06357	BOLT	2	
51	15674-93J00	BRACKET, CHECK VALVE	1	
52	15645-93J10	VALVE, CHECK	1	
53	15637-93J20	HOSE, FUEL (L)	1	
54	15629-99E10	SCREW, DRAIN	2	
55	15683-87J00	HOSE, DRAIN	1	
56	02112-0406B	SCREW	3	
57	09401-08412	CLIP	1	
58	18498-93J10	PROTECTOR, EVAP HOSE (L:1130)	1	
59	09160-06084	WASHER (6.5X18X1.6)	2	
60	09169-06062	WASHER	2	
61	01500-06257	BOLT	2	
62	15671-93J00	BRACKET, VAPOR SEPARATOR	1	
63	01550-06357	BOLT	2	
64	09169-08042	WASHER	6	
65	01550-08407	BOLT	3	
66	18417-93J00	BRACKET, PURGE VALVE	1	
67	01550-06127	BOLT	2	
68	09352-50823-00B	HOSE (5X8.2X2000)	1	

DF300A_E01_015

FIG.147D



DF300A_E01_015_147D
FUEL PUMP/FUEL VAPOR SEPARATOR

FIG.147D (1-D-2) FUEL PUMP/FUEL VAPOR SEPARATOR (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
69	09320-08086	CUSHION	1	
70	09403-14304	CLAMP	1	
71	09408-00043	CLAMP	1	

DF300A_E01_015

FIG.160A




FIG.160A (1-D-3) WATER PUMP (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J02	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J01	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-2	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J00	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L00	FILTER, WATER PORT SIDE	1	
14	17632-93L00	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
21	17416-93J00	.SEALING, CASE	1	OPT
22	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
23	17471-98J01	.PANEL, PUMP CASE UNDER	1	OPT
24	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
25	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
26	09420-05009	.KEY	1	OPT

FIG.160B




FIG.160B (1-D-4) WATER PUMP (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J12	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J11	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-2	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J00	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L00	FILTER, WATER PORT SIDE	1	
14	17632-93L00	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
21	17416-93J00	.SEALING, CASE	1	OPT
22	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
23	17471-98J11	.PANEL, PUMP CASE UNDER	1	OPT
24	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
25	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
26	09420-05009	.KEY	1	OPT

FIG.160C




FIG.160C (1-D-5) WATER PUMP (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J02	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J01	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-2	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J00	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L00	FILTER, WATER PORT SIDE	1	
14	17632-93L00	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
21	17416-93J00	.SEALING, CASE	1	OPT
22	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
23	17471-98J01	.PANEL, PUMP CASE UNDER	1	OPT
24	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
25	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
26	09420-05009	.KEY	1	OPT

FIG.160D




FIG.160D (1-D-6) WATER PUMP (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-93J01	CASE, WATER PUMP	1	
2	17413-93J12	SLEEVE, CASE	1	
3	17416-93J00	SEALING, CASE	1	
4	17461-93J00	IMPELLER, WATER PUMP	1	
5	17471-98J11	PANEL, PUMP CASE UNDER	1	
6	17472-98J00	GASKET, PUMP CASE PANEL	1	
7	17473-98J00	PANEL, WATER PUMP NO.2	1	
8-1	17561-93J03	TUBE, WATER (UL)	1	W/TRANSOM(X)
8-2	17561-93J13	TUBE, WATER (XX)	1	W/TRANSOM(XX)
9	17562-93J00	BUSH, WATER TUBE UPPER	1	
10	17563-93J00	BUSH, WATER TUBE LOWER	1	
11	17564-93J00	BUSH, WATER PUMP CASE	1	
12	17612-93J00	SPACER, WATER TUBE	1	
13	17631-93L00	FILTER, WATER PORT SIDE	1	
14	17632-93L00	FILTER, WATER STBD SIDE	1	
15	29116-93J00	BOLT, PUMP CASE PANEL	2	
16	09116-08131	BOLT (8X45)	4	
17	09132-04034	SCREW (4X18)	1	
18	09202-06031	PIN (6X12)	2	
19	09420-05009	KEY	1	
20	17400-98J01	WATER PUMP REPAIR KIT	1	OPT
21	17416-93J00	.SEALING, CASE	1	OPT
22	17461-93J00	.IMPELLER, WATER PUMP	1	OPT
23	17471-98J11	.PANEL, PUMP CASE UNDER	1	OPT
24	17472-98J00	.GASKET, PUMP CASE PANEL	1	OPT
25	17473-98J00	.PANEL, WATER PUMP NO.2	1	OPT
26	09420-05009	.KEY	1	OPT

FIG.162A




FIG.162A (1-D-7) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11196-93J00	HOSE, WATER RETURN STBD	1	
2	11197-93J00	HOSE, WATER RETURN PORT	1	
3	11270-93J00	PLATE, CYL BLOCK WTR JKT	1	
4	11272-93J00	GASKET, CYL BLOCK PLATE	1	
5	17581-93J00	PIPE, OUTLET	2	
6	17582-93J00	GASKET, OUTLET PIPE	2	
7-1	17611-90J00-0EP	COVER, WATER PRESS VALVE (BLACK)	1	
7-2	17611-90J00-Y5S	COVER, WATER PRESS VALVE (WHITE)	1	
8	17660-99E01	VALVE, WATER PRESSURE	1	
9-1	17670-90J20	THERMOSTAT (50C)	2	
9-2	17670-90J10	THERMOSTAT (71C)	1	OPT
10	17681-93J00	COVER, THERMOSTAT	2	
11	17711-90J00	3 WAY, WATER HOSE	1	
12	17712-93J00	HOSE (3 WAY TO E/H COV)	1	
13	09116-06121	BOLT (6X25)	2	
14	09280-26006	O RING (D:3.1,ID:26.4)	1	
15	09320-12014	CUSHION	1	
16	09352-50903-600	HOSE (5X9X600)	1	L:600->60
17	09352-50903-600	HOSE (5X9X600)	1	L:600->120
18	09352-50903-600	HOSE (5X9X600)	1	L:600->190
19	09352-50903-600	HOSE (5X9X600)	1	L:600->300
20	09352-50903-600	HOSE (5X9X600)	1	L:600->330
21	09352-50903-600	HOSE (5X9X600)	1	
22	09352-50903-600	HOSE (5X9X600)	1	
23	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->850
24	09352-50903-00B	HOSE (5X9X2000)	1	L:2000->1010
25	01550-08127	BOLT	1	
26	09367-06002	JOINT, 3 WAY	1	
27	09401-08413	CLIP	18	
28	09401-14409	CLIP	2	
29	09401-25406	CLIP	4	
30	09403-25304	CLAMP	1	
31	09408-00008	CLIP (ID:20)	1	

FIG.162A




FIG.162A (1-D-8) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32	09408-00056	CLIP	1	
33	01550-06207	BOLT	6	
34	01550-06207	BOLT	4	
35	01550-06257	BOLT	10	
36	17713-98J00	HOLDER, WATER HOSE	1	
37	09401-15414	CLIP	2	
38	17915-98J01	HOSE, WATER FLUSH	1	
39	09408-00024	CLIP (ID:23)	1	
40	09408-00021	CLIP (ID:16)	1	
41	36617-93J10	BRACKET, HOSE CLAMP	1	

FIG.163A




FIG.163A (1-D-9) THROTTLE BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11193-98J00	HOSE, PCV	1	
2	11198-58B00	SEAL, PCV VALVE	1	
3	13100-98J01	COLLECTOR ASSY	1	
4	13137-98J00	.SPACER, COLLECTOR	4	
5	13140-98J01	.COVER, COLLECTOR	1	
6	61436-98J00	..MARK, EMBLEM V6 (4.0L)	1	
7	13147-98J00	.GASKET, COLLECTOR COVER	1	
8	13180-98J00	.FUNNEL, COLLECTOR	2	
9	18590-68H00	.SENSOR, MAP	1	
10	09280-10009	.O RING (D:1.3,ID:9.8)	8	
11	01550-08167	.BOLT	4	
12	01550-08357	.BOLT	11	
13	02162-05207	.SCREW	2	
14	04211-11129	.PIN	8	
15	13134-98J00	BRACKET, COLLECTOR	1	
16	13139-98J00	GASKET, COLLECTOR	1	
17	13310-98J00	BODY ASSY, THROTTLE	1	
18	13343-98J10	GASKET, THROTTLE BODY	1	
19	13315-98J00	DAMPER, THROTTLE BODY	1	
20	13421-98J00	GASKET, THROTTLE BODY	1	
21	13813-98J00	GROMMET, THROTTLE BODY	1	
22	09401-13423	CLIP	2	
23	18118-93J00	VALVE, PCV	1	
24	09103-08370	BOLT (8X250)	6	
25	09320-08076	GROMMET	4	
26	09403-13310	CLAMP	1	
27	09408-00155	CLAMP	1	
28	01421-08357	BOLT	2	
29	01550-08167	BOLT	5	
30	01550-08357	BOLT	2	
31	01550-08607	BOLT	2	
32	04211-11129	PIN	2	
33	09159-08136	NUT	4	
34	08316-10087	NUT	2	
35	09160-08161	WASHER (8.2X23X3.2)	2	

FIG.175A




FIG.175A (1-D-10) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12632-93J11	SPROCKET, OIL PUMP DRIVE (NT:32)	1	
2	16113-93J10	SPROCKET, OIL PUMP DRIVEN (NT:18)	1	
3	16400-93J02	PUMP ASSY, OIL	1	
4	16520-93J00	STRAINER, OIL PUMP	1	
5	16760-93J00	CHAIN, OIL PUMP DRIVE	1	
6	16781-93J00	TENSIONER, OIL PUMP CHAIN	1	
7	16782-93J00	SPRING, OIL PUMP TENSIONER	1	
8	16783-93J01	BOLT, OIL PUMP TENSIONER	1	
9	09181-12158	SHIM (12X20X0.5)	1	
10	09280-22020	O RING (D:2.4,ID:21.8)	2	
11	01550-0616A	BOLT	3	
12	01550-0845A	BOLT	1	
13	01550-0865A	BOLT	3	
14	01550-0885A	BOLT	1	
15	08110-60020	BEARING	1	

FIG.180A




FIG.180A (1-D-11) OIL PAN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	11261-93J10-0EP	COVER, PROTECTION ANODE (BLACK)	1	
1-2	11261-93J10-Y5S	COVER, PROTECTION ANODE (WHITE)	1	
2-1	55321-87J00	ANODE, PROTECTION	1	
2-2	55321-87J10	ANODE (MAGNESIUM)	1	OPT
3	29103-93J30	BOLT, ANODE COVER	1	
4	09103-06281	BOLT (6X14)	1	
5	09280-22019	O RING (D:1.9,ID:21.8)	1	
6	11489-93J00	GASKET, OIL PAN	1	
7-1	11501-93J02-0EP	PAN, OIL (BLACK)	1	
7-2	11501-93J02-Y5S	PAN, OIL (WHITE)	1	
8	11591-93J10	UNION, OIL PAN	1	
9-1	11541-93J00-0EP	PIPE, EXHAUST (BLACK)	1	
9-2	11541-93J00-Y5S	PIPE, EXHAUST (WHITE)	1	
10	14154-93J01	SEAL, EXHAUST TUBE	1	
11	14211-98J00	TUBE, EXHAUST	1	
12	14212-93J00	GASKET, EXHAUST TUBE	1	
13	29116-93J00	BOLT, EXHAUST PIPE	4	
14	11435-93J00	PIPE, EXHAUST RELEASE	1	
15	09168-12012	GASKET (12.5X20X2.5)	1	
16	09248-12009	PLUG (12X18.65)	1	
17	09202-08006	PIN (8X12)	2	
18	09202-08006	PIN (8X12)	2	
19	01550-1050A	BOLT	4	
20	09116-08128	BOLT (8X40)	10	
21	09116-10175	BOLT (10X50)	2	
22	09116-10146	BOLT (10X195)	4	
23	29103-93J00	BOLT, SPEEDOMETER HOSE CLAMP	1	
24	29404-93J10	CLAMP, SPEEDOMETER HOSE	1	
25	16910-93J00	GAUGE, OIL LEVEL	1	
26	16930-93J00	GUIDE, OIL LEVEL GAUGE	1	
27	09280-09008	O RING (D:2.1,ID:8.8)	1	
28	01550-06127	BOLT	1	

FIG.204A




FIG.204A (1-D-12) CLUTCH SHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-98J00	LEVER, CLUTCH	1	
2	21131-93J00	BUSH, CLUTCH LEVER	1	
3	21151-93J00	HOLDER, CLUTCH LEVER	1	
4	09160-10148	WASHER (10X20X3)	1	
5	21210-98J01	SHAFT, CLUTCH	1	
6	21230-98J01	ARM, CLUTCH SHAFT	1	
7	23111-93J00	ROD, CLUTCH (UL)	1	
8	23115-98J00	LINK, CLUTCH LEVER	1	
9	25223-94400	COVER, CLUTCH ROD	1	
10	09160-06094	WASHER (6.5X15X1.5)	2	
11	09204-01006	PIN	2	
12	09205-10006	SPRING PIN (10.2X10)	1	
13	09248-12011	PLUG (12X9)	1	
14	09260-10005	BALL	1	
15	09262-17019	BEARING (17X35X8)	1	
16	09289-18001	OIL SEAL (18X30X8)	1	
17	09306-06005	BUSH	2	
18	09306-10001	BUSH	3	
19	09383-08004	E RING	1	
20	09440-07051	SPRING	1	
21	01550-06207	BOLT	1	
22	02142-05107	SCREW	2	
23	08331-41359	CIRCLIP	1	
24	21241-98J10	LINK, CLUTCH LEVER NO.2	1	
25	67467-89J01	CONNECTOR, REMOCON CABLE	1	
26	67471-99E00	NUT, REMOCON CABLE	1	
27	09160-06055	WASHER (7X12X1)	2	
28	09385-06012	CLIP	2	
29	19115-98J10	HOLDER, CLUTCH LEVER	1	
30	01550-08557	BOLT	2	
31	67467-89J10	CONNECTOR, REMOCON CABLE NO.2	1	
32	67471-99E10	NUT, REMOCON CABLE NO.2	1	

FIG.206A




FIG.206A (1-D-13) CLUTCH ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	25112-93L00	ROD, SHIFT DRIVE (X)	1	W/TRANSOM(X)
1-2	25112-93L10	ROD, SHIFT DRIVE (XX)	1	W/TRANSOM(XX)
2	25130-93L00	YOKE, SHIFTER	1	
3	25232-90J00	MAGNET, GEAR CASE	2	
4	09205-03004	SPRING PIN (3X20)	1	
5-1	25141-93L00-0EP	HOUSING, SHIFT ROD GUIDE (BLACK)	1	
5-2	25141-93L00-Y5S	HOUSING, SHIFT ROD GUIDE (WHITE)	1	
6	25222-90J00	COVER, SFT GUIDE HSG OIL SEAL	1	
7	09283-10011	OIL SEAL (10X22X8)	1	
8	25321-93L00	SLIDER, SHIFT HORIZONTAL	1	
9	29116-93J00	BOLT, SHIFT ROD HOUSING	3	
10	09160-10082	WASHER (10.5X19X2)	1	
11	25113-93L00	GEAR, SHIFT ROD (NT:13)	1	
12	25215-93L00	HOUSING, MAGNET	1	
13	09383-07003	E RING	3	
14	55122-93L00	SEALING, SHIFT ROD GUIDE HSG	1	
15	56141-93L00	HOUSING, SHIFT SLIDER	1	
16	17637-93L00	FILTER, WATER PORT FRONT SIDE	1	
17	17638-93L00	FILTER, WATER STBD FRONT SIDE	1	
18	55321-87J00	ANODE, PROTECTION	1	
19	01550-06357	BOLT	2	
20	09103-06281	BOLT (6X14)	1	
21	09206-09012	PIN (7.4X9X10)	2	
22	09132-04034	SCREW (4X18)	1	

FIG.220A




FIG.220A (1-D-14) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57110-93L10	SHAFT, DRIVE (X)	1	W/TRANSOM(X)
1-2	57110-93L20	SHAFT, DRIVE (XX)	1	W/TRANSOM(XX)
2	57133-93L00	COLLAR, DRIVE SHAFT	1	
3	57134-93J00	SPACER, DRIVE SHAFT BEARING	1	
4	09159-28003	NUT	1	
5	09269-32002	BEARING (32X66X49)	1	
6	57300-93L02	SET GEAR	1	
7-1	09181-60004	SHIM (T:0.45)	1	
7-2	09181-60005	SHIM (T:0.50)	1	
7-3	09181-60006	SHIM (T:0.55)	1	
7-4	09181-60007	SHIM (T:0.60)	1	
7-5	09181-60008	SHIM (T:0.65)	1	
7-6	09181-60009	SHIM (T:0.70)	1	
7-7	09181-60010	SHIM (T:0.75)	1	
7-8	09181-60011	SHIM (T:0.80)	1	
7-9	09181-60012	SHIM (T:0.85)	1	
7-10	09181-60013	SHIM (T:0.90)	1	
8	09140-16026	NUT	1	
9	08221-16256	WASHER	1	
10	09180-32006	SPACER (32.4X40X3)	1	REV GEAR
11-1	09181-32035	SHIM (T:0.50)	1	REV GEAR
11-2	09181-32036	SHIM (T:0.55)	1	REV GEAR
11-3	09181-32037	SHIM (T:0.60)	1	REV GEAR
11-4	09181-32038	SHIM (T:0.65)	1	REV GEAR
11-5	09181-32039	SHIM (T:0.70)	1	REV GEAR
11-6	09181-32040	SHIM (T:0.75)	1	REV GEAR
11-7	09181-32041	SHIM (T:0.80)	1	REV GEAR
11-8	09181-32042	SHIM (T:0.85)	1	REV GEAR
11-9	09181-32043	SHIM (T:0.90)	1	REV GEAR
11-10	09181-32044	SHIM (T:0.95)	1	REV GEAR
12	09160-60012	WASHER (60X72X3)	1	FWD GEAR
13	09160-50006	WASHER (50X58X3)	1	REV GEAR

FIG.220A




FIG.220A (1-D-15) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14-1	09181-78001	SHIM (T:0.50)	1	REV GEAR
14-2	09181-78002	SHIM (T:0.55)	1	REV GEAR
14-3	09181-78003	SHIM (T:0.60)	1	REV GEAR
14-4	09181-78004	SHIM (T:0.65)	1	REV GEAR
14-5	09181-78005	SHIM (T:0.70)	1	REV GEAR
14-6	09181-78006	SHIM (T:0.75)	1	REV GEAR
14-7	09181-78007	SHIM (T:0.80)	1	REV GEAR
14-8	09181-78008	SHIM (T:0.85)	1	REV GEAR
14-9	09181-78009	SHIM (T:0.90)	1	REV GEAR
14-10	09181-78010	SHIM (T:0.95)	1	REV GEAR
15-1	09181-84001	SHIM (T:0.50)	1	FWD GEAR
15-2	09181-84002	SHIM (T:0.55)	1	FWD GEAR
15-3	09181-84003	SHIM (T:0.60)	1	FWD GEAR
15-4	09181-84004	SHIM (T:0.65)	1	FWD GEAR
15-5	09181-84005	SHIM (T:0.70)	1	FWD GEAR
15-6	09181-84006	SHIM (T:0.75)	1	FWD GEAR
15-7	09181-84007	SHIM (T:0.80)	1	FWD GEAR
15-8	09181-84008	SHIM (T:0.85)	1	FWD GEAR
15-9	09181-84009	SHIM (T:0.90)	1	FWD GEAR
15-10	09181-84010	SHIM (T:0.95)	1	FWD GEAR
16	09265-30033	BEARING (30X72X28.75)	1	
17	57610-93L00	SHAFT, PROPELLER	1	
18	57621-93L00	SHIFTER, CLUTCH DOG	1	
19	09202-08013	PIN (8X55)	1	
20	57631-93L01	PIN, CONNECTOR	1	
21	09440-58001	SPRING	1	
22	57617-93L00	SPRING, DETENT	1	
23	06111-07004	BALL	2	
24	06111-11004	BALL	2	
25-1	56120-93L10-0EP	HOUSING, PROP SFT BRG (BLACK)	1	
25-2	56120-93L10-Y5S	HOUSING, PROP SFT BRG (WHITE)	1	
26	56124-93L00	.WASHER, REVERSE GEAR THRUST	1	
27	09263-30023	.BEARING (30X40X25)	1	
28	09263-72001	.BEARING (72X90X34)	1	

FIG.220A




FIG.220A (1-E-2) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	09280-00047	.O RING (D:3, ID:109)	1	
30	09282-30006	.OIL SEAL (30X45X6)	2	
31	09381-40003	.CIRCLIP	1	
32	56130-93J01	HOUSING, DRIVE SHAFT BRG	1	
33	09280-66004	.O RING (D:3.1, ID:65.4)	1	
34	09282-24004	.OIL SEAL (24X40X7)	2	
35	57622-93L00	SPACER, FORWARD THRUST	1	
36	09265-32003	BEARING (32X58X17)	1	
37	09381-72001	SNAP RING	1	
38	08331-4158A	CIRCLIP	1	
39	56122-93L00	STOPPER, PROP SFT BRG HSG	1	
40	56126-93L00	WASHER., PROP SFT BRG HSG NO.1	1	
41	56127-93L00	WASHER., PROP SFT BRG HSG NO.2	1	
42	56128-93L00	SEAL, PROP SFT BRG HSG	1	
43	56129-93L00	BUSH, STOPPER	1	
44	09280-00030	O RING (D:1.8, ID:117.6)	1	
45	09263-78001	BEARING (78.26X105X5.45)	1	REVERSE
46	09263-83001	BEARING (83.26X110X5.45)	1	FORWARD

FIG.301A




FIG.301A (1-E-3) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-96J02	STARTING MOTOR	1	
2	31131-90J01	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-90J02	.HOLDER, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-93J00	.PINION	1	
13	31341-93J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31913-93J00	.TERMINAL	1	
18	31914-93J00	.CAP, TERMINAL	1	
19	31170-90J00	.COVER ASSY, REAR	1	
20	31912-98J00	BAND, STARTING MOTOR	1	
21	31918-90J10	DAMPER, LOWER	1	
22	36645-93J00	LEAD WIRE	1	
23	01550-08207	BOLT	2	LOWER
24	01550-08307	BOLT	2	UPPER

DF300A_E01_015_303A
MAGNETO



DF300A_E01_015

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	32102-98J01	FLYWHEEL	1	
2	09103-12125	BOLT (12X26)	8	
3	09202-06031	PIN (6X12)	1	
4	32120-93J00	COIL, BATTERY CHARGING	1	
5	32131-93J00	HOLDER, STATOR CONNECTING	1	
6	01550-06167	BOLT	2	
7	32160-88L00	COIL, IGNITION TIMING	1	
8	09106-05030	BOLT (5X10)	2	
9	33220-69J00	SENSOR, CAM POSITION	3	
10	33221-42F00	.O RING	3	
11	01550-06167	BOLT	3	
12	09103-06231	BOLT (6X35)	4	
13	09403-13408	CLAMP	2	
14	01550-06127	BOLT	2	

FIG.310A




FIG.310A (1-E-5) RECTIFIER/IGNITION COIL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-98J01	RECTIFIER & REGULATOR	1	
2	32805-93J00	O RING, RECTIFIER & REGULATOR	2	
3	32890-98J01	HOLDER, ELECTRIC PARTS	1	
4	09160-06134	WASHER (6.5X24X1.6)	1	
5	09169-06062	WASHER	3	
6	09320-09016	CUSHION	3	
7	09116-06202	BOLT (6X25)	3	
8	09320-12076	CUSHION	1	
9	01550-06127	BOLT	1	
10	01550-06257	BOLT	4	
11	33410-93J00	COIL ASSY, IGNITION	6	
12	01547-06207	BOLT	6	
13	09408-00021	CLIP (ID:16)	1	



FIG.315A




FIG.315A (1-E-6) SENSOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13650-52G00	SENSOR, INLET AIR TEMP	1	
2	13655-87J00	GROMMET, AIR TEMP SENSOR	1	
3	29103-93J00	BOLT, PTT MOTOR LEAD CLAMP	1	
4	34830-87J20	SENSOR ASSY, EXHAUST TEMP	2	
5	34830-87J20	SENSOR ASSY, CYLINDER TEMP	1	
6	34840-98J03	SENSOR ASSY, TRIM	1	
7	37820-98J00	SWITCH ASSY, OIL PRESSURE	1	
8	09125-06063	SCREW (6X10)	1	
9	09403-19409	CLAMP	1	
10	29404-93J10	CLAMP, PTT MOTOR LEAD	1	
11	09407-14407	CLAMP (L:145)	2	
12	34841-88L00	LEVER, TRIM SENSOR	1	
13	34845-88L01	BRACKET, TRIM SENSOR	1	
14	09140-05005	.NUT	1	
15	09125-05048	SCREW (5X16)	1	
16	09160-05029	WASHER (5.5X12X0.8)	1	
17	09103-06093	BOLT (6X20)	2	
18	18213-98J10	SENSOR, OXYGEN	1	
19	09403-07340	CLAMP	1	
20	11218-98J01	HOLDER, TEMP SENSOR	1	
21	11219-98J00	HOLDER, OIL SENSOR	1	
22	34830-98J00	SENSOR ASSY, OIL TEMP	1	

FIG.322A





FIG.322A (1-E-7) HARNESS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-93J01	CABLE, STARTER MOTOR	1	
2	08316-10087	NUT	1	
3	36610-98J50	HARNESS ASSY, WIRING	1	
4	09481-10501	.FUSE (10A)	2	
5	36612-98J10	.CONNECTOR, SELECT TERMINAL	1	
6	36721-96J00	.O RING, UPPER COVER	1	
7	36737-96J00	.PULLER, FUSE	1	
8	36738-98J00	.COVER, FUSE CASE UPPER	1	
9	09320-08021	.CUSHION	2	
10	38860-76F01	.RELAY, ENG CONTROL UNIT	1	
11	38860-76F01	.RELAY, STARTER MOTOR	1	
12	09481-15501	.FUSE (15A)	5	
13	09481-30501	.FUSE (30A)	3	
14	09481-40401	.FUSE (40A)	1	
15	09481-60401	.FUSE (60A)	2	
16	08310-00067	NUT	1	
17	08321-01067	WASHER	1	
18	36617-93J00	BRACKET, HARNESS	3	
19	36617-93J10	BRACKET, HARNESS	8	
20	36617-98J00	BRACKET, HARNESS	1	
21	01550-06127	BOLT	12	
22	09403-20308	CLAMP	1	
23	09407-14407	CLAMP (L:145)	4	
24	09408-00008	CLIP (ID:20)	2	
25	09408-00184	CLAMP	3	
26	09408-00012	CLIP (ID:11.5)	1	
27	09408-00008	CLIP (ID:20)	1	
28	01550-06127	BOLT	1	
29	36625-98J10	WIRE ASSY, BATTEERY	1	OPT
30	09481-30501	.FUSE (30A)	1	OPT

FIG.326A




DF300A_E01_015_326A
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326A (1-E-8) PTT SWITCH/ENGINE CONTROL UNIT (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-98J00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH	1	
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J11	SWITCH ASSY, TILT LIMIT	1	
17	09403-09316	CLAMP	1	
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23	33920-98JE0	UNIT, ENGINE CONTROL	1	
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J10	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38860-76F01	RELAY, OXYGEN SENSOR HEATER	1	
32	38915-90J00	HOLDER, RELAY	3	

DF300A_E01_015

FIG.326B




DF300A_E01_015_326B
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326B (1-E-9) PTT SWITCH/ENGINE CONTROL UNIT (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-98J00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH		
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J11	SWITCH ASSY, TILT LIMIT	1	
17	09403-09316	CLAMP	1	
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23	33920-98JE0	UNIT, ENGINE CONTROL	1	
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J10	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38860-76F01	RELAY, OXYGEN SENSOR HEATER	1	
32	38915-90J00	HOLDER, RELAY	3	

DF300A_E01_015

FIG.326C




DF300A_E01_015_326C
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326C (1-E-10) PTT SWITCH/ENGINE CONTROL UNIT (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-98J00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH		
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J11	SWITCH ASSY, TILT LIMIT	1	
17	09403-09316	CLAMP	1	
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23	33920-98JF0	UNIT, ENGINE CONTROL	1	
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J10	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38860-76F01	RELAY, OXYGEN SENSOR HEATER	1	
32	38915-90J00	HOLDER, RELAY	3	

DF300A_E01_015

FIG.326D



DF300A_E01_015_326D
PTT SWITCH/ENGINE CONTROL UNIT

FIG.326D (1-E-11) PTT SWITCH/ENGINE CONTROL UNIT (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13580-98J02	SENSOR ASSY, SHIFT POSITION	1	
2	13575-40F00	.O RING	1	
3	37729-98J00	LEVER, SHIFT SENSOR	1	
4	09160-05029	WASHER (5.5X12X0.8)	1	
5	07130-05167	BOLT	1	
6	08321-0105A	WASHER	1	
7	37721-93J00	SWITCH ASSY, NEUTRAL	1	
8	09137-04004	SCREW (4X16)	2	
9	09407-10404	CLAMP (L:100)	2	
10	37725-93J11	COVER, SWITCH ASSY	1	
11	37850-92J00	SWITCH ASSY, PTT	1	
12	37856-92J00	.TAPE, PTT SWITCH		
13	37857-92J00	BUSH, PTT SWITCH	1	
14	09403-11315	CLAMP	1	
15	01550-06127	BOLT	1	
16	37722-93J11	SWITCH ASSY, TILT LIMIT	1	
17	09403-09316	CLAMP	1	
18	29125-93J00	SCREW, TILT LIMIT CLAMP	1	
19	38410-93J12	RELAY, PTT	1	
20	38415-93J00	HOLDER, PTT RELAY	1	
21	01550-06127	BOLT	1	
22	09407-30401	CLAMP (L:300)	1	
23	33920-98JF0	UNIT, ENGINE CONTROL	1	
24	33925-98J00	CUSHION, ENGINE CONTROL UNIT	1	
25	38890-98J10	ACTUATOR, SHIFT	1	
26	38892-98J00	DAMPER, SHIFT ACTUATOR	1	
27	38895-98J00	BRACKET, SHIFT ACTUATOR	1	
28	01550-06167	BOLT	2	
29	01550-06357	BOLT	3	
30	38860-76F01	RELAY, ACTUATOR	2	
31	38860-76F01	RELAY, OXYGEN SENSOR HEATER	1	
32	38915-90J00	HOLDER, RELAY	3	

DF300A_E01_015

FIG.335A




FIG.335A (1-E-12) CLAMP BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-93J14-0EP	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-93J14-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-93J06-0EP	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-93J06-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41117-93J01	PLATE, CLAMP BRKT LOWER STBD	1	
4	41122-93J01	PLATE, CLAMP BRKT LOWER PORT	1	
5	09125-06063	SCREW (6X10)	4	
6	41130-93J12	SHAFT, CLAMP BRKT	1	
7	41135-93J11	WASHER, CLAMP BRACKET SHAFT	1	
8	09159-22006	NUT	1	
9-1	09100-12085	BOLT (12.7X115)	1	OPT
9-2	09100-12092	BOLT (12.7X75)	1	OPT
9-3	09100-12086	BOLT (12.7X150)	6	
10	09159-12062	NUT	6	
11	09160-13022	WASHER	4	
12	09160-13021	WASHER	6	
13	41155-93J02	PLATE, TRANSOM	2	
14	55320-94900	ZINC SET, PROTECTION	1	
15	09116-06121	.BOLT (6X25)	2	
16	45421-87D02	PIN, TILT LOCK	1	
17	09159-14020	NUT	2	
18	48140-93J01	CAM, TILT LIMIT SWITCH	1	
19	48144-93J00	HOLDER, TILT LIMIT SWITCH	1	
20	09103-06278	BOLT (6X25)	2	
21	55321-94910	ANODE (MAGNESIUM)	1	OPT
22	48145-93J00	COVER, TILT LIMIT SWITCH	1	
23	36894-87D00	LEAD (CLAMP TO SWIVEL)	1	
24	09125-06063	SCREW (6X10)	2	

FIG.336A




FIG.336A (1-E-13) SWIVEL BRACKET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE, GREASE SWIVEL BRKT	4	
2	36894-87D00	LEAD (SWIVEL TO MOUNT BRKT)	1	
3-1	43111-93J23-0EP	BRACKET, SWIVEL (BLACK)	1	
3-2	43111-93J23-Y5S	BRACKET, SWIVEL (WHITE)	1	
4	43114-93J00	WASHER, SWIVEL TO CLAMP BRKT	2	
5	43211-93J00	BUSH, CLAMP SHAFT SWIVEL	2	
6	43711-97E01	BUSH, STEERING	2	
7-1	43750-93J20-0EP	BRACKET, STEERING (BLACK)	1	
7-2	43750-93J20-Y5S	BRACKET, STEERING (WHITE)	1	
8	09125-06063	SCREW (6X10)	1	
9	09160-39001	WASHER (39.5X64X1)	2	
10	09181-39001	SHIM (39.5X64X0.3)	AR	
11	09282-39001	OIL SEAL (39X51X5)	1	
12	09380-38003	CIRCLIP	1	
13	41220-93J11	LEVER, TILT LOCK	1	
14	41234-93J11	LEVER, TILT LOCK PORT	1	
15	41224-95E01	BUSH, TILT STOPPER ROD	2	
16	41230-96J00	LINK, TILT LOCK LEVER	1	
17	41233-95E10	BRACKET, TILT LOCK SPRING	1	
18	09125-06063	SCREW (6X10)	1	
19	09140-10032	NUT	1	
20	09160-06082	WASHER (6.5X13X1.0)	1	
21	09204-01006	PIN	1	
22	09440-19028	SPRING	1	
23	09443-10043	SPRING	1	

FIG.337A




FIG.337A (1-E-14) TRIM CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48500-98J03	MANIFOLD ASSY	1	
2	48582-95E01	.FILTER	1	
3	48605-93J00	.O RING SET	2	
4	48610-93J01	.PISTON / RAM	2	
5	48630-98J01	.ROD GUIDE	2	
6	48633-93J00	..O RING	4	
7	48691-93J00	.CHECK VALVE	1	
8	48400-98J02	CYLINDER ASSY	1	
9	48405-93J00	.O RING SET	1	
10	48650-93J00	.PISTON, FREE	1	
11	48627-93J00	.O RING SET	1	
12	48572-87J10	PLUG	1	
13	48585-95E00	O RING	1	
14	48862-87J20	BOLT, RESERVOIR	2	
15	48864-93J01	MANUAL VALVE	1	
16	48583-95E00	JOINT, DRIVE	1	
17	48121-93J13	SHAFT	1	
18	48125-93J00	O RING SET	1	
19	48126-93J00	WASHER, TILT CYL TO MANIF	2	
20	48320-93J00	VALVE SET, UP BLOW	1	
21	48573-93J00	COVER	1	
22	48128-93J11	BOLT	1	
23	48311-96J10	PAD, TRIM CYL RAM	2	
24	48321-93J00	SHAFT, TILT CYL UPPER	1	
25	29141-93J20	NUT, TRIM CYL RAM	2	
26	09162-10005	LOCK WASHER	2	
27	09306-24001	BUSH	2	
28	09380-21002	CIRCLIP	2	
29	09116-10175	BOLT (10X50)	8	
30	48571-93J00	RESERVOIR TANK	1	

FIG.337A




FIG.337A (1-E-15) TRIM CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	36894-87D00	LEAD, PTT TO ANODE	1	
32	36895-87D01	LEAD, PTT TO ANODE	1	
33	36895-87D01	LEAD, PTT TO ANODE	1	
34	09125-06063	SCREW (6X10)	1	
35	09125-06063	SCREW (6X10)	1	
36	09125-06063	SCREW (6X10)	1	

FIG.340A




FIG.340A (1-F-2) PTT MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-93J03	MOTOR ASSY, PTT	1	
2	31111-94900	.SCREW, YOKE	3	
3	31123-94910	.O RING	1	
4	31133-90J00	.BRUSH SET, PLUS	1	
5	31133-94900	..BRUSH	1	
6	31135-94900	.SPRING	2	
7	31136-90J10	.BREAKER	1	
8	31173-94910	.HOLDER, BRUSH	1	
9	31311-93J00	.ARMATURE	1	
10	33799-97E00	.OIL SEAL	1	
11	31281-92J10	BOLT	4	
12	48585-95E00	O RING	1	



FIG.401A




FIG.401A (1-F-3) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	51111-93J20-0EP	HOLDER, ENGINE (BLACK)	1	
1-2	51111-93J20-Y5S	HOLDER, ENGINE (WHITE)	1	
2	16519-93J00	SEAL, ENGINE HOLDER OIL	1	
3	17913-93J00	PLUG, WATER	1	
4	17914-93J00	GASKET, WATER PLUG	1	
5	51116-93J00	SEAL, WATER RETURN	1	
6	51211-93J00	GASKET, ENGINE HOLDER	1	
7	61155-93J20	UNION, WATER INDICATOR	1	
8	09206-08001	PIN (8X11)	2	
9	01550-08307	BOLT	6	
10	51122-93J02	COVER, MOUNT OIL SEAL	1	
11	51124-93J01	OIL SEAL	2	
12	51125-93J00	SCRAPER	1	
13	51123-93J00	GASKET, MOUNT OIL SEAL COVER	1	
14	09103-08109	BOLT (8X120)	2	
15	09206-08001	PIN (8X11)	2	
16	01550-0830A	BOLT	6	
17-1	51140-98J00-0EP	COVER, ENGINE HOLDER (BLACK)	1	
17-2	51140-98J00-Y5S	COVER, ENGINE HOLDER (WHITE)	1	
18	51142-93J00	GASKET, ENGINE HOLDER COVER	1	
19	09116-08122	BOLT (8X30)	8	
20	51151-93J00	COVER, ENGINE HOLDER UPPER	1	
21	51152-93J00	SEAL, ENGINE HOLDER UPPER COV	1	
22	01550-08307	BOLT	3	
23	01550-08607	BOLT	2	
24	54123-93J02	PLATE, UPPER MOUNT	1	
25	54130-93J01	MOUNT, UPPER	2	
26	09100-14004	BOLT (14X220)	2	
27	09159-14026	NUT	2	
28	09160-15051	WASHER (15X24X3)	2	
29	54137-93J02	COVER, UPPER MOUNT	1	
30	09116-10135	BOLT (10X95)	2	
31	09116-10175	BOLT (10X50)	1	

FIG.401A




FIG.401A (1-F-4) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
32	54121-98J00	STOPPER, UPPER THRUST	2	
33	54140-98J00	MOUNT, UPPER THRUST REVERSE	1	
34	09116-10137	BOLT (10X70)	6	
35	09116-10175	BOLT (10X50)	4	
36	09116-10146	BOLT (10X195)	2	
37	09116-10134	BOLT (10X115)	1	
38	09116-08126	BOLT (8X65)	4	
39	09169-08038	WASHER (8.3X15X3)	2	

FIG.405A




FIG.405A (1-F-5) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	52111-98J00-0EP	HOUSING, DRIVE SHAFT (BLACK)	1	
1-2	52111-98J00-Y5S	HOUSING, DRIVE SHAFT (WHITE)	1	
2	09116-10176	BOLT (10X44)	8	
3	09202-08006	PIN (8X12)	2	
4	57130-87D10	BUSH, DRIVE SHAFT	1	
5	09387-38002	RING	1	
6	09125-06063	SCREW (6X10)	1	
7-1	52131-93J00-0EP	CASE, EXTENSION (BLACK)	1	W/TRANSOM(XX)
7-2	52131-93J00-Y5S	CASE, EXTENSION (WHITE)	1	W/TRANSOM(XX)
8	09108-10115	STUD BOLT	6	W/TRANSOM(XX)
9	09108-12013	STUD BOLT	1	W/TRANSOM(XX)
10	09202-08006	PIN (8X12)	2	W/TRANSOM(XX)
11	36894-87D00	LEAD, MT BRKT TO HSG	1	
12	09125-06063	SCREW (6X10)	1	
13	54150-98J00	MOUNT, LOWER THRUST	1	
14	54160-98J00	MOUNT, LOWER	2	
15	09100-14004	BOLT (14X220)	2	
16	09160-16050	WASHER (16X32X3)	2	
17	09159-14026	NUT	2	
18	09160-16050	WASHER (16X32X3)	2	
19-1	54211-93J00-0EP	BRACKET, LOWER MOUNT (BLACK)	1	
19-2	54211-93J00-Y5S	BRACKET, LOWER MOUNT (WHITE)	1	
20-1	54221-93J00-0EP	COVER, LOWER MOUNT (BLACK)	2	
20-2	54221-93J00-Y5S	COVER, LOWER MOUNT (WHITE)	2	
21	09116-10175	BOLT (10X50)	4	
22	54165-98J00	DAMPER, REVERSE STOPPER LOWER	4	
23	09160-14066	WASHER (14X50X4)	2	
24	29404-93J10	CLAMP, SPEEDOMETER HOSE	1	
25	29103-93J00	BOLT, CLAMP (6X12)	1	
26-1	55321-93J00	ANODE, PROTECTION	1	W/TRANSOM(X)
26-2	55321-93J00	ANODE, PROTECTION	2	W/TRANSOM(XX)
27-1	09116-06236	BOLT (6X16)	1	W/TRANSOM(X)
27-2	09116-06236	BOLT (6X16)	2	W/TRANSOM(XX)

FIG.407A




FIG.407A (1-F-6) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55110-93L00-0EP	CASE, GEAR (BLACK)	1	
1-2	55110-93L00-Y5S	CASE, GEAR (WHITE)	1	
2	55118-93L00	.WASHER, FORWARD GEAR THRUST	1	
3	09206-03001	.BUSH (2X3X11)	1	
4	09263-35048	.BEARING (35X56X37)	1	
5	09263-80001	.BEARING (80X100X30)	1	
6	09100-12052	BOLT (12X70)	1	W/TRANSOM(X)
7	09116-10150	BOLT (10X55)	6	W/TRANSOM(X)
8	09160-10141	WASHER (10.5X19X2)	6	W/TRANSOM(XX)
9	09160-12066	WASHER (12.5X22X2.5)	1	
10	29141-93J20	NUT, EXTENSION BOLT NO.1	6	W/TRANSOM(XX)
11	09159-12014	NUT	1	W/TRANSOM(XX)
12	09202-08006	PIN (8X12)	2	
13-1	55125-93L00-0EP	TAB, TRIM (BLACK)	1	
13-2	55125-93L00-Y5S	TAB, TRIM (WHITE)	1	
14	09116-08137	BOLT (8X22)	1	
15	55128-93J10	PLUG, DRAIN	1	
16	09168-10034	GASKET (9.5X16.5X2)	2	
17	55321-93J00	ANODE, PROTECTION	2	
18	09116-06236	BOLT (6X16)	2	
19	55332-98J00	RUBBER, EXHAUST SEAL	1	
20	55333-98J00	PLATE, EXHAUST SEAL	1	
21	55127-87D00	UNION, SPEEDOMETER HOSE	1	
22	09355-40805-00B	HOSE (4X8X2000)	1	L:2000->1300
23	09362-09008	UNION	1	
24	09407-10404	CLAMP (L:100)	1	
25	09202-06031	PIN (6X12)	2	
26-1	58200-93L00	PROPELLER (3X16X17)	1	W/REGULAR ROTATION
26-2	58200-93L10	PROPELLER (3X16X18.5)	1	W/REGULAR ROTATION
26-3	58200-93L20	PROPELLER (3X16X20)	1	W/REGULAR ROTATION
26-4	58200-93L30	PROPELLER (3X16X21.5)	1	W/REGULAR ROTATION
26-5	58200-93L40	PROPELLER (3X16X23)	1	W/REGULAR ROTATION
26-6	58200-93L50	PROPELLER (3X16X24.5)	1	W/REGULAR ROTATION
26-7	58200-93L80	PROPELLER (3X16X15)	1	W/REGULAR ROTATION

FIG.407A




FIG.407A (1-F-7) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26-8	58200-93L60	PROPELLER (3X16X26)	1	OPT W/REGULAR ROTATION
26-9	58200-93L70	PROPELLER (3X16X27.5)	1	OPT W/REGULAR ROTATION
26-10	58200-93L80	PROPELLER (3X16X15)	1	OPT W/REGULAR ROTATION
26-11	58300-93J00	PROPELLER (4X15.25X18)	1	OPT W/REGULAR ROTATION
26-12	58300-93J10	PROPELLER (4X15.25X20)	1	OPT W/REGULAR ROTATION
26-13	58300-93J20	PROPELLER (4X15.25X22)	1	OPT W/REGULAR ROTATION
26-14	58300-93J30	PROPELLER (4X15.25X24)	1	OPT W/REGULAR ROTATION
26-15	58300-93J40	PROPELLER (4X15.25X26)	1	OPT W/REGULAR ROTATION
26-16	58200-93LA0	PROPELLER (3X16X18.5)	1	W/COUNTER ROTATION
26-17	58200-93LB0	PROPELLER (3X16X20)	1	W/COUNTER ROTATION
26-18	58200-93LC0	PROPELLER (3X16X21.5)	1	W/COUNTER ROTATION
26-19	58200-93LD0	PROPELLER (3X16X23)	1	W/COUNTER ROTATION
26-20	58200-93LE0	PROPELLER (3X16X17)	1	W/COUNTER ROTATION
26-21	58200-93LF0	PROPELLER (3X16X24.5)	1	OPT W/COUNTER ROTATION
26-22	58200-93LG0	PROPELLER (3X16X26)	1	OPT W/COUNTER ROTATION
26-23	58300-93JA0	PROPELLER (4X15.25X20)	1	OPT W/COUNTER ROTATION
26-24	58300-93JB0	PROPELLER (4X15.25X22)	1	OPT W/COUNTER ROTATION
26-25	58300-93JC0	PROPELLER (4X15.25X24)	1	OPT W/COUNTER ROTATION
26-26	58300-93JD0	PROPELLER (4X15.25X26)	1	OPT W/COUNTER ROTATION
27	58105-93J10	.BUSH SET, PROPELLER	1	

FIG. 407A

This diagram shows an exploded perspective view of a boat hull assembly. The main components are labeled with numbers: 1 (hull), 2 (flange), 3 (pin), 4 (cylindrical component), 5 (flange), 6 (nut), 7 (pin), 8 (nut), 9 (washer), 10 (nut), 11 (washer), 12 (pin), 13 (circular plate), 14 (pin), 15 (nut), 16 (washer), 17 (pin), 18 (pin), 19 (flange), 20 (flange), 21 (pin), 22 (pin), 23 (pin), 24 (pin), 25 (pin), 26 (pin), 27 (pin), 28 (pin), 29 (pin), 30 (propeller), 31 (pin), 32 (pin), 33 (pin), 34 (pin), 35 (pin), 36 (pin), 37 (pin), and 38 (pin). The assembly includes a hull, a propeller, and various internal components like a pump or motor housing. A small arrow in the bottom left corner points to the right.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
28-1	58200-96J00	PROPELLER (3X15.5X17)	1	OPT W/REGULAR ROTATION
28-2	58200-96J10	PROPELLER (3X15.25X19)	1	OPT W/REGULAR ROTATION
28-3	58200-96J20	PROPELLER (3X14.75X21)	1	OPT W/REGULAR ROTATION
28-4	58200-96J30	PROPELLER (3X14.75X23)	1	OPT W/REGULAR ROTATION
28-5	58200-96J40	PROPELLER (3X14.5X25)	1	OPT W/REGULAR ROTATION
28-6	58200-96J50	PROPELLER (3X14.5X27)	1	OPT W/REGULAR ROTATION
28-7	58200-96JA0	PROPELLER (3X15.5X17)	1	OPT W/COUNTER ROTATION
28-8	58200-96JB0	PROPELLER (3X15.25X19)	1	OPT W/COUNTER ROTATION
28-9	58200-96JC0	PROPELLER (3X14.75X21)	1	OPT W/COUNTER ROTATION
28-10	58200-96JD0	PROPELLER (3X14.75X23)	1	OPT W/COUNTER ROTATION
28-11	58200-96JE0	PROPELLER (3X14.5X25)	1	OPT W/COUNTER ROTATION
28-12	58200-96JF0	PROPELLER (3X14.5X27)	1	OPT W/COUNTER ROTATION
29	58105-93J10	.BUSH SET, PROPELLER	1	
30	57632-93L01	STOPPER, PROPELLER BUSH	1	
31	57633-87D30	SPACER, PROPELLER NUT	1	
32	09141-18005	NUT	1	
33	09160-18028	WASHER (18.5X31X1)	1	
34	09204-03003	COTTER PIN (D:3.6,L:25)	1	
35	55128-93L00	PLUG, DRAIN	1	
36	29404-93J10	CLAMP	1	
37	01550-06127	BOLT	2	

FIG.407A




FIG.407A (1-F-9) GEAR CASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
38	57630-92E00	KIT, PROPELLER NUT	1	OPT
39	25700-93L00	KIT, GEAR CASE SEALING	1	OPT NOT ILLUSTRATED

FIG.410A




FIG.410A (1-F-10) SIDE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61131-93J01-0EP	COVER, OIL PAN STBD (BLACK)	1	
1-2	61131-93J01-Y5S	COVER, OIL PAN STBD (WHITE)	1	
2-1	61141-93J01-0EP	COVER, OIL PAN PORT (BLACK)	1	
2-2	61141-93J01-Y5S	COVER, OIL PAN PORT (WHITE)	1	
3	61137-93J00	CUSHION, OIL PAN COV UPPER	2	
4	09139-06135	SCREW (6X17)	5	
5	09139-06136	SCREW (6X65)	3	
6-1	61811-98J20-0EP	COVER, SIDE STBD (BLACK)	1	
6-2	61811-98J20-Y5S	COVER, SIDE STBD (WHITE)	1	
7-1	61821-98J10-0EP	COVER, SIDE PORT (BLACK)	1	
7-2	61821-98J10-Y5S	COVER, SIDE PORT (WHITE)	1	
8	61134-93J20	SEAL, SIDE COVER	1	
9	09409-05302-5PK	CLIP (BLACK)	2	
10	61817-93J00	PLUG, SIDE COVER	2	
11	09136-06148	SCREW (6X35)	10	
12	61827-93J02	HOLDER, SIDE COVER	1	
13	09321-10030	CUSHION	2	
14	01550-08167	BOLT	2	
15	61832-98J00	SEAL, FRONT PANEL STBD	1	
16	61812-98J00	SEAL, SIDE COVER	1	
17	61814-98J00	PROTECTOR, SIDE COVER	1	
18-1	61831-98J02-0EP	PANEL, FRONT (BLACK)	1	
18-2	61831-98J02-Y5S	PANEL, FRONT (WHITE)	1	
19	09116-08163	BOLT (8X38)	2	
20	09169-08039	WASHER	2	
21	09320-11013	CUSHION	2	
22	09321-10030	CUSHION	3	
23	17913-93J00	PLUG, WATER	1	
24	17914-93J00	GASKET, WATER PLUG	1	
25	61112-98J00	RUBBER, SIDE COVER	1	
26	61630-98J00	SHAFT, COVER HOOK (FRONT)	1	
27	63632-98J20	SHAFT, COVER HOOK (PORT)	1	
28	63632-98J30	SHAFT, COVER HOOK (STBD)	1	
29	09306-17002	BUSH	3	

FIG.410A





FIG.410A (1-F-11) SIDE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09160-17052	WASHER (17X30X3)	3	
31	61636-98J00	BUSH	3	
32-1	61633-98J10-0EP	LEVER, HOOK RR STBD (BLACK)	1	
32-2	61633-98J10-Y5S	LEVER, HOOK RR STBD (WHITE)	1	
33-1	61634-98J10-0EP	LEVER, HOOK RR PORT (BLACK)	1	
33-2	61634-98J10-Y5S	LEVER, HOOK RR PORT (WHITE)	1	
34-1	61645-98J00-0EP	LEVER, HOOK FRONT (BLACK)	1	
34-2	61645-98J00-Y5S	LEVER, HOOK FRONT (WHITE)	1	
35	29103-93J20	BOLT, HOOK LEVER (8X45) (STBD / PORT)	2	
36	29103-93J30	BOLT, HOOK LEVER (8X25) (FRONT)	1	
37	09160-08152	WASHER (8.5X28X1.5)	2	
38	09160-08082	WASHER (8.5X16X1.2)	1	
39	61635-98J00	SPACER	2	
40	61643-98J00	BUSH	2	
41	61658-98J00	SPRING, HOOK SHAFT	3	
42	09329-14002	CUSHION	1	
43	61124-98J00	GROMMET, REMOCON CABLE	1	
44	09407-25402	CLAMP (L:250)	1	
45	67300-93J00	KIT, HOSE ADAPTER	1	OPT
46	67361-93J00	.ADAPTER, HOSE	1	OPT
47	09250-21003	.PLUG (OD:28)	1	OPT

FIG.420A



DF300A_E01_015_420A
ENGINE COVER

FIG.420A (1-F-12) ENGINE COVER (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-98Y61-OEP	COVER SET, ENGINE (BLACK)	1	
1-2	61400-98Y71-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-OEP	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.BOLT	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.BOLT	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM "S" (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J01	.BRACKET, FASTENER FRONT	1	
22	61624-98J10	.BRACKET, FASTENER PORT	1	
23	61625-98J10	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	

DF300A_E01_015

FIG.420A





FIG.420A (1-F-13) ENGINE COVER (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28-1	61443-93J32	.STRIPE, ENGINE COVER STBD	1	
28-2	61443-93J40	.STRIPE, ENGINE COVER STBD (WHITE)	1	
29-1	61453-93J32	.STRIPE, ENGINE COVER PORT	1	
29-2	61453-93J40	.STRIPE, ENGINE COVER PORT (WHITE)	1	
30-1	61446-93J32	.DECAL, EFI & VVT	1	
30-2	61446-93J40	.DECAL, EFI & VVT (WHITE)	1	
31-1	61422-98J12	MARK, EMBLEM FRONT (300)	1	
31-2	61422-98J20	MARK, EMBLEM FRONT (300) (WHITE)	1	
32-1	61435-98J12	MARK, EMBLEM REAR (300)	1	
32-2	61435-98J20	MARK, EMBLEM REAR (300) (WHITE)	1	
33	61458-99E70	LABEL, ENGINE COVER	1	
34	61471-98J00	DECAL, LEAN BURN	1	
35-1	61473-98J00	DECAL (S.S.R.)	1	
35-2	61473-98J10	DECAL (S.S.R.) (WHITE)	1	
36	09800-81834	TOOL SET	1	
37-1	61446-96J20	DECAL (S.P.C.)	1	
37-2	61446-96J30	DECAL (S.P.C.) (WHITE)	1	
38	61425-98J00	CUSHION, ENGINE COVER	1	
39-1	99011-98J40-054	MANUAL, OWNER'S	1	
39-2	99011-98J40-059	MANUAL, OWNER'S	1	
40	68110-98J00	COVER, WEATHER	1	OPT

FIG.420B



DF300A_E01_015_420B
ENGINE COVER

FIG.420B (1-F-14) ENGINE COVER (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-98Y61-OEP	COVER SET, ENGINE (BLACK)	1	
1-2	61400-98Y71-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-OEP	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.BOLT	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.BOLT	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM "S" (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J01	.BRACKET, FASTENER FRONT	1	
22	61624-98J10	.BRACKET, FASTENER PORT	1	
23	61625-98J10	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	

DF300A_E01_015

FIG.420B





FIG.420B (1-F-15) ENGINE COVER (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28-1	61443-93J32	.STRIPE, ENGINE COVER STBD	1	
28-2	61443-93J40	.STRIPE, ENGINE COVER STBD (WHITE)	1	
29-1	61453-93J32	.STRIPE, ENGINE COVER PORT	1	
29-2	61453-93J40	.STRIPE, ENGINE COVER PORT (WHITE)	1	
30-1	61446-93J32	.DECAL, EFI & VVT	1	
30-2	61446-93J40	.DECAL, EFI & VVT (WHITE)	1	
31-1	61422-98J12	MARK, EMBLEM FRONT (300)	1	
31-2	61422-98J20	MARK, EMBLEM FRONT (300) (WHITE)	1	
32-1	61435-98J12	MARK, EMBLEM REAR (300)	1	
32-2	61435-98J20	MARK, EMBLEM REAR (300) (WHITE)	1	
33	61458-99E70	LABEL, ENGINE COVER	1	
34	61471-98J00	DECAL, LEAN BURN	1	
35-1	61473-98J00	DECAL (S.S.R.)	1	
35-2	61473-98J10	DECAL (S.S.R.) (WHITE)	1	
36	09800-81834	TOOL SET	1	
37-1	61446-96J20	DECAL (S.P.C.)	1	
37-2	61446-96J30	DECAL (S.P.C.) (WHITE)	1	
38	61425-98J00	CUSHION, ENGINE COVER	1	
39	99011-98J40-059	MANUAL, OWNER'S	1	
40	68110-98J00	COVER, WEATHER	1	OPT

FIG.420C




DF300A_E01_015_420C
ENGINE COVER

FIG.420C (1-G-2) ENGINE COVER (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-98Y61-OEP	COVER SET, ENGINE (BLACK)	1	
1-2	61400-98Y71-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-OEP	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.BOLT	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.BOLT	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM "S" (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J01	.BRACKET, FASTENER FRONT	1	
22	61624-98J10	.BRACKET, FASTENER PORT	1	
23	61625-98J10	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	

DF300A_E01_015

FIG.420C




DF300A_E01_015_420C
ENGINE COVER

FIG.420C (1-G-3) ENGINE COVER (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28-1	61443-93J32	.STRIPE, ENGINE COVER STBD	1	
28-2	61443-93J40	.STRIPE, ENGINE COVER STBD (WHITE)	1	
29-1	61453-93J32	.STRIPE, ENGINE COVER PORT	1	
29-2	61453-93J40	.STRIPE, ENGINE COVER PORT (WHITE)	1	
30-1	61446-93J32	.DECAL, EFI & VVT	1	
30-2	61446-93J40	.DECAL, EFI & VVT (WHITE)	1	
31-1	61422-93J72	MARK, EMBLEM FRONT (250)	1	
31-2	61422-93J80	MARK, EMBLEM FRONT (250) (WHITE)	1	
32-1	61435-93J52	MARK, EMBLEM REAR (250)	1	
32-2	61435-93J60	MARK, EMBLEM REAR (250) (WHITE)	1	
33	61458-99E70	LABEL, ENGINE COVER	1	
34	61471-98J00	DECAL, LEAN BURN	1	
35-1	61473-98J00	DECAL (S.S.R.)	1	
35-2	61473-98J10	DECAL (S.S.R.) (WHITE)	1	
36	09800-81834	TOOL SET	1	
37-1	61446-96J20	DECAL (S.P.C.)	1	
37-2	61446-96J30	DECAL (S.P.C.) (WHITE)	1	
38	61425-98J00	CUSHION, ENGINE COVER	1	
39-1	99011-98J40-054	MANUAL, OWNER'S	1	
39-2	99011-98J40-059	MANUAL, OWNER'S	1	
40	68110-98J00	COVER, WEATHER	1	OPT

DF300A_E01_015

FIG.420D



DF300A_E01_015_420D
ENGINE COVER

FIG.420D (1-G-4) ENGINE COVER (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-98Y61-OEP	COVER SET, ENGINE (BLACK)	1	
1-2	61400-98Y71-Y5S	COVER SET, ENGINE (WHITE)	1	
2-1	61431-98J10-OEP	.COVER, TOP (BLACK)	1	
2-2	61431-98J10-Y5S	.COVER, TOP (WHITE)	1	
3	61432-98J01	.LOUVER, AIR INTAKE	1	
4	61433-98J01	.GRIP, UPPER COVER STBD	1	
5	61434-98J02	.GRIP, UPPER COVER PORT	1	
6	61439-98J00	.SEAL, GRIP STBD	1	
7	61439-98J10	.SEAL, GRIP PORT	1	
8	61439-98J21	.SEAL, AIR VENT NO.2	1	
9	61476-98J00	.SEAL, AIR VENT NO.1	1	
10	01550-06167	.BOLT	2	
11	01550-06207	.BOLT	3	
12	01550-06167	.BOLT	3	
13	03542-06169	.BOLT	5	
14	01550-06167	.BOLT	4	
15	03542-06169	.BOLT	4	
16	61610-98J00	.FASTENER (FRONT)	1	
17	61610-98J30	.FASTENER (PORT)	1	
18	61610-98J40	.FASTENER (STBD)	1	
19	77811-54GC0-0PG	.EMBLEM "S" (CHROME)	1	
20	61614-98J00	.PROTECTOR, FASTENER	1	
21	61621-98J01	.BRACKET, FASTENER FRONT	1	
22	61624-98J10	.BRACKET, FASTENER PORT	1	
23	61625-98J10	.BRACKET, FASTENER STBD	1	
24	61619-98J00	.CUSHION, ENG COV FASTENER	3	
25	01547-06167	.BOLT	6	
26	01550-06127	.BOLT	1	
27	01550-06127	.BOLT	2	

DF300A_E01_015

FIG.420D




FIG.420D (1-G-5) ENGINE COVER (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28-1	61443-93J32	.STRIPE, ENGINE COVER STBD	1	
28-2	61443-93J40	.STRIPE, ENGINE COVER STBD (WHITE)	1	
29-1	61453-93J32	.STRIPE, ENGINE COVER PORT	1	
29-2	61453-93J40	.STRIPE, ENGINE COVER PORT (WHITE)	1	
30-1	61446-93J32	.DECAL, EFI & VVT	1	
30-2	61446-93J40	.DECAL, EFI & VVT (WHITE)	1	
31-1	61422-93J72	MARK, EMBLEM FRONT (250)	1	
31-2	61422-93J80	MARK, EMBLEM FRONT (250) (WHITE)	1	
32-1	61435-93J52	MARK, EMBLEM REAR (250)	1	
32-2	61435-93J60	MARK, EMBLEM REAR (250) (WHITE)	1	
33	61458-99E70	LABEL, ENGINE COVER	1	
34	61471-98J00	DECAL, LEAN BURN	1	
35-1	61473-98J00	DECAL (S.S.R.)	1	
35-2	61473-98J10	DECAL (S.S.R.) (WHITE)	1	
36	09800-81834	TOOL SET	1	
37-1	61446-96J20	DECAL (S.P.C.)	1	
37-2	61446-96J30	DECAL (S.P.C.) (WHITE)	1	
38	61425-98J00	CUSHION, ENGINE COVER	1	
39	99011-98J40-059	MANUAL, OWNER'S	1	
40	68110-98J00	COVER, WEATHER	1	OPT

FIG.430A




FIG.430A (1-G-6) FUEL HOSE (DF300A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09251-09002	CAP (OD:13.6)	1	
2	09367-10001	JOINT	1	
3	09401-13423	CLIP	1	
4	65700-93J02	HOSE, FUEL (TANK TO ENGINE)	1	
5	65770-93J11	.PUMP, SQUEEZE	1	
6	09401-13423	CLIP	1	

FIG.430B




FIG.430B (1-G-7) FUEL HOSE (DF300A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09251-09002	CAP (OD:13.6)	1	
2	09367-10001	JOINT	1	
3	09401-13423	CLIP	1	
4	65770-93J11	PUMP, SQUEEZE	1	

FIG.430C




FIG.430C (1-G-8) FUEL HOSE (DF250A E01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09251-09002	CAP (OD:13.6)	1	
2	09367-10001	JOINT	1	
3	09401-13423	CLIP	1	
4	65700-93J02	HOSE, FUEL (TANK TO ENGINE)	1	
5	65770-93J11	.PUMP, SQUEEZE	1	
6	09401-13423	CLIP	1	

FIG.430D

FIG.430D (1-G-9) FUEL HOSE (DF250A E40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09251-09002	CAP (OD:13.6)	1	
2	09367-10001	JOINT	1	
3	09401-13423	CLIP	1	
4	65770-93J11	PUMP, SQUEEZE	1	




FIG.502A




FIG.502A (1-G-10) OPT:METER (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-98J01	KIT, SPEEDOMETER SUB	1	
2	34190-95500	.SENDER ASSY, SPEEDOMETER	1	
3	03112-06303	..SCREW	2	
4	55127-87D00	.UNION, HOSE	1	
5	09355-40805-00B	.HOSE (4X8X2000)	1	L:2000->1700
6	09407-10404	.CLAMP (L:100)	2	
7	17917-87L00	CONNECTOR, FLUSH WATER	1	
8	34011-88L03	KIT, 4 IN MULTI GAUGE	1	
9	34200-88L02	.GAUGE ASSY, 4 IN MULTI	1	
10	34922-88L02	.UNIT, INTERFACE	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36665-88L00	.UNIT, RESISTOR FEMALE	1	
13	36665-88L10	.UNIT, RESISTOR MALE	1	
14	34011-88L13	KIT, 2 IN MULTI GAUGE	1	
15	34800-88L01	.GAUGE ASSY, 2 IN MULTI	1	
16	34922-88L02	.UNIT, INTERFACE	1	
17	36662-88L00	.WIRE, 25 EXTENSION	1	
18	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
19	36665-88L00	.UNIT, RESISTOR FEMALE	1	
20	36665-88L10	.UNIT, RESISTOR MALE	1	
21	36668-88L00	.WIRE, ADAPTER TO DIAGNS	1	
22	34011-87L20	KIT, SINGLE GAUGE FOR AP MODEL	1	
23	34200-87L12	.GAUGE ASSY, MULTI	1	
24	34211-87L00	..COVER, FRONT	1	
25	36661-87L11	.ADAPTER, GAUGE	1	
26	36615-96300	..TERMINAL	5	
27	36663-98J10	.HARNESS, ACTIVE HUB PWR (6M)	1	
28	09481-05501	..FUSE (5A)	1	
29	36990-87D00	.TERMINAL/SLEEVE SET	1	
30	39950-87L00	MODULE ASSY, GPS RECIVER	1	

FIG.503A







FIG.503A (1-G-11) OPT:METER (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34011-87L30	KIT, DUAL GAUGE FOR AP MODEL	1	
2	34200-87L12	.GAUGE ASSY, MULTI	2	
3	34211-87L00	..COVER, FRONT	2	
4	36661-87L11	.ADAPTER, GAUGE	2	
5	36615-96300	..TERMINAL	10	
6	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
7	36663-98J10	.HARNESS, ACTIVE HUB PWR (6M)	1	
8	09481-05501	..FUSE (5A)	1	
9	36664-88L00	.CONNECTOR, BRANCH	3	
10	36665-87L00	ADAPTER, GAUGE FOR MULTI	1	
11	36665-88L00	.UNIT, RESISTOR FEMALE	1	
12	36665-88L10	.UNIT, RESISTOR MALE	1	
13	36666-87L00	.WIRE, NETWORK	2	
14	36990-87D00	.TERMINAL/SLEEVE SET	1	
15	39950-87L00	MODULE ASSY, GPS RECIVER	1	
16	34011-87L40	KIT, SNGL GAUGE & DUAL STATION	1	
17	34200-87L12	.GAUGE ASSY, MULTI	1	
18	34211-87L00	..COVER, FRONT	1	
19	36662-88L00	.WIRE, 25 EXTENSION	1	
20	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
21	36664-87L00	.ADAPTER, GAUGE FOR DUAL	1	
22	36664-88L00	.CONNECTOR, BRANCH	3	
23	36665-87L00	.ADAPTER, GAUGE FOR MULTI	1	
24	36665-88L00	.UNIT, RESISTOR FEMALE	1	
25	36665-88L10	.UNIT, RESISTOR MALE	1	
26	36666-87L00	.WIRE, NETWORK	2	
27	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	1	
28	34011-87L50	KIT, DUAL GAUGE & DUAL STATION	1	
29	34200-87L12	.GAUGE ASSY, MULTI	2	
30	34211-87L00	..COVER, FRONT	2	
31	36662-88L00	.WIRE, 25 EXTENSION	1	
32	36664-87L00	.ADAPTER, GAUGE FOR DUAL	2	
33	36664-88L00	.CONNECTOR, BRANCH	2	
34	36666-87L00	.WIRE, NETWORK	2	

FIG.503A








FIG.503A (1-G-12) OPT:METER (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	36682-92E00	.WIRE, TRIM METER EXT (L:6500)	2	
36	36663-98J00	WIRE, GAUGE POWER	1	
37	09481-05501	.FUSE (5A)	1	
38	36663-98J10	WIRE, GAUGE POWER	1	
39	09481-05501	.FUSE (5A)	1	

FIG.520A



DF300A_E01_015_520A
OPT:FLUSH MOUNT REMOCON

FIG.520A (1-G-13) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J22	REMOCON ASSY, FLUSH MOUNT	1	
2	67271-98J20	.COVER, BOTTON BASE	1	
3	67264-98J00	.COVER, TOP BASE	1	
4	67263-98J20	.COVER, LEVER	1	
5	67261-98J20	.GRIP, A	1	
6	67261-98J30	.GRIP, B	1	
7	67265-98J00	.BUTTON, NEUTRAL LOCK	1	
8	67255-98J00	.LINK, NEUTRAL LOCK NO.1	1	
9	67258-98J00	.PLATE, JOINT	1	
10	67256-98J00	.BLOCK, NEUTRAL LOCK	1	
11	67259-98J00	.SPRING	3	
12	67251-98J20	.LEVER, HANDLE	1	
13	67294-98J00	.SPACER	1	
14	67254-98J00	.LINK, NEUTRAL LOCK NO.2	1	
15	67233-98J00	.SLIDER, NEUTRAL BUTTON	1	
16	67296-98JA0	.SCREW (4X10)	3	
17	67234-98J00	.PLATE, LEVER	1	
18	67211-98J20	.HOUSING	1	
19	67269-98J20	.CLAMP, LEAD	1	
20	67296-98JB0	.SCREW (4X30)	1	
21	67227-98J20	.SCREW, TAPPING (4X35)	1	
22	67227-98J30	.SCREW, TAPPING (4X20)	1	
23	67288-98J50	.WASHER, PLANE	8	
24	67296-98JC0	.SCREW (6X40)	4	
25	67287-98J00	.NUT	4	
26	67226-98J10	.BOLT (6X50)	4	
27	67288-98J60	.WASHER, INNTERNAL TOOTH (M4)	3	
28	67296-98JD0	.SCREW (5X40)	1	
29	67238-98J00	.PIN	2	
30	67288-98J70	.WASHER, PLANE	5	
31	67246-98J00	.SHAFT, DRIVE REMOCON	1	
32	67222-98J00	.PANEL ASSY, BACK	1	
33	67236-98J00	.ROLLER, DETENT	1	
34	67235-98J00	.GUIDE, DETENT ROLLER	1	

DF300A_E01_015

FIG.520A




FIG.520A (1-G-14) OPT:FLUSH MOUNT REMOCON

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67237-98J00	.SPRING, DETENT	1	
36	67223-98J00	.PAD, BRAKE	1	
37	67296-98JE0	.SCREW, ADJUST (5X35)	1	
38	67252-98J00	.BUSH, DRIVE	1	
39	67288-98J20	.WASHER, PLANE	1	
40	67292-98J00	.C RING	1	
41	15980-98J00	.POTENTIOMETER	1	
42	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
43	67296-94300	.SCREW (4X10)	2	
44	67288-98J00	.WASHER, PLANE	5	
45	67296-98J10	.SCREW (5X35)	1	
46	67288-98J10	.WASHER, SPRING	8	
47	67228-98J50	.WASHER, WAVE	2	
48	67296-98J60	.SCREW (8X30)	1	
49	09160-06104	.WASHER (6.5X24X2)	4	
50	67296-98J50	.SCREW (5X18)	2	
51	67272-98J00	.GROMMET	2	
52	37850-98J02	.SWITCH ASSY, PTT	1	
53	67269-98J10	.BAND	1	
54	68165-98J00	.MARK, LEVER (SUZUKI)	1	
55	36890-98J00	.CONDENSER, ADAPTER HARNESS	1	

FIG.522A




FIG.522A (1-G-15) OPT:HARNESS (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-98J50	WIRE ASSY, REMOCON EXTENSION	1	
2	33830-98J10	SET, BATTERY ISOLATOR LEAD	1	
3	09407-10404	.CLAMP (L:100)	2	
4	09481-40401	.FUSE (40A)	1	
5	33911-88BL0	CAP, BCM CONNECTOR	1	
6	33925-93J00	CUSHION, BCM	1	
7	33926-98J00	RESISTOR, TERMINAL	2	
8	36623-98J20	HARNESS ASSY, BCM NO.1 FOR SNGL	1	
9	36615-96300	.TERMINAL RESIN	4	
10	36770-98J10	CONTROLLER ASSY, BOAT ELECTRIC	1	
11	36775-98J00	HOLDER, BCM (L)	1	
12	36776-98J00	HOLDER, BCM (R)	1	
13	36622-98J00	HARNESS ASSY, DUAL STATION MAIN	1	
14	09481-10501	.FUSE (10A)	1	
15	36624-98J02	HARNESS ASSY, BCM NO.2 FOR SNGL	1	
16	36615-96300	.TERMINAL, RESIN	2	
17	36621-98J00	HARNESS ASSY, DUAL ENGINE	1	
18	36623-98J30	HARNESS ASSY, BCM NO.1 FOR MULT	1	
19	36615-96300	.TERMINAL, RESIN	5	
20	36624-98J11	HARNESS ASSY, BCM NO.2 FOR MULT	1	
21	36615-96300	.TERMINAL, RESIN	2	
22	36621-98J10	HARNESS ASSY, TRIPLE ENGINE	1	
23	09403-13402	CLAMP (ID:13)	20	
24-1	36612-98J01	CONNECTOR, COUNTER SELECT (GREEN)	1	
24-2	36612-98J20	CONNECTOR, COUNTER SELECT (WHITE)	1	
25	36661-98J10	ADAPTER, INTERFACE SINGLE	1	
26	09481-05501	.FUSE (5A)	1	

FIG.522A




FIG.522A (1-H-2) OPT:HARNESS (1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	36661-98J20	ADAPTER, INTERFACE DUAL	1	
28	36661-98J30	ADAPTER, INTERFACE TRIPLE	1	
29	36990-87D00	TERIMINAL SET, WITH SLEEVE	1	
30	36667-87L00	ADAPTER, GAUGE FOR MULTI	1	
31	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	

FIG.523A





FIG.523A (1-H-3) OPT:HARNESS (2)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33925-93J00	CUSHION, ENGINE CONTROL UNIT	2	
2	33926-98J00	RESISTOR, TERMINAL	4	
3	36621-98J00	HARNESS ASSY, DUAL ENGINE	2	
4	36615-96300	TERMINAL	8	
5	36625-98J10	WIRE ASSY, BATTERY	2	
6	09481-30501	.FUSE (30A)	2	
7	36770-98J20	CONTROLLER ASSY, BOAT ELECTRIC	2	
8	36775-98J00	HOLDER, BCM, LH	2	
9	36776-98J00	HOLDER, BCM, RH	2	
10	37100-98J21	PANEL ASSY, DUAL	2	
11	37112-98J10	.NUT	2	
12	38500-93J90	BUZZER, WARNING	2	
13	33925-93J00	CUSHION, ENGINE CONTROL UNIT	2	
14	36622-98J00	HARNESS ASSY, DUAL STATION MAIN	2	
15	09481-10501	.FUSE (10A)	2	
16	36623-98J40	HARNESS ASSY, BCM QUADRUPLE	1	
17	36770-98J20	CONTROLLER ASSY, BOAT ELECTRIC	2	
18	36775-98J00	HOLDER, BCM, LH	2	
19	36776-98J00	HOLDER, BCM, RH	2	
20	37100-98J21	PANEL ASSY, DUAL	2	
21	37112-98J10	.NUT	2	
22	38500-93J90	BUZZER, WARNING	2	

FIG.530A



DF300A_E01_015_530A
OPT:SWITCH

FIG.530A (1-H-4) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-98J04	PANEL ASSY, MAIN SW	1	
2	37110-98J01	.SWITCH ASSY, MAIN	1	
3-1	37141-99EA0	..KEY (941)	1	
3-2	37141-99EB0	..KEY (942)	1	
3-3	37141-99E00	..KEY (931)	1	
3-4	37141-99E10	..KEY (932)	1	
3-5	37141-99E20	..KEY (933)	1	
3-6	37141-99E30	..KEY (934)	1	
3-7	37141-99E40	..KEY (935)	1	
3-8	37141-99E50	..KEY (936)	1	
3-9	37141-99E60	..KEY (937)	1	
3-10	37141-99E70	..KEY (938)	1	
3-11	37141-99E80	..KEY (939)	1	
3-12	37141-99E90	..KEY (940)	1	
4	37143-99E00	..CAP, KEY	1	
5	37139-98J00	.PANEL, MAIN SW	1	
6	37820-93J04	.SWITCH ASSY, EMERGENCY STOP	1	
7	37823-92E01	..PLATE ASSY, EMERGENCY SW LOCK	1	
8	37826-92J00	..NUT	1	
9	03122-05165	.SCREW	4	
10	37114-98J00	.SHEET, MAIN SW PANEL	1	
11	37100-98J11	PANEL ASSY, SINGLE	1	
12	37112-98J00	.NUT	1	
13	38500-93J90	BUZZER ASSY, WARNING	1	
14	09407-08401	CLAMP (L:80)	2	
15	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
16	37825-99E00	.PANEL, EMERGENCY STOP SW	1	
17	37100-98J21	PANEL ASSY, DUAL	1	
18	37112-98J10	.NUT	1	
19	37100-98J31	PANEL ASSY, TRIPLE	1	
20	37112-98J10	.NUT	1	

DF300A_E01_015

FIG.530A





FIG.530A (1-H-5) OPT:SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	37860-87L00	PANEL ASSY, TROLLING CTR SW	1	
22	37862-87L00	.PANEL	1	
23	09131-05004	.SCREW (5X16)	4	

FIG.540A




DF300A_E01_015_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A (1-H-6) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J13	REMOTE CONTROL ASSY	1	
2	67211-98J20	.HOUSING (L)	1	
3	67251-98J00	.LEVER, HANDLE	2	
4	67246-98J10	.SHAFT, DRIVE (L)	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67261-98J10	.GRIP, NO.2	1	
7	67263-98J00	.COVER, LEVER	2	
8	67212-98J30	.COVER, UPPER	1	
9	67271-98J40	.COVER, BOTTOM	1	
10	67222-98J10	.PANEL ASSY, BACK (L)	1	
11	67236-98J10	.ROOLER, DETENT	2	
12	67235-98J10	.GUIDE, DETENT ROOLER	2	
13	67237-98J40	.SPRING, DETENT	2	
14	67233-98J10	.HOLDER, DETENT SPRING	2	
15	67287-92E00	.NUT (M5)	2	
16	67239-98J00	.SCREW, DETENT ADJUST (5X14)	2	
17	67223-98J00	.PAD, BRAKE	2	
18	67296-98J50	.SCREW (5X18)	8	
19	67296-98JA0	.SCREW, BRAKE ADJUST (5X30)	2	
20	67272-98J10	.GROMMET, COVER	2	
21	67252-98J10	.BUSH, DRIVE SHAFT	2	
22	67288-98J20	.WASHER	2	
23	67292-98J00	.C-RING	2	
24	15980-98J00	.POTENTIOMETER	2	
25	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
26	37850-98J02	.SWITCH ASSY, PTT	1	
27	67269-98J00	.CLAMP, LEAD	1	
28	67273-98J20	.PACKING	1	
29	67296-98J60	.SCREW (8X30)	2	
30	67296-98J30	.SCREW (5X65)	4	
31	67296-98J80	.SCREW (5X14)	2	
32	67296-98J00	.SCREW (5X12)	1	
33	67296-94300	.SCREW (4X10)	4	
34	67288-98J40	.WASHER	14	

DF300A_E01_015

FIG.540A



DF300A_E01_015_540A
OPT:REMOTE CONTROL ASSY DUAL

FIG.540A (1-H-7) OPT:REMOTE CONTROL ASSY DUAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67288-98J00	.WASHER	4	
36	67288-92E20	.WASHER	2	
37	67226-98J00	.BOLT (5X50)	4	
38	09160-05024	.WASHER (5.5X16X1.5)	4	
39	67287-92E00	.NUT	4	
40	67296-98J90	.SCREW	2	
41	67227-98J00	.LEVER, POTENTIOMETER NO.1	1	
42	67284-98J00	.MARK (F-N-R)	1	
43	68165-98J00	.MARK, LEVER (SUZUKI)	2	
44	68165-98J10	.EMBLEM (SUZUKI)	1	
45	67269-98J30	.BAND	1	
46	67288-98J10	.WASHER, SPRING	16	
47	67288-98J30	.WASHER	2	
48	67228-98J50	.WASHER, WAVE	2	
49	67211-98J30	.HOUSING (R)	1	
50	67222-98J20	.PANEL ASSY, BACK (R)	1	
51	67246-98J20	.SHAFT, DRIVE (R)	1	
52	67273-98J10	.PACKING (FRONT)	1	
53	67273-98J30	.PACKING (REAR)	1	
54	67277-98J00	.GROMMET	1	
55	67296-98JF0	.BOLT (5X14)	1	
56	67297-98J00	.NUT	1	
57	67237-98J50	.SPRING, DETENT	2	
58	36890-98J00	.CONDENSER, ADAPTER HARNESS	1	
59-1	36620-98J30	WIRE ASSY, REMOTE CONTROL	1	L:6500
59-2	36620-98J40	WIRE ASSY, REMOTE CONTROL	1	L:9500

DF300A_E01_015

FIG.543A




FIG.543A (1-H-8) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-98J03	REMOTE CONTROL ASSY	1	
2	67211-98J20	.HOUSING	1	
3	67251-98J00	.LEVER, HANDLE	1	
4	67246-98J10	.SHAFT, DRIVE	1	
5	67261-98J00	.GRIP, NO.1	1	
6	67263-98J00	.COVER, LEVER	1	
7	67212-98J20	.COVER, UPPER	1	
8	67271-98J30	.COVER, BOTTOM	1	
9	67222-98J10	.PANEL ASSY, BACK	1	
10	67236-98J00	.ROLLER, DETENT	1	
11	67235-98J10	.GUIDE, DETENT ROLLER	1	
12	67237-98J30	.SPRING, DETENT	1	
13	67233-98J10	.HOLDER, DETENT SPRING	1	
14	67287-92E00	.NUT	1	
15	67239-98J00	.SCREW, DETENT ADJUST (5X14)	1	
16	67223-98J00	.PAD, BRAKE	1	
17	67296-98J50	.SCREW (5X18)	6	
18	67296-98JA0	.SCREW, BRAKE ADJUST (5X30)	1	
19	67272-98J10	.GROMMET, COVER	1	
20	67252-98J10	.BUSH, DRIVE SHAFT	1	
21	67288-98J20	.WASHER	1	
22	67292-98J00	.C-RING	1	
23	15980-98J00	.POTENTIOMETER	1	
24	67227-98J10	.LEVER, POTENTIOMETER NO.2	1	
25	37850-98J02	.SWITCH ASSY, PTT	1	
26	67269-98J00	.CLAMP, LEAD	1	
27	67273-98J00	.PACKING	1	
28	67296-98J60	.SCREW (8X30)	1	
29	67274-98J00	.FLANGE, BASE	1	
30	67288-92E20	.WASHER	1	
31	67296-98J90	.SCREW	1	
32	67296-98J80	.SCREW (5X14)	1	
33	67296-94300	.SCREW (4X10)	2	
34	67288-98J00	.WASHER	2	

FIG.543A




FIG.543A (1-H-9) OPT:REMOTE CONTROL ASSY SINGLE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67296-98J20	.SCREW (5X50)	2	
36	67226-98J00	.BOLT (5X50)	4	
37	09160-05024	.WASHER (5.5X16X1.5)	4	
38	67287-92E00	.NUT	4	
39	67296-98J00	.SCREW (5X12)	1	
40	67288-98J40	.WASHER	12	
41	67296-98J10	.SCREW (5X35)	1	
42	67284-98J00	.MARK (F-N-R)	1	
43	68165-98J00	.MARK, LEVER (SUZUKI)	1	
44	68165-98J10	.EMBLEM (SUZUKI)	1	
45	67269-98J30	.BAND	1	
46	67288-98J10	.WASHER, SPRING	8	
47	67288-98J30	.WASHER	1	
48	67228-98J50	.WASHER, WAVE	1	
49	67273-98J10	.PACKING (FRONT)	1	
50	67273-98J30	.PACKING (REAR)	1	
51	67277-98J00	.GROMMET	1	
52	67296-98JF0	.BOLT (5X14)	1	
53	67297-98J00	.NUT	1	
54	36890-98J00	.CONDENSER, ADAPTER HARNESS	1	
55-1	36620-98J30	WIRE ASSY, REMOTE CONTROL	1	L:6500
55-2	36620-98J40	WIRE ASSY, REMOTE CONTROL	1	L:9500

FIG.585A




FIG.585A (1-H-10) OPT:GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11410-98830	GASKET SET	1	
2	11141-98J10	.GASKET, CYL HEAD STBD	1	
3	11142-98J10	.GASKET, CYL HEAD PORT	1	
4	11179-93J00	.GASKET, CYL HEAD COVER STBD	1	
5	11189-93J00	.GASKET, CYL HEAD COVER PORT	1	
6	11332-93J00	.GASKET, CRANKCASE WTR JKT COV	1	
7	13119-98J00	.GASKET, INTAKE MANIFOLD	2	
8	14151-93J00	.GASKET, EXH COVER STBD	1	
9	14152-93J00	.GASKET, EXH COVER PORT	1	
10	17472-98J00	.GASKET, PUMP CASE PANEL	1	
11	11272-93J00	.GASKET, CYL BLOCK PLATE	1	
12	11489-93J00	.GASKET, OIL PAN	1	
13	14212-93J00	.GASKET, EXHAUST TUBE	1	
14	51123-93J00	.GASKET, MOUNT OIL SEAL COVER	1	
15	51142-93J00	.GASKET, ENGINE HOLDER COVER	1	
16	51211-93J00	.GASKET, ENGINE HOLDER	1	

FIG.588A




FIG.588A (1-H-11) OPT:LOWRANCE GAUGE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34190-88L00	SENSOR ASSY,PAD WHEEL	1	
2	34193-88L00	BEZEL, 4 IN CHR	1	
3	34193-88L20	BEZEL, 4 IN WHITE	1	
4	34193-88L40	BEZEL, 2 IN CHR	1	
5	34193-88L60	BEZEL, 2 IN WHITE	1	
6	34455-88L00	SENSOR ASSY, WATER TEMP	1	
7	34455-88L10	SENSOR ASSY, WATER TEMP	1	
8	34810-88L00	SENSOR ASSY, FLUID LEVEL	1	
9	34960-88L00	SENSOR ASSY, WATER PRESSURE	1	
10	36662-88L10	WIRE, 2 EXTENSION	1	
11	36662-88L20	WIRE, 6 EXTENSION	1	
12	36662-88L30	WIRE, 15 EXTENSION	1	
13	36663-88L10	HARNESS ASSY, NETWORK POWER	1	
14	36666-88L00	WIRE, ADAPTER TO N NETWORK	1	
15	36666-88L10	WIRE, ADAPTER TO L NETWORK	1	
16	39950-88L00	MODULE ASSY, GPS RECEIVER	1	
17	36664-88L00	CONNECTOR, BRANCH	1	

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		11291-98J00	111A-37	12340-98J00-0A0	116A-8-1
		11293-98J00	113A-1	12340-98J00-0B0	116A-8-2
		11301-98J30	113A-3	12340-98J00-0C0	116A-8-3
		11330-93J01	113A-22	12340-98J00-0D0	116A-8-4
		11332-93J00	113A-23	12340-98J00-0E0	116A-8-5
11101-98J03	111A-1	585A-6	12632-93J11	175A-1	
11103-98J03	111A-5	11382-93J00	111A-31	12701-98J10	121A-1
11112-93J00	113A-4	11390-98J00	113A-19	12705-98J10	121A-2
11115-93J10-001	111A-36	11410-98830	585A-1	12721-98J10	121A-3
11116-93J01	111A-9	11435-93J00	180A-14	12729-98J20	121A-4
11117-93J10	113A-5	11489-93J00	180A-6	12730-98J01	119A-1
11117-98J10	113A-6	585A-12	12734-93J00	119A-5	
11119-93J00	113A-7	11501-93J02-0EP	180A-7-1	12740-93J00	121A-5
11128-90J00	111A-2	11501-93J02-Y5S	180A-7-2	12748-93J00	121A-6
	111A-6	11510-98J02	136A-1	12749-93J00	121A-8
11141-98J10	111A-10	136B-1	12753-93J00	121A-7	
	585A-2	136C-1	12761-93J00	119A-8	
11142-98J10	111A-11	136D-1	12762-93J00	119A-9	
	585A-3	11514-98J00	136A-4	12770-93J00	119A-10
11170-93J01	111A-21	136B-4	12771-93J00	119A-14	
11173-93J00	111A-23	136C-4	12772-93J00	119A-16	
11174-98J00	136A-2	136D-4	12775-93J00	119A-15	
	136B-2	11515-93J00	136A-11	12778-93J00	119A-11
	136C-2		136B-11	12810-93J00	119A-18
	136D-2		136C-11	12812-90J00	119A-20
11176-98J00	136A-3		136D-11	12813-73G00	119A-19
	136B-3	11517-98J00	136A-10	12831-93J01	119A-22
	136C-3		136B-10	12832-93J00	119A-23
	136D-3		136C-10	12833-93J00	119A-24
11179-93J00	111A-25		136D-10	12891-93J00	121A-14
	585A-4	11541-93J00-0EP	180A-9-1	12892-93J00-218	121A-15-1
11180-98J01	111A-22	11541-93J00-Y5S	180A-9-2	12892-93J00-220	121A-15-2
11183-93J00	111A-24	11591-93J10	180A-8	12892-93J00-223	121A-15-3
11189-93J00	111A-26	12100-98810-025	116A-6-2	12892-93J00-225	121A-15-4
	585A-5	12100-98810-0A0	116A-6-1	12892-93J00-228	121A-15-5
11193-98J00	163A-1	12100-98J00-050	116A-14	12892-93J00-230	121A-15-6
11196-93J00	162A-1	12111-98J00-0B0	116A-1	12892-93J00-233	121A-15-7
11197-93J00	162A-2	12140-98J00	116A-2	12892-93J00-235	121A-15-8
11198-58B00	163A-2	12140-98J00-050	116A-15	12892-93J00-238	121A-15-9
11217-85FA0	113A-8	12151-02F00	116A-3	12892-93J00-240	121A-15-10
11218-98J01	315A-20	12160-98J00	116A-5	12892-93J00-243	121A-15-11
11219-98J00	315A-21	12220-98J00	116A-7	12892-93J00-245	121A-15-12
11261-93J00	111A-13	12242-98J00	116A-10	12892-93J00-248	121A-15-13
	140A-5	12300-98810-0AA	116A-8-6	12892-93J00-250	121A-15-14
11261-93J10-0EP	180A-1-1	12300-98810-0BA	116A-8-7	12892-93J00-253	121A-15-15
11261-93J10-Y5S	180A-1-2	12300-98810-0CA	116A-8-8	12892-93J00-255	121A-15-16
11270-93J00	162A-3	12300-98810-0DA	116A-8-9	12892-93J00-258	121A-15-17
11272-93J00	162A-4	12300-98810-0EA	116A-8-10	12892-93J00-260	121A-15-18
	585A-11	12300-98821	116A-9-1	12892-93J00-263	121A-15-19
11291-93J00	111A-34	12300-98821-012	116A-9-2	12892-93J00-265	121A-15-20

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
12892-93J00-268	121A-15-21	13710-98J00	136A-5		147D-6
12892-93J00-270	121A-15-22		136B-5	15415-93J10	147A-4
12892-93J00-273	121A-15-23		136C-5		147B-4
12892-93J00-275	121A-15-24		136D-5		147C-4
12892-93J00-278	121A-15-25	13811-98J00	136A-6		147D-4
12892-93J00-280	121A-15-26		136B-6	15440-93J00	147A-11
12892-93J00-283	121A-15-27		136C-6		147C-11
12892-93J00-285	121A-15-28		136D-6	15440-93J10	147B-11
12892-93J00-288	121A-15-29	13813-98J00	163A-21		147D-11
12892-93J00-290	121A-15-30	13841-98J10	136A-12	15600-98J00	147A-20
12892-93J00-293	121A-15-31		136B-12		147C-20
12892-93J00-295	121A-15-32		136C-12	15600-98J10	147B-20
12892-93J00-298	121A-15-33		136D-12		147D-20
12892-93J00-300	121A-15-34	13851-98J10	136A-13	15626-93J00	147A-22
12911-98J00	121A-16		136B-13		147C-22
12915-93J50	121A-17		136C-13	15626-93J10	147B-22
12921-93J10	121A-18		136D-13		147D-22
12931-78G00	121A-19	14140-98J01	140A-2	15627-93J00	147A-33
12932-24400	121A-20	14141-93J01	140A-1		147B-33
12933-69G10	121A-21	14151-93J00	140A-3		147C-33
13100-98J01	163A-3		585A-8		147D-33
13110-98J10	122A-1	14152-93J00	140A-4	15628-99E00	147A-32
13119-98J00	122A-2		585A-9		147B-32
	585A-7	14154-93J01	180A-10		147C-32
13134-98J00	163A-15	14211-98J00	180A-11		147D-32
13137-98J00	163A-4	14212-93J00	180A-12	15629-99E10	147A-54
13139-98J00	163A-16		585A-13		147B-54
13140-98J01	163A-5	15100-94900	147A-1		147C-54
13147-98J00	163A-7		147B-1		147D-54
13180-98J00	163A-8		147C-1	15631-99E10	147B-30
13310-98J00	163A-17		147D-1		147D-30
13315-98J00	163A-19	15200-98J00	147A-24	15632-93J20	147A-44
13343-98J10	163A-18		147C-24		147B-44
13370-93J00	147A-21	15200-98J10	147B-24		147C-44
	147B-21		147D-24		147D-44
	147C-21	15410-93J10	147A-2	15633-93J20	147A-8
	147D-21		147B-2		147B-8
13421-98J00	163A-20		147C-2		147C-8
13575-40F00	326A-2		147D-2		147D-8
	326B-2	15411-93J10	147A-3	15634-93J20	147A-49
	326C-2		147B-3		147B-49
	326D-2		147C-3		147C-49
13580-98J02	326A-1		147D-3		147D-49
	326B-1	15412-93J10	147A-5	15635-93J20	147A-43
	326C-1		147B-5		147B-43
	326D-1		147C-5		147C-43
13614-93J00	147B-29		147D-5		147D-43
	147D-29	15413-93J10	147A-6	15636-98J20	147A-38
13650-52G00	315A-1		147B-6		147B-38
13655-87J00	315A-2		147C-6		147C-38

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15637-93J20	147D-38	15674-93J00	147B-45	15756-93J01	144D-5
	147A-53		147C-45		144A-6
	147B-53		147D-45		144B-6
	147C-53		147A-51		144C-6
15641-90J00	147D-53	15675-93J00	147B-51	15760-93J00	144D-6
	147A-26		147C-51		147A-31
	147C-26		147D-51		147B-31
	147B-26		147A-35		147C-31
15641-90J10	147D-26		147B-35		147D-31
	147A-27	15680-93J21	147C-35	15762-93J00	147B-17
	147B-27		147D-35		147D-17
	147C-27		144A-19		144A-7
15643-93J00	147D-27		144B-19	15762-93J10	144C-7
	147A-47		144C-19		144B-7
	147B-47	15681-93J01	144D-19		144D-7
	147C-47		144A-1	15770-93J00	147A-16
15644-93J00	147D-47		144B-1		147B-16
	147A-7		144C-1		147C-16
	147B-7		144D-1		147D-16
	147C-7	15683-87J00	147A-55	15773-90J00	147A-13
15645-93J00	147D-7		147B-55		147B-13
	147A-52		147C-55		147C-13
	147C-52		147D-55		147D-13
15645-93J10	147B-52	15684-98J00	144A-22	15830-77EA0	144A-8
	147D-52		144B-22		144C-8
	147A-9		144C-22		147B-19
	147B-9		144D-22		147D-19
15646-93J00	147C-9	15685-93J00	147A-40	15830-93J00	147A-14
	147D-9		147B-40		147B-14
	147A-25		147C-40		147C-14
	147C-25		147D-40		147D-14
15647-93J10	147B-25	15686-93J00	147A-39	15831-93J00	144A-9
	147D-25		147B-39		144B-9
	147A-23		147C-39		144C-9
	147B-23		147D-39		144D-9
15650-93J00	147C-23	15710-96J00	144A-2	15832-93J00	144B-8
	147D-23		144B-2		144D-8
	147A-28		144C-2	15980-98J00	520A-41
	147B-28		144D-2		540A-24
15654-99E00	147C-28	15717-16G00	144A-3		543A-23
	147D-28		144B-3		175A-2
	147A-62		144C-3	16113-93J10	175A-3
	147B-62		144D-3		16430-93J00
15671-93J00	147C-62	15735-58B00	144A-4		113A-25
	147D-62		144B-4		16431-93J00
	147A-41		144C-4		113A-26
	147B-41		144D-4		113A-27
15672-93J00	147C-41	15751-93J00	144A-5	16510-96J00	113A-30
	147D-41		144B-5		16519-93J00
	147A-45		144C-5		401A-2
					16520-93J00
15673-98J00				16550-93J00	175A-4
					121A-11
					121A-12

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
16700-93J00	113A-14	17473-98J00	160D-24	17670-90J20	162A-9-1
	16760-93J00		585A-10		162A-10
	16781-93J00		160A-7		17711-90J00
	16782-93J00		160A-25		162A-11
16783-93J01	175A-7	17611-90J00-0EP	160A-25	17712-93J00	162A-12
	175A-8		160B-7		17713-98J00
	16910-93J00		160B-25		162A-36
	16930-93J00		160C-7	17913-93J00	401A-3
17400-98J01	160A-20	17561-93J03	160C-25		410A-23
	160B-20		160D-7		401A-4
	160C-20		160D-25		410A-24
	160D-20		160A-8-1	17915-98J01	162A-38
17410-93J01	160A-1	17561-93J13	160B-8-1		502A-7
	160B-1		160C-8-1		18118-93J00
	160C-1		160D-8-1		163A-23
	160D-1		160A-8-2	18213-98J10	315A-18
17413-93J02	160A-2	17562-93J00	160B-8-2		18417-93J00
	160C-2		160C-8-2		147B-66
	160B-2		160D-8-2		147C-66
	160D-2		160A-9	18498-93J00	147D-66
17416-93J00	160A-3	17563-93J00	160B-9		144A-10
	160A-21		160C-9		144B-10
	160B-3		160D-9		144C-10
	160B-21		160A-10	18498-93J10	144D-10
17461-93J00	160C-3	17564-93J00	160B-10		147A-58
	160C-21		160C-10		147B-58
	160D-3		160D-10		147C-58
	160D-21		160A-11		147D-58
17461-93J00	160A-4	17581-93J00	160B-11	18590-68H00	163A-9
	160A-22		160C-11		19115-98J10
	160B-4		160D-11		204A-29
	160B-22		162A-5	20000	
17471-98J01	160C-4	17582-93J00	162A-6		
	160C-22		162A-7-1		
	160D-4		162A-7-2		
	160D-22		162A-12		
17471-98J01	160A-5	17612-93J00	160A-12	21110-98J00	204A-1
	160A-23		160B-12		21131-93J00
	160C-5		160C-12		204A-2
	160C-23		160D-12	21151-93J00	204A-3
17471-98J11	160B-5	17631-93L00	160A-13		21210-98J01
	160B-23		160B-13		204A-5
	160D-5		160C-13		21230-98J01
	160D-23		160D-13	21241-98J10	204A-6
17472-98J00	160A-6	17632-93L00	160A-14		204A-24
	160A-24		160B-14		22511-99011
	160B-6		160C-14		336A-1
	160B-24		160D-14	23111-93J00	204A-7
17637-93L00	160C-6	17638-93L00	206A-16		204A-8
	160C-24		206A-17		25112-93L00
	160D-6		162A-8		206A-1-1
			162A-9-2	25112-93L00	206A-1-2
17670-90J10		17660-99E01			206A-11
					25130-93L00
					206A-2
					25141-93L00-0EP
		17670-90J10		25141-93L00-Y5S	206A-5-1
					206A-5-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
25215-93L00	206A-12	31173-94910	340A-8	34190-95500	502A-2	36622-98J00	522A-13	36666-88L10	588A-15	37141-99E60	530A-3-9
25222-90J00	206A-6	31191-96J00	301A-9	34193-88L00	588A-2		523A-14	36667-87L00	522A-30	37141-99E70	530A-3-10
25223-94400	204A-9	31220-94J00	301A-10	34193-88L20	588A-3	36623-98J20	522A-8	36668-88L00	502A-21	37141-99E80	530A-3-11
25232-90J00	206A-3	31281-92J10	340A-11	34193-88L40	588A-4	36623-98J30	522A-18	36682-92E00	503A-27	37141-99E90	530A-3-12
25321-93L00	206A-8	31310-90J00	301A-11	34193-88L60	588A-5	36623-98J40	523A-16		503A-35	37141-99EA0	530A-3-1
25700-93L00	407A-39	31311-93J00	340A-9	34200-87L12	502A-23	36624-98J02	522A-15		522A-31	37141-99EB0	530A-3-2
29103-93J00	180A-23	31320-93J00	301A-12		503A-2	36624-98J11	522A-20	36721-96J00	322A-6	37143-99E00	530A-4
	315A-3	31341-93J00	301A-13		503A-17	36625-98J10	322A-29	36737-96J00	322A-7		326A-7
	405A-25	31343-90J00	301A-14		503A-29		523A-5	36738-98J00	322A-8		326B-7
29103-93J20	410A-35	31344-90J00	301A-15	34200-88L02	502A-9		301A-22	36770-98J10	522A-10		326C-7
29103-93J30	180A-3	31360-93J01	301A-16	34211-87L00	502A-24	36661-87L11	502A-25	36770-98J20	523A-7		326D-7
	410A-36	31912-98J00	301A-20		503A-3		503A-4		523A-17	37722-93J11	326A-16
29116-93J00	160A-15	31913-93J00	301A-17		503A-18	36661-98J10	522A-25	36775-98J00	522A-11		326B-16
	160B-15	31914-93J00	301A-18		503A-30	36661-98J20	522A-27		523A-8		326C-16
	160C-15	31918-90J10	301A-21	34455-88L00	588A-6	36661-98J30	522A-28		523A-18		326D-16
	160D-15	32102-98J01	303A-1	34455-88L10	588A-7	36662-88L00	502A-17	36776-98J00	522A-12	37725-93J11	326A-10
	180A-13	32120-93J00	303A-4	34800-88L01	502A-15		503A-19		523A-9		326B-10
29125-93J00	206A-9	32131-93J00	303A-5	34810-88L00	588A-8		503A-31		523A-19		326C-10
	326A-18	32160-88L00	303A-7	34830-87J20	315A-4	36662-88L10	588A-10	36890-98J00	520A-55		326D-10
	326B-18	32800-98J01	310A-1		315A-5	36662-88L20	588A-11		540A-58	37729-98J00	326A-3
	326C-18	32805-93J00	310A-2	34830-98J00	315A-22	36662-88L30	588A-12		543A-54		326B-3
	326D-18	32890-98J01	310A-3	34840-98J03	315A-6	36663-88L00	502A-11	36894-87D00	335A-23		326C-3
29141-93J20	337A-25	33220-69J00	303A-9	34841-88L00	315A-12		502A-18		336A-2		326D-3
	407A-10	33221-42F00	303A-10	34845-88L01	315A-13		503A-6		337A-31	37803-93J04	530A-15
29404-93J10	180A-24	33410-93J00	310A-11	34922-88L02	502A-10		503A-20		405A-11	37820-93J04	530A-6
	315A-10	33799-97E00	340A-10		502A-16	36663-88L10	588A-13	36895-87D01	337A-32	37820-98J00	315A-7
	405A-24	33810-93J01	322A-1	34960-88L00	588A-9	36663-98J00	503A-36		337A-33	37823-92E01	530A-7
	407A-36	33830-98J10	522A-2	36610-98J50	322A-3	36663-98J10	502A-27	36990-87D00	502A-29	37825-99E00	530A-16
		33911-88BL0	522A-5	36612-98J01	522A-24-1		503A-7		503A-14	37826-92J00	530A-8
		33920-98JE0	326A-23	36612-98J10	322A-5		503A-38		522A-29	37850-92J00	326A-11
			326B-23	36612-98J20	522A-24-2	36664-87L00	503A-21	37100-98J04	530A-1		326B-11
		33920-98JF0	326C-23	36615-96300	502A-26		503A-32	37100-98J11	530A-11		326C-11
			326D-23		503A-5	36664-88L00	503A-9	37100-98J21	523A-10		326D-11
		33925-93J00	522A-6		522A-9		503A-22		523A-20	37850-98J02	520A-52
			523A-1		522A-16		503A-33		530A-17		540A-26
31100-96J02	301A-1		523A-13		522A-19		588A-17	37100-98J31	530A-19		543A-25
31111-94900	340A-2	33925-98J00	326A-24		522A-21	36665-87L00	503A-10	37110-98J01	530A-2	37856-92J00	326A-12
31123-94910	340A-3		326B-24		523A-4		503A-23	37112-98J00	530A-12		326B-12
31131-90J01	301A-2		326C-24	36617-93J00	322A-18	36665-88L00	502A-12	37112-98J10	523A-11		326C-12
31133-90J00	340A-4		326D-24	36617-93J10	162A-41		502A-19		523A-21		326D-12
31133-94900	340A-5	33926-98J00	522A-7		322A-19		503A-11		530A-18	37857-92J00	326A-13
31135-90J00	301A-3		523A-2	36617-98J00	322A-20		503A-24		530A-20		326B-13
31135-94900	340A-6	34011-87L20	502A-22	36620-98J30	540A-59-1	36665-88L10	502A-13	37114-98J00	530A-10		326C-13
31136-90J10	340A-7	34011-87L30	503A-1		543A-55-1		502A-20	37139-98J00	530A-5		326D-13
31151-94J01	301A-4	34011-87L40	503A-16	36620-98J40	540A-59-2		503A-12	37141-99E00	530A-3-3	37860-87L00	530A-21
31152-90J00	301A-5	34011-87L50	503A-28		543A-55-2		503A-25	37141-99E10	530A-3-4	37862-87L00	530A-22
31153-90J00	301A-6	34011-88L03	502A-8	36620-98J50	522A-1		503A-13	37141-99E20	530A-3-5	38100-93J03	340A-1
31170-90J00	301A-19	34011-88L13	502A-14	36621-98J00	522A-17		503A-26	37141-99E30	530A-3-6	38410-93J12	326A-19
31171-96J00	301A-7	34120-98J01	502A-1		523A-3		503A-34	37141-99E40	530A-3-7		326B-19
31173-90J02	301A-8	34190-88L00	588A-1	36621-98J10	522A-22	36666-88L00	588A-14	37141-99E50	530A-3-8		326C-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
38415-93J00	326D-19	41122-93J01	335A-4	50000	
	326A-20	41130-93J12	335A-6		
	326B-20	41135-93J11	335A-7		
	326C-20	41155-93J02	335A-13		
38500-93J90	326D-20	41220-93J11	336A-13		
	523A-12	41224-95E01	336A-15	51111-93J20-0EP	401A-1-1
	523A-22	41230-96J00	336A-16	51111-93J20-Y5S	401A-1-2
	530A-13	41233-95E10	336A-17	51116-93J00	401A-5
38860-76F01	322A-10	41234-93J11	336A-14	51122-93J02	401A-10
	322A-11	43111-93J23-0EP	336A-3-1	51123-93J00	401A-13
	326A-30	43111-93J23-Y5S	336A-3-2	585A-14	
	326A-31	43114-93J00	336A-4	51124-93J01	401A-11
	326B-30	43211-93J00	336A-5	51125-93J00	401A-12
	326B-31	43711-97E01	336A-6	51140-98J00-0EP	401A-17-1
	326C-30	43750-93J20-0EP	336A-7-1	51140-98J00-Y5S	401A-17-2
	326C-31	43750-93J20-Y5S	336A-7-2	51142-93J00	401A-18
38890-98J10	326D-30	45421-87D02	335A-16	585A-15	
	326D-31	48121-93J13	337A-17	51151-93J00	401A-20
	326A-25	48125-93J00	337A-18	51152-93J00	401A-21
	326B-25	48126-93J00	337A-19	51211-93J00	401A-6
	326C-25	48128-93J11	337A-22	585A-16	
	326D-25	48140-93J01	335A-18	52111-98J00-0EP	405A-1-1
	326A-26	48144-93J00	335A-19	52111-98J00-Y5S	405A-1-2
	326B-26	48145-93J00	335A-22	52131-93J00-0EP	405A-7-1
38892-98J00	326C-26	48311-96J10	337A-23	52131-93J00-Y5S	405A-7-2
	326D-26	48320-93J00	337A-20	54121-98J00	401A-32
	326A-27	48321-93J00	337A-24	54123-93J02	401A-24
	326B-27	48400-98J02	337A-8	54130-93J01	401A-25
38895-98J00	326C-27	48405-93J00	337A-9	54137-93J02	401A-29
	326D-27	48500-98J03	337A-1	54140-98J00	401A-33
	326A-32	48571-93J00	337A-30	54150-98J00	405A-13
	326B-32	48572-87J10	337A-12	54160-98J00	405A-14
38915-90J00	326C-32	48573-93J00	337A-21	54165-98J00	405A-22
	326D-32	48582-95E01	337A-2	54211-93J00-0EP	405A-19-1
	502A-30	48583-95E00	337A-16	54211-93J00-Y5S	405A-19-2
	503A-15	48585-95E00	337A-13	54221-93J00-0EP	405A-20-1
39950-87L00	588A-16		340A-12	54221-93J00-Y5S	405A-20-2
		48605-93J00	337A-3	55110-93L00-0EP	407A-1-1
		48610-93J01	337A-4	55110-93L00-Y5S	407A-1-2
		48627-93J00	337A-11	55118-93L00	407A-2
		48630-98J01	337A-5	55122-93L00	206A-14
		48633-93J00	337A-6	55125-93L00-0EP	407A-13-1
		48650-93J00	337A-10	55125-93L00-Y5S	407A-13-2
		48691-93J00	337A-7	55127-87D00	407A-21
40000		48862-87J20	337A-14	502A-4	
		48864-93J01	337A-15	55128-93J10	407A-15
	41111-93J14-0EP	335A-1-1		55128-93L00	407A-35
	41111-93J14-Y5S	335A-1-2		55320-94900	335A-14
	41117-93J01	335A-3		55321-87J00	111A-15
	41121-93J06-0EP	335A-2-1			140A-6
	41121-93J06-Y5S	335A-2-2			

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
55321-87J10	180A-2-1	58200-93LF0	407A-26-21		420D-31-2
	206A-18	58200-93LG0	407A-26-22	61422-98J12	420A-31-1
	180A-2-2	58200-96J00	407A-28-1		420B-31-1
	405A-26-1	58200-96J10	407A-28-2	61422-98J20	420A-31-2
55321-93J00	405A-26-2	58200-96J20	407A-28-3		420B-31-2
	407A-17	58200-96J30	407A-28-4	61425-98J00	420A-38
	55321-94910	335A-21	58200-96J40	407A-28-5	420B-38
	55332-98J00	407A-19	58200-96J50	407A-28-6	420C-38
	55333-98J00	407A-20	58200-96JA0	407A-28-7	420D-38
	56120-93L10-0EP	220A-25-1	58200-96JB0	407A-28-8	61431-98J10-0EP
	56120-93L10-Y5S	220A-25-2	58200-96JC0	407A-28-9	420A-2-1
	56122-93L00	220A-39	58200-96JD0	407A-28-10	420B-2-1
	56124-93L00	220A-26	58200-96JE0	407A-28-11	420C-2-1
	56126-93L00	220A-40	58200-96JF0	407A-28-12	420D-2-1
	56127-93L00	220A-41	58300-93J00	407A-26-11	61431-98J10-Y5S
	56128-93L00	220A-42	58300-93J10	407A-26-12	420A-2-2
	56129-93L00	220A-43	58300-93J20	407A-26-13	420B-2-2
	56130-93J01	220A-32	58300-93J30	407A-26-14	420C-2-2
	56141-93L00	206A-15	58300-93JA0	407A-26-15	420D-2-2
	57110-93L10	220A-1-1	58300-93JB0	407A-26-23	420A-3
	57110-93L20	220A-1-2	58300-93JC0	407A-26-24	420B-3
	57130-87D10	405A-4	58300-93JD0	407A-26-25	420C-3
	57133-93L00	220A-2		407A-26-26	420D-3
	57134-93J00	220A-3			61432-98J01
	57300-93L02	220A-6			420A-4
	57610-93L00	220A-17			420B-4
	57617-93L00	220A-22			420C-4
	57621-93L00	220A-18			420D-4
	57622-93L00	220A-35			420A-5
	57630-92E00	407A-38			420B-5
	57631-93L01	220A-20	61112-98J00	410A-25	420C-5
	57632-93L01	407A-30	61124-98J00	410A-43	420D-5
	57633-87D30	407A-31	61131-93J01-0EP	410A-1-1	61435-93J52
	58105-93J10	407A-27	61131-93J01-Y5S	410A-1-2	61435-93J60
		407A-29	61134-93J20	410A-8	61435-98J12
	58200-93L00	407A-26-1	61137-93J00	410A-3	420A-32-1
	58200-93L10	407A-26-2	61141-93J01-0EP	410A-2-1	420B-32-2
	58200-93L20	407A-26-3	61141-93J01-Y5S	410A-2-2	61436-98J00
	58200-93L30	407A-26-4	61155-93J20	401A-7	61439-98J00
	58200-93L40	407A-26-5	61400-98Y61-0EP	420A-1-1	420A-6
	58200-93L50	407A-26-6		420B-1-1	420B-6
	58200-93L60	407A-26-8		420C-1-1	420C-6
	58200-93L70	407A-26-9		420D-1-1	420D-6
	58200-93L80	407A-26-7	61400-98Y71-Y5S	420A-1-2	61439-98J10
		407A-26-10		420B-1-2	420A-7
	58200-93LA0	407A-26-16		420C-1-2	420C-7
	58200-93LB0	407A-26-17		420D-1-2	420D-7
	58200-93LC0	407A-26-18	61422-93J72	420C-31-1	61439-98J21
	58200-93LD0	407A-26-19		420D-31-1	420A-8
	58200-93LE0	407A-26-20	61422-93J80	420C-31-2	420B-8
					420C-8
					420D-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61443-93J32	420A-28-1 420B-28-1 420C-28-1 420D-28-1	61476-98J00	420C-35-2 420D-35-2 420A-9 420B-9	61634-98J10-Y5S 61635-98J00 61636-98J00 61643-98J00	410A-33-2 410A-39 410A-31 410A-40	67227-98J30 67228-98J50	520A-22 520A-47 540A-48 543A-48	67269-98J30	540A-45 543A-45 540A-2 543A-8	67296-98J10	543A-39 520A-45 543A-41 543A-35
61443-93J40	420A-28-2 420B-28-2 420C-28-2 420D-28-2		420C-9 420D-9 136A-20 136B-20	61645-98J00-0EP 61645-98J00-Y5S 61658-98J00 61811-98J20-0EP	410A-34-1 410A-34-2 410A-41 410A-6-1	67233-98J00 67233-98J10	520A-15 540A-14 543A-13 520A-17	67271-98J20 67271-98J30 67271-98J40 67272-98J00	540A-9 520A-51 540A-20 543A-19	67296-98J20 67296-98J30 67296-98J50	540A-30 520A-50 540A-18 543A-17
61446-93J32	420A-30-1 420B-30-1 420C-30-1 420D-30-1		136C-20 136D-20 136A-21 136B-21	61811-98J20-Y5S 61812-98J00 61814-98J00 61817-93J00	410A-6-2 410A-16 410A-17 410A-10	67234-98J00 67235-98J00 67235-98J10	520A-34 540A-12 543A-11 520A-33	67273-98J00 67273-98J10	543A-27 540A-52 543A-49 540A-28	67296-98J60	520A-48 540A-29 543A-28 540A-31
61446-93J40	420A-30-2 420B-30-2 420C-30-2 420D-30-2		136C-21 136D-21 420A-16 420B-16	61821-98J10-0EP 61821-98J10-Y5S 61827-93J02 61831-98J02-0EP	410A-7-1 410A-7-2 410A-12 410A-18-1	67236-98J00 67236-98J10 67237-98J00 67237-98J30	540A-11 540A-11 520A-35 543A-12	67273-98J20 67273-98J30	540A-28 540A-53 543A-50 543A-29	67296-98J80	543A-32 540A-40 543A-31 520A-16
61446-96J20	420A-37-1 420B-37-1 420C-37-1 420D-37-1	61610-98J30	420C-16 420D-16 420A-17 420B-17	61831-98J02-Y5S 61832-98J00 63632-98J20 63632-98J30	410A-18-2 410A-15 410A-27 410A-28	67237-98J40 67237-98J50 67238-98J00 67239-98J00	540A-13 540A-57 520A-29 540A-16	67284-98J00	543A-51 540A-42 543A-42 540A-15	67296-98JB0 67296-98JCO	543A-19 520A-20 520A-24 520A-28
61446-96J30	420A-37-2 420B-37-2 420C-37-2 420D-37-2		420C-17 420D-17 420A-18 420B-18	65700-93J02 65770-93J11 67200-98J03 67200-98J13	430A-4 430C-4 430A-5 430B-4	67246-98J00 67246-98J10	543A-15 520A-31 540A-4 543A-4	67287-98J00	540A-39 543A-14 543A-38 520A-25	67296-98JD0 67296-98JE0	520A-37 540A-55 543A-52 540A-56
61453-93J32	420A-29-1 420B-29-1 420C-29-1 420D-29-1		420C-18 420D-18 420A-20 420B-20	430C-5 430D-4 67200-98J03 67200-98J13	430C-5 430D-4 543A-1 540A-1	67246-98J20 67251-98J00	540A-51 540A-3 543A-3 520A-12	67288-92E20	540A-36 543A-30 520A-44 540A-35	67297-98J00	540A-56 543A-53 410A-45 410A-46
61453-93J40	420A-29-2 420B-29-2 420C-29-2 420D-29-2		420C-20 420D-20 420A-24 420B-24	67200-98J22 67211-98J20 540A-2 543A-2	520A-1 520A-18 540A-2 540A-49	67252-98J00 67252-98J10	520A-38 540A-21 543A-20 520A-14	67288-98J10	543A-34 520A-46 540A-46 543A-46	67300-93J00 67361-93J00	204A-25 204A-31 204A-26 204A-32
61458-99E70	420A-33 420B-33 420C-33 420D-33	61621-98J01	420C-24 420D-24 420A-21 420B-21	67211-98J30 67212-98J20 67212-98J30 67222-98J00	540A-7 540A-8 540A-8 520A-32	67256-98J00 67258-98J00 67259-98J00	520A-10 520A-9 520A-11 540A-5	67288-98J20	540A-39 540A-22 543A-21 540A-47	68110-98J00	420A-40 420B-40 420C-40 420D-40
61471-98J00	420A-34 420B-34 420C-34 420D-34		420C-21 420D-21 420A-22 420B-22	67222-98J10 67222-98J20 67223-98J00 520A-36	540A-10 543A-9 540A-50 520A-36	67261-98J00 67261-98J10	540A-5 543A-5 540A-6 520A-5	67288-98J40	540A-34 543A-40 520A-23 520A-27	68165-98J00	520A-54 543A-43 540A-44 543A-44
61472-93E32	136B-18 136D-18		420C-22 420D-22	67226-98J00 67226-98J10	540A-17 543A-16 540A-37 543A-36	67261-98J20 67261-98J30	520A-6 540A-7 543A-6 520A-4	67288-98J60 67288-98J70	540A-23 520A-30 520A-40 540A-23	69711-93E10	136A-19 136B-19 136C-19 136D-19
61472-93E40	136A-18 136C-18		420A-23 420B-23	67226-98J00 67226-98J10	540A-37 520A-26 540A-41 520A-42	67263-98J20 67264-98J00	543A-6 520A-3 520A-7 540A-27	67292-98J00	540A-23 543A-22 520A-13 520A-43		
61473-98J00	420A-35-1 420B-35-1 420C-35-1 420D-35-1	61630-98J00	420C-23 420D-23 410A-26 410A-32-1	67226-98J10 67227-98J00 67227-98J10 61633-98J10-0EP	520A-26 540A-41 520A-42 540A-25	67265-98J00 67269-98J00	520A-7 540A-27 543A-26 520A-53	67294-98J00 67296-94300	540A-33 543A-33 540A-32		
61473-98J10	420A-35-2 420B-35-2		410A-32-2 410A-33-1	61633-98J10-Y5S 61634-98J10-0EP	543A-24 520A-21	67269-98J10 67269-98J20	520A-53 520A-19	67296-98J00			

70000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
77811-54GC0-0PG	420A-19 420B-19 420C-19 420D-19		147B-67 147C-67 147D-67 180A-28 303A-14 310A-9 322A-21 322A-28 326A-15 326A-21		136B-9 136B-14 136B-15 136C-9 136C-14 136C-15 136D-9 136D-14 136D-15 162A-33
90000			326B-15 326B-21 326C-15 326C-21 326D-15 326D-21		162A-34 204A-21 420A-11 420B-11 420C-11 420D-11
99011-98J40-054	420A-39-1 420C-39-1		407A-37 420A-26 420A-27	01550-0620A	119A-25 119A-26
99011-98J40-059	420A-39-2 420B-39 420C-39-2 420D-39		420B-26 420B-27 420C-26 420C-27 420D-26 420D-27	01550-06257	121A-13 140A-10 147A-46 147B-46 147C-46 147D-46 162A-35
00000			303A-6 303A-11 326A-28 326B-28 326C-28 326D-28	01550-06357	310A-10 147A-63 147B-63 147C-63 147D-63 206A-19
01421-08357	163A-28	01550-06167	420A-10 420A-12 420A-14 420B-10		326B-29 326C-29 326D-29
01500-06167	147A-42 147B-42 147C-42 147D-42		420B-12 420B-14 420C-10 420C-12	01550-06407	136A-16 136B-16 136C-16 136D-16
01500-06257	147A-61 147B-61 147C-61 147D-61		420C-14 420D-10 420D-12		162A-25 163A-11
01547-06167	420A-25 420B-25 420C-25 420D-25		420D-14 420D-12 420D-14 175A-11	01550-08127	163A-29 410A-14
01547-06207	310A-12		111A-4	01550-08207	111A-17 111A-35
01547-06257	111A-29	01550-0616A	111A-8		113A-2
01547-06507	111A-30	01550-06207	113A-24		140A-9
01550-06127	136A-8 136B-8 136C-8 136D-8		136A-9 136A-14 136A-15	01550-08307	301A-23 301A-24 401A-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
01550-0830A	401A-22 119A-13 119A-17 119A-21 401A-16		420A-15 420B-13 420B-15 420C-13 420C-15	09108-12013	405A-9
01550-08357	136A-17 136B-17 136C-17 136D-17 163A-12 163A-30	04211-11129	420D-13 420D-15 163A-14 163A-32 119A-12	09116-06121	162A-13
01550-0835A	113A-28	04211-13149	220A-23	09116-06202	310A-7
01550-08407	144A-18 144B-18 144C-18 144D-18	06111-07004	220A-24	09116-06236	405A-27-1
	147A-65 147B-65 147C-65 147D-65	06111-11004	113A-18		405A-27-2
01550-08457	113A-29	07130-0510A	326A-5	09116-08122	407A-18
01550-0845A	175A-12	07130-05167	326B-5 326C-5 326D-5	09116-08126	401A-19
01550-08557	204A-30		07130-0616A	09116-08128	401A-38
01550-0855A	119A-7	08110-60020	175A-15	09116-08131	180A-20
01550-08607	111A-18 111A-19 163A-31	08221-16256	220A-9		160A-16
	401A-23	08310-00067	322A-16	09116-08137	160B-16
01550-0865A	175A-13	08316-10087	163A-34	09116-08163	160C-16
01550-0885A	175A-14		322A-2	09116-10134	160D-16
01550-1025A	116A-12	08321-0105A	326A-6 326B-6 326C-6 326D-6	09116-10135	401A-30
01550-1050A	180A-19		09116-10150	09116-10137	401A-34
01570-06357	147A-50 147B-50 147C-50 147D-50		326A-6 326B-6 326C-6 326D-6	09116-10146	180A-22
02112-0406B	147A-56 147B-56 147C-56 147D-56	08321-01067	322A-17		401A-36
	147A-30	08331-41359	204A-23	09116-10176	401A-36
02112-0612A	111A-28	08331-4158A	220A-38	09125-05048	405A-2
02142-0408B	147A-29 147C-29	09100-12052	407A-6	09125-06063	315A-15
	204A-22	09100-12085	335A-9-1		315A-8
02142-05107	147A-30	09100-12086	335A-9-3		335A-5
	147C-30	09100-12092	335A-9-2		335A-24
02112-05107	147A-30	09100-14004	401A-26		336A-8
	147C-30		405A-15		336A-18
02112-0612A	111A-28	09103-06093	315A-17		337A-34
02142-0408B	147A-29 147C-29	09103-06231	303A-12		337A-35
	204A-22	09103-06278	335A-20		337A-36
02142-05107	163A-13	09103-06281	111A-16	09131-05004	405A-6
03112-06303	502A-3		140A-7		405A-12
03122-05165	530A-9	09103-08109	206A-20		530A-23
03542-06169	420A-13	09103-08370	163A-24	09132-04034	160A-17
		09103-08437	122A-4		160B-17
		09103-12125	303A-2		160C-17
		09106-05030	303A-8		160D-17
		09108-08282	122A-3		206A-22
		09108-10115	405A-8	09136-06148	410A-11
				09137-04004	326A-8
					326B-8
					326C-8
					326D-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09139-06135	410A-4	09160-39001	336A-9	09181-78004	220A-14-4
09139-06136	410A-5	09160-50006	220A-13	09181-78005	220A-14-5
09140-05005	315A-14	09160-60012	220A-12	09181-78006	220A-14-6
09140-10032	336A-19	09162-10005	337A-26	09181-78007	220A-14-7
09140-16026	220A-8	09168-10034	407A-16	09181-78008	220A-14-8
09141-18005	407A-32	09168-12012	180A-15	09181-78009	220A-14-9
09159-08136	122A-5	09168-12013	147A-17	09181-78010	220A-14-10
	163A-33		147C-17	09181-84001	220A-15-1
09159-10116	113A-12	09168-16009	111A-12	09181-84002	220A-15-2
09159-12014	407A-11	09169-06062	147A-15	09181-84003	220A-15-3
09159-12062	335A-10		147A-60	09181-84004	220A-15-4
09159-14020	335A-17		147B-15	09181-84005	220A-15-5
09159-14026	401A-27		147B-60	09181-84006	220A-15-6
	405A-17		147C-15	09181-84007	220A-15-7
09159-22006	335A-8		147C-60	09181-84008	220A-15-8
09159-28003	220A-4		147D-15	09181-84009	220A-15-9
09160-05024	540A-38		147D-60	09181-84010	220A-15-10
	543A-37		310A-5	09202-05032	
09160-05029	315A-16	09169-08038	401A-39	09202-06031	160A-18
	326A-4	09169-08039	410A-20		160B-18
	326B-4	09169-08042	147A-64		160C-18
	326C-4		147B-64		160D-18
	326D-4		147C-64		303A-3
09160-06055	204A-27		147D-64		407A-25
09160-06082	336A-20	09180-32006	220A-10	09202-08006	180A-17
09160-06084	147A-59	09181-12158	175A-9		180A-18
	147B-59	09181-32035	220A-11-1		405A-3
	147C-59	09181-32036	220A-11-2		405A-10
	147D-59	09181-32037	220A-11-3		407A-12
09160-06094	204A-10	09181-32038	220A-11-4	09202-08013	220A-19
09160-06104	520A-49	09181-32039	220A-11-5	09204-01006	204A-11
09160-06134	310A-4	09181-32040	220A-11-6		336A-21
09160-08082	410A-38	09181-32041	220A-11-7	09204-03003	407A-34
09160-08152	410A-37	09181-32042	220A-11-8	09205-03004	206A-4
09160-08161	122A-6	09181-32043	220A-11-9	09205-10006	204A-12
	163A-35	09181-32044	220A-11-10	09206-03001	407A-3
09160-10082	206A-10	09181-39001	336A-10	09206-08001	111A-3
09160-10104	116A-11	09181-60004	220A-7-1		111A-7
09160-10141	407A-8	09181-60005	220A-7-2		111A-27
09160-10148	204A-4	09181-60006	220A-7-3		401A-8
09160-12066	407A-9	09181-60007	220A-7-4		401A-15
09160-13021	335A-12	09181-60008	220A-7-5	09206-09012	206A-21
09160-13022	335A-11	09181-60009	220A-7-6	09206-13019	113A-13
09160-14066	405A-23	09181-60010	220A-7-7	09206-14004	111A-20
09160-15051	401A-28	09181-60011	220A-7-8	09246-05006	113A-21
09160-16050	405A-16	09181-60012	220A-7-9	09247-14041	144A-11
	405A-18	09181-60013	220A-7-10		144C-11
09160-17052	410A-30	09181-78001	220A-14-1	09247-14042	144B-11
09160-18028	407A-33	09181-78002	220A-14-2		144D-11
09160-18031	113A-10	09181-78003	220A-14-3	09248-12009	180A-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09248-12011	204A-13	09320-08062	144A-12		502A-5
09248-18006	113A-11		144B-12	09360-12008	147A-18
09248-26001	113A-9		144C-12		147C-18
09250-21003	410A-47		144D-12	09360-12013	147B-18
09251-09002	430A-1	09320-08076	163A-25		147D-18
	430B-1	09320-08086	147A-69	09360-14009	144A-13
	430C-1		147B-69		144C-13
	430D-1		147C-69	09360-14014	144B-13
09260-10005	204A-14		147D-69		144D-13
09261-05006	121A-10	09320-08501	147A-12	09362-09008	407A-23
09262-17019	204A-15		147B-12	09363-08004	147A-19
09262-40017	119A-3		147C-12		147C-19
09262-40018	119A-2		147D-12	09367-06002	162A-26
09263-30023	220A-27	09320-09016	310A-6	09367-10001	430A-2
09263-35048	407A-4	09320-11013	410A-21		430B-2
09263-72001	220A-28	09320-12014	162A-15		430C-2
09263-78001	220A-45	09320-12072	147A-34		430D-2
09263-80001	407A-5		147B-34	09380-21002	337A-28
09263-83001	220A-46		147C-34	09380-38003	336A-12
09265-30033	220A-16		147D-34	09381-22010	116A-4
09265-32003	220A-36	09320-12076	310A-8		220A-31
09269-32002	220A-5	09321-10030	410A-13	09381-72001	220A-37
09280-00030	220A-44		410A-22	09383-07003	206A-13
09280-00047	220A-29	09329-14002	410A-42	09383-08004	204A-19
09280-06005	113A-20	09343-75001-600	147A-10	09385-06012	204A-28
09280-09008	180A-27		147A-36	09387-38002	405A-5
09280-10009	113A-15		147A-48	09401-08412	147A-57
	163A-10		147B-10		147B-57
09280-10016	113A-16		147B-36		147C-57
09280-22019	111A-14		147B-48		147D-57
	140A-8		147C-10	09401-08413	162A-27
	180A-5		147C-36	09401-11414	147A-37
09280-22020	175A-10		147C-48		147B-37
09280-26006	111A-32		147D-10		147C-37
	162A-14		147D-36		147D-37
09280-66004	220A-33		147D-48	09401-11425	144A-14
09280-70012	119A-6	09352-50823-00B	147A-68		144B-14
09282-24004	220A-34		147B-68		144C-14
09282-30006	220A-30		147C-68		144D-14
09282-39001	336A-11		147D-68	09401-13423	144A-20
09283-10011	206A-7	09352-50903-00B	162A-23		144B-20
09283-32044	119A-4		162A-24		144C-20
09283-91001	116A-13	09352-50903-600	162A-16		144D-20
09289-05012	121A-22		163A-22		163A-22
09289-18001	204A-16		162A-18		430A-3
09306-06005	204A-17		162A-19		430A-6
09306-10001	204A-18		162A-20		430B-3
09306-17002	410A-29		162A-21		430C-3
09306-24001	337A-27		162A-22		430C-6
09320-08021	322A-9	09355-40805-00B	407A-22		430D-3

SUZUKI DF300AP/250AP PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Technical Readiness Group, Quality Administration Department

300 Takatsuka, Minami, Hamamatsu, Japan

Reprint Prohibited

SUZUKI MOTOR CORPORATION