

SUZUKI

PARTS CATALOGUE

DF9. 9B/15A/20A

DF9.9B/BR

DF9.9BT

DF15A/AR

DF15AT/ATH

DF20A/AR

DF20AT/ATH



OUTBOARD MOTOR

P01/P40

2016-9

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF9.9B/15A/20A production start 2016.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S, L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 02002F-123456		
123456~	: From E. NO. 02002F-123456		

12 x 34 x 5.6..... Figures in the description column

| | | show the dimensions of parts.

ID OD T(or W, L)

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec.:

spec. code :	DF9.9B : P1	DF9.9BR : P1
	DF15A : P1	DF15AR : P1
	DF20A : P1, P40	DF20AR : P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE NO.
DF9.9B	P01	00995F	S, L, X	00995F-710001~
DF9.9BR	P01	00995F	S, L, X	00995F-710001~
DF9.9BT	P01	00995F	S, L, X	00995F-710001~
DF15A	P01	01504F	S, L, X	01504F-710001~
DF15AR	P01	01504F	S, L, X	01504F-710001~
DF15AT	P01	01504F	S, L, X	01504F-710001~
DF15ATH	P01	01504F	S, L, X	01504F-710001~
DF20A	P01, P40	02002F	S, L, X	02002F-710001~
DF20AR	P01	02002F	S, L, X	02002F-710001~
DF20AT	P01	02002F	S, L, X	02002F-710001~
DF20ATH	P01	02002F	S, L, X	02002F-710001~

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




DC9M_R01_012_111A
COUNDESEAL

FIG.113A




DC9M_R01_012_113A
COUNDESEAL

FIG.116A




DC9M_R01_012_116A
COUNDESEAL

FIG.120A




DC9M_R01_012_120A
COUNDESEAL

FIG.121A




DC9M_R01_012_121A
COUNDESEAL

FIG.121B




DC9M_R01_012_121B
COUNDESEAL

FIG.121C




DC9M_R01_012_121C
COUNDESEAL

FIG.121D




DC9M_R01_012_121D
COUNDESEAL

FIG. 121E




DC90A_P01_01Z_021E
CABESV4ET

FIG. 121F




DC90A_P01_01Z_021F
CABESV4ET

FIG. 121G




DC90A_P01_01Z_021G
CABESV4ET

FIG. 121H




DC90A_P01_01Z_021H
CABESV4ET

FIG. 121J




DC90A_P01_01Z_021J
CABESV4ET

FIG. 121K




DC90A_P01_01Z_021K
CABESV4ET

FIG. 121L




DC90A_P01_01Z_021L
CABESV4ET

FIG. 121M




DC90A_P01_01Z_021M
CABESV4ET

FIG. 126A




DC604_R01_012_126A
PIELET MARKING

FIG. 126B




DC604_R01_012_126B
PIELET MARKING

FIG. 126C




DC604_R01_012_126C
PIELET MARKING

FIG. 126D




DC604_R01_012_126D
PIELET MARKING

FIG. 126E




DC604_R01_012_126E
PIELET MARKING

FIG. 126F




DC604_R01_012_126F
PIELET MARKING

FIG. 126G




DC604_R01_012_126G
PIELET MARKING

FIG. 126H




DC604_R01_012_126H
PIELET MARKING

FIG.126J




DC604_R01_012_126J
FUEL MANIFOLD

FIG.126K




DC604_R01_012_126K
FUEL MANIFOLD

FIG.126L




DC604_R01_012_126L
FUEL MANIFOLD

FIG.126M




DC604_R01_012_126M
FUEL MANIFOLD

FIG.144A




DC604_R01_012_144A
FUEL INJECTOR

FIG.146A



DC604_R01_012_146A
FUEL PUMP

FIG.146B



DC604_R01_012_146B
FUEL PUMP

FIG.146C






FIG.146D




DC604_P01_012_146D
FILE: 0500

FIG.146E




DC604_P01_012_146E
FILE: 0500

FIG.146F




DC604_P01_012_146F
FILE: 0500

FIG.146G




DC604_P01_012_146G
FILE: 0500

FIG.146H




DC604_P01_012_146H
FILE: PL00P

FIG.146J




DC604_P01_012_146J
FILE: PL00P

FIG.146K




DC604_P01_012_146K
FILE: PL00P

FIG.146L




DC604_P01_012_146L
FILE: PL00P

FIG.146M




DC9M_P01_012_146M
BAUER PUMP

FIG.160A




DC9M_P01_012_160A
BAUER PUMP

FIG.160B




DC9M_P01_012_160B
BAUER PUMP

FIG.160C




DC9M_P01_012_160C
BAUER PUMP

FIG.160D




DC9M_P01_012_160D
BAUER PUMP

FIG.160E




DC9M_P01_012_160E
BAUER PUMP

FIG.160F




DC9M_P01_012_160F
BAUER PUMP

FIG.160G




DC9M_P01_012_160G
BAUER PUMP

FIG.160H




DC90A_P01_012_160H
WATER PUMP

FIG.160J




DC90A_P01_012_160J
WATER PUMP

FIG.160K




DC90A_P01_012_160K
WATER PUMP

FIG.160L




DC90A_P01_012_160L
WATER PUMP

FIG.160M




DC90A_P01_012_160M
WATER PUMP

FIG.162A




DC90A_P01_012_162A
THERMOSTAT

FIG.163A




DC90A_P01_012_163A
THERMOSTAT

FIG.163B




DC90A_P01_012_163B
THERMOSTAT

FIG. 163C




DC60A_R01_012_163C
THROTTLE BODY

FIG. 163D




DC60A_R01_012_163D
THROTTLE BODY

FIG. 163E




DC60A_R01_012_163E
THROTTLE BODY

FIG. 163F




DC60A_R01_012_163F
THROTTLE BODY

FIG. 163G




DC60A_R01_012_163G
THROTTLE BODY

FIG. 163H




DC60A_R01_012_163H
THROTTLE BODY

FIG. 163J




DC60A_R01_012_163J
THROTTLE BODY

FIG. 163K




DC60A_R01_012_163K
THROTTLE BODY

FIG. 163L




DC604_R01_012_163L
THROTTLE CONTROL

FIG. 163M




DC604_R01_012_163M
THROTTLE CONTROL

FIG. 166A




DC604_R01_012_166A
THROTTLE CONTROL

FIG. 166B




DC604_R01_012_166B
THROTTLE CONTROL

FIG. 166C




DC604_R01_012_166C
THROTTLE CONTROL

FIG. 166D




DC604_R01_012_166D
THROTTLE CONTROL

FIG. 166E



DC604_R01_012_166E
THROTTLE CONTROL

FIG. 166F



DC604_R01_012_166F
THROTTLE CONTROL

FIG.167A


D004_R01_012_NEF
RECCE STARTER

FIG.167B


D004_R01_012_NEF
RECCE STARTER

FIG.167C


D004_R01_012_NEF
RECCE STARTER

FIG.167D


D004_R01_012_NEF
RECCE STARTER

FIG.167E


D004_R01_012_NEF
RECCE STARTER

FIG.167F


D004_R01_012_NEF
RECCE STARTER

FIG.167G


D004_R01_012_NEF
RECCE STARTER

FIG.167H




D004_R01_012_NEF
RECCE STARTER

FIG. 167J




DF204_P01_017_167J

FIG. 167K




DF204_P01_017_167K

FIG. 167L




DFRM_P01_017_1672

FIG. 167M




DEFRA_P01_017_167M

FIG. 175A




DFRDA_P01_017_175A
OR PUMP

FIG. 206A




DF204_R01_017_2064
CLUTCH ROD

FIG. 206B




DF204_P01_017_2163
CLUTCH ROD

FIG. 206C




DF20A_P01_017_208C
CLUTCH ROD

FIG.206D




DC604_R01_012_206D
(CLUTCH RED)

FIG.206E




DC604_R01_012_206E
(CLUTCH RED)

FIG.206F




DC604_R01_012_206F
(CLUTCH RED)

FIG.206G




DC604_R01_012_206G
(CLUTCH RED)

FIG.206H




DC604_R01_012_206H
(CLUTCH RED)

FIG.206J




DC604_R01_012_206J
(CLUTCH RED)

FIG.206K




DC604_R01_012_206K
(CLUTCH RED)

FIG.206L




DC604_R01_012_206L
(CLUTCH RED)

FIG.206M




DC6M_R01_012_004M
CLUTCH/202

FIG.210A




DC6M_R01_012_010A
G5/F/202

FIG.220A




DC6M_R01_012_200A
TRANSMISSION

FIG.220B




DC6M_R01_012_200B
TRANSMISSION

FIG.220C




DC6M_R01_012_200C
TRANSMISSION

FIG.220D




DC6M_R01_012_200D
TRANSMISSION

FIG.220E




DC6M_R01_012_200E
TRANSMISSION

FIG.220F




DC6M_R01_012_200F
TRANSMISSION

FIG.220G




DC604_R01_012_283G
TRANSMISSION

FIG.220H




DC604_R01_012_283H
TRANSMISSION

FIG.220J




DC604_R01_012_283J
TRANSMISSION

FIG.220K




DC604_R01_012_283K
TRANSMISSION

FIG.220L




DC604_R01_012_283L
TRANSMISSION

FIG.220M




DC604_R01_012_283M
TRANSMISSION

FIG.301A




DC604_R01_012_301A
STARTING MOTOR

FIG.303A




DC604_R01_012_303A
MAGNETO

FIG.303B




DC604_P01_012_303B
MAGNETO

FIG.303C




DC604_P01_012_303C
MAGNETO

FIG.303D




DC604_P01_012_303D
MAGNETO

FIG.303E




DC604_P01_012_303E
MAGNETO

FIG.310A




DC604_P01_012_310A
RECTOR-REGENERATION COIL

FIG.310B




DC604_P01_012_310B
RECTOR-REGENERATION COIL

FIG.310C




DC604_P01_012_310C
RECTOR-REGENERATION COIL

FIG.310D




DC604_P01_012_310D
RECTOR-REGENERATION COIL

FIG.310E




DCRM_P01_012_310E
REC'D REVISION CODE

FIG.310F




DCRM_P01_012_310F
REC'D REVISION CODE

FIG.310G




DCRM_P01_012_310G
REC'D REVISION CODE

FIG.310H




DCRM_P01_012_310H
REC'D REVISION CODE

FIG.310J




DCRM_P01_012_310J
REC'D REVISION CODE

FIG.310K




DCRM_P01_012_310K
REC'D REVISION CODE

FIG.310L




DCRM_P01_012_310L
REC'D REVISION CODE

FIG.310M




DCRM_P01_012_310M
REC'D REVISION CODE

FIG.322A




DC604_R01_012_3204
HARNESS

FIG.322B




DC604_R01_012_3202
HARNESS

FIG.322C




DC604_R01_012_3201
HARNESS

FIG.322D




DC604_R01_012_3203
HARNESS

FIG.322E




DC604_R01_012_3235
HARNESS

FIG.322F




DC604_R01_012_3237
HARNESS

FIG.322G




DC604_R01_012_3232
HARNESS

FIG.322H




DC604_R01_012_3239
HARNESS

FIG.322J




DC604_R01_012_302J
PIT SWITCH

FIG.322K




DC604_R01_012_302K
PIT SWITCH

FIG.322L




DC604_R01_012_302L
PIT SWITCH

FIG.322M




DC604_R01_012_302M
PIT SWITCH

FIG.327A




DC604_R01_012_307A
PIT SWITCH

FIG.327B




DC604_R01_012_307B
PIT SWITCH

FIG.327C




DC604_R01_012_307C
PIT SWITCH

FIG.327D




DC604_R01_012_307D
PIT SWITCH

FIG.327E




DK9M_P01_012_207E
P/T SWITCH

FIG.334A




DK9M_P01_012_204A
SENSOR SWITCH

FIG.334B




DK9M_P01_012_204B
SENSOR SWITCH

FIG.334C




DK9M_P01_012_204C
SENSOR SWITCH

FIG.334D




DK9M_P01_012_204D
SENSOR SWITCH

FIG.334E




DK9M_P01_012_204E
SENSOR SWITCH

FIG.334F




DK9M_P01_012_204F
SENSOR SWITCH

FIG.334G




DK9M_P01_012_204G
SENSOR SWITCH

FIG.334H




DCRM_R01_012_204F
SS302058WTCV

FIG.334J




DCRM_R01_012_204F
SS302058WTCV

FIG.334K




DCRM_R01_012_204F
SS302058WTCV

FIG.334L




DCRM_R01_012_204F
SS302058WTCV

FIG.334M




DCRM_R01_012_204F
SS302058WTCV

FIG.335A




DCRM_R01_012_205A
CLAMP BRACKET

FIG.335B




DCRM_R01_012_205B
CLAMP BRACKET

FIG.335C




DCRM_R01_012_205C
CLAMP BRACKET

FIG.335D




DCRM_R01_012_0020
CLAMP BRACKET

FIG.335E




DCRM_R01_012_0020
CLAMP BRACKET

FIG.335F




DCRM_R01_012_0020
CLAMP BRACKET

FIG.335G




DCRM_R01_012_0020
CLAMP BRACKET

FIG.335H




DCRM_R01_012_0030
CLAMP BRACKET

FIG.335J




DCRM_R01_012_0030
CLAMP BRACKET

FIG.335K




DCRM_R01_012_0030
CLAMP BRACKET

FIG.335L




DCRM_R01_012_0030
CLAMP BRACKET

FIG.335M




DK04_R01_012_035M
CLAMP BRACKET

FIG.336A




DK04_R01_012_036A
SWIVEL BRACKET

FIG.336B




DK04_R01_012_036B
SWIVEL BRACKET

FIG.336C




DK04_R01_012_036C
SWIVEL BRACKET

FIG.336D




DK04_R01_012_036D
SWIVEL BRACKET

FIG.336E




DK04_R01_012_036E
SWIVEL BRACKET

FIG.336F




DK04_R01_012_036F
SWIVEL BRACKET

FIG.336G




DK04_R01_012_036G
SWIVEL BRACKET

FIG.336H




DC604_R01_012_286V
SWING BRACKET

FIG.336J




DC604_R01_012_286V
SWING BRACKET

FIG.336K




DC604_R01_012_286V
SWING BRACKET

FIG.336L




DC604_R01_012_286V
SWING BRACKET

FIG.336M




DC604_R01_012_286V
SWING BRACKET

FIG.338A




DC604_R01_012_286V
TILT CYLINDER

FIG.338B




DC604_R01_012_286V
TILT CYLINDER

FIG.338C




DC604_R01_012_286V
TILT CYLINDER

FIG.338D




DC604_R01_012_38D
PIT C-1000320

FIG.338E




DC604_R01_012_38E
PIT C-1000320

FIG.340A




DC604_R01_012_36A
PIT 467020

FIG.340B




DC604_R01_012_36B
PIT 467020

FIG.340C




DC604_R01_012_36C
PIT 467020

FIG.340D




DC604_R01_012_36D
PIT 467020

FIG.340E




DC604_R01_012_36E
PIT 467020

FIG.401A




DC604_R01_012_401A
ENGINE ASSEMBLY

FIG.405A




DC90A_P01_012_405A
SEE DRAWING

FIG.407A




DC90A_P01_012_407A
SEE DRAWING

FIG.407B




DC90A_P01_012_407B
SEE DRAWING

FIG.410A




DC90A_P01_012_410A
SEE DRAWING

FIG.410B




DC90A_P01_012_410B
SEE DRAWING

FIG.410C




DC90A_P01_012_410C
SEE DRAWING

FIG.410D




DC90A_P01_012_410D
SEE DRAWING

FIG.410E




DC90A_P01_012_410E
SEE DRAWING

FIG.410F




DCRM_P01_012_410F
SEE COVER

FIG.410G




DCRM_P01_012_410G
SEE COVER

FIG.410H




DCRM_P01_012_410H
SEE COVER

FIG.410J




DCRM_P01_012_410J
SEE COVER

FIG.410K




DCRM_P01_012_410K
SEE COVER

FIG.410L




DCRM_P01_012_410L
SEE COVER

FIG.410M




DCRM_P01_012_410M
SEE COVER

FIG.420A




DCRM_P01_012_420A
ENGINE COVER

FIG.420B




DC604_R01_012_420B
ENGINE COVER

FIG.420C




DC604_R01_012_420C
ENGINE COVER

FIG.420D




DC604_R01_012_420D
ENGINE COVER

FIG.420E




DC604_R01_012_420E
ENGINE COVER

FIG.420F




DC604_R01_012_420F
ENGINE COVER

FIG.420G




DC604_R01_012_420G
ENGINE COVER

FIG.420H




DC604_R01_012_420H
ENGINE COVER

FIG.420J




DC604_R01_012_420J
ENGINE COVER

FIG.420K




DCRM_R01_012_420K
ENGINE COVER

FIG.420L




DCRM_R01_012_420L
ENGINE COVER

FIG.420M




DCRM_R01_012_420M
ENGINE COVER

FIG.432A




DCRM_R01_012_432A
FUEL TANK

FIG.442A




DCRM_R01_012_442A
FUEL TANK

FIG.442B




DCRM_R01_012_442B
FUEL TANK

FIG.442C




DCRM_R01_012_442C
FUEL TANK

FIG.442D




DCRM_R01_012_442D
FUEL TANK

FIG.442E




DK04_R01_012_442E
DRUGLIN

FIG.442F




DK04_R01_012_442F
DRUGLIN

FIG.444A




DK04_R01_012_444A
TILEX HANDLE

FIG.444B




DK04_R01_012_444B
TILEX HANDLE

FIG.444C




DK04_R01_012_444C
TILEX HANDLE

FIG.444D




DK04_R01_012_444D
TILEX HANDLE

FIG.444E




DK04_R01_012_444E
TILEX HANDLE

FIG.444F




DK04_R01_012_444F
TILEX HANDLE

FIG.501C




DC904_R01_012.B01C
OPT.PARANTE CONTR.O.

FIG.501D




DC904_R01_012.B01D
OPT.PARANTE CONTR.O.

FIG.501E




DC904_R01_012.B01E
OPT.PARANTE CONTR.O.

FIG.501F




DC904_R01_012.B01F
OPT.PARANTE CONTR.O.

FIG.508A




DC904_R01_012.B08A
OPT.PARANTE CONTR.O.

FIG.508B




DC904_R01_012.B08B
OPT.PARANTE CONTR.O.

FIG.508C




DC904_R01_012.B08C
OPT.PARANTE CONTR.O.

FIG.508D




DC904_R01_012.B08D
OPT.PARANTE CONTR.O.

FIG.513A




DCRM_R01_012.513A
OPT REMOTE CONTROL PARTS

FIG.513B




DCRM_R01_012.513B
OPT REMOTE CONTROL PARTS

FIG.513C




DCRM_R01_012.513C
OPT REMOTE CONTROL PARTS

FIG.513D




DCRM_R01_012.513D
OPT REMOTE CONTROL PARTS

FIG.515A




DCRM_R01_012.515A
OPT REMOTE CABLE

FIG.515B




DCRM_R01_012.515B
OPT REMOTE CABLE

FIG.515C





DCRM_R01_012.515C
OPT REMOTE CABLE

FIG.515D





DCRM_R01_012.515D
OPT REMOTE CABLE

FIG.515E





DC9M_R11_012,515E
OPT.FASMCCHIO CABLE

FIG.515F





DC9M_R11_012,515F
OPT.FASMCCHIO CABLE

FIG.515G





DC9M_R11_012,515G
OPT.FASMCCHIO CABLE

FIG.515H





DC9M_R11_012,515H
OPT.FASMCCHIO CABLE

FIG.515J




DC9M_R11_012,515J
OPT.FASMCCHIO CABLE

FIG.515K




DC9M_R11_012,515K
OPT.FASMCCHIO CABLE

FIG.530A




DC9M_R11_012,530A
OPT.SWITCH

FIG.530B




DC9M_R11_012,530B
OPT.SWITCH

FIG.530C




DCRM_P01_012.530C
OPT-CONTROL

FIG.530D




DCRM_P01_012.530D
OPT-CONTROL

FIG.530E




DCRM_P01_012.530E
OPT-CONTROL

FIG.530F




DCRM_P01_012.530F
OPT-CONTROL

FIG.544A




DCRM_P01_012.544A
OPT-PARAMETER CONTROL ASSY SINGLE (1)

FIG.544B




DCRM_P01_012.544B
OPT-PARAMETER CONTROL ASSY SINGLE (1)

FIG.544C




DCRM_P01_012.544C
OPT-PARAMETER CONTROL ASSY SINGLE (1)

FIG.544D




DCRM_P01_012.544D
OPT-PARAMETER CONTROL ASSY SINGLE (1)

FIG.544E




DC90A_P01_012_844C
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544F




DC90A_P01_012_844C
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544G




DC90A_P01_012_844C
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544H




DC90A_P01_012_844C
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544J




DC90A_P01_012_844J
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.544K




DC90A_P01_012_844K
OPT-REMOTE CONTROL ASSY SINGLE (7)

FIG.545A




DC90A_P01_012_845A
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545B




DC90A_P01_012_845B
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545C




DCRM_P01_017_545C
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545D




DCRM_P01_017_545D
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545E




DCRM_P01_017_545E
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545F




DCRM_P01_017_545F
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545G




DCRM_P01_017_545G
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545H




DCRM_P01_017_545H
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545J




DCRM_P01_017_545J
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.545K




DCRM_P01_017_545K
OPT-REMOTE CONTROL ASSY SINGLE (2)

FIG.546A




DC60A_P01_012_846A
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.546B




DC60A_P01_012_846B
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.546C




DC60A_P01_012_846C
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.546D




DC60A_P01_012_846D
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.546E




DC60A_P01_012_846E
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.546F




DC60A_P01_012_846F
OPT.FARACCONI CABLE (ELECTRIC STARTER)

FIG.553A




DC60A_P01_012_853A
OPT.ELECTRICAL (MANUAL STARTER)

FIG.553B




DC60A_P01_012_853B
OPT.ELECTRICAL (MANUAL STARTER)

FIG.553C




DC90A_P01_012,8EC
OPT-ELECTRICAL (MANUAL STARTER)

FIG.553D




DC90A_P01_012,8EC
OPT-ELECTRICAL (MANUAL STARTER)

FIG.561A




DC90A_P01_012,801A
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.561B




DC90A_P01_012,801D
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.561C




DC90A_P01_012,801C
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.561D




DC90A_P01_012,801D
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.575A




DC90A_P01_012,555A
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.575B




DC90A_P01_012,555B
OPT-STARTING MOTOR (MANUAL STARTER)

FIG.575C




DC604_R01_012_052C
OPT:2042010V

FIG.575D




DC604_R01_012_052D
OPT:2042010V

FIG.583A




DC604_R01_012_053A
OPT:2042010V

FIG.600A




DC604_R01_012_050A
OPT:ALL TO FUNCTION GAUGE

FIG.600B




DC604_R01_012_050B
OPT:ALL TO FUNCTION GAUGE

FIG.600C




DC604_R01_012_050C
OPT:ALL TO FUNCTION GAUGE

FIG.600D




DC604_R01_012_050D
OPT:ALL TO FUNCTION GAUGE

FIG.600E



DC604_R01_012_050E
OPT:ALL TO FUNCTION GAUGE

FIG. 600F



DIGITAL PULL-OFF TEST GAUGE
OPTIONAL FUNCTION GAUGE

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-89L01	HEAD, CYLINDER	1	
2	11141-89L00	GASKET, CYLINDER HEAD	1	
3	09119-08L02	BOLT (8X72)	6	
4	09119-08L01	BOLT (8X77)	2	
5	11261-93J00	COVER, PROTECTION ANODE	1	
6	09280-22019	O RING (D:1.9,ID:21.8)	1	
7	55321-87J01	ANODE, PROTECTION	1	
8	09103-06281	BOLT (6X14)	1	
9	01550-0820C	BOLT	1	
10	11382-93E00	CAP, OIL FILLER	1	
11	09280-17003	O RING (D:3.1,ID:16.8)	1	
12	04211-11129	PIN	2	
13	11170-89L00	COVER, CYLINDER HEAD	1	
14	11162-89L00	GASKET, CYLINDER HEAD COVER	1	
15	01550-0620C	BOLT	6	
16	11174-89L00	HOSE, BREATHER	1	
17	09401-12413	CLIP	2	
18	09482-00L04	SPARK PLUG (CPR6EA-9)	2	NGK
19	11115-93E00-001	GUIDE, VALVE (OS:0.3)	4	OPT

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11300-89L03	BLOCK ASSY, CYLINDER	1	
2	01550-06357	.BOLT	6	
3	01560-08757	.BOLT	4	
4	04211-11129	.PIN	2	
5	16440-11D00	REGULATOR ASSY, ENGINE	1	
6	11291-91B50	HOOK, ENGINE	1	OPT
7	01550-08207	BOLT	1	OPT

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-89L00-0B0	PISTON	2	
2	12140-89L10	RING SET, PISTON	2	
3	12151-89L00	PIN, PISTON	2	
4	09381-16001	SNAP RING	4	
5	12160-89L11	CONNROD ASSY	2	
6	12163-89L02	.BOLT, CONNROD	4	
7	12220-89L00	CRANKSHAFT	1	
8	12341-89L10	BEARING, CRANKSHAFT	4	
9	09283-32039	OIL SEAL (32X44X6.5)	2	
10	12100-89L10-050	PISTON SET (OS:0.50)	2	OPT
11	12140-89L10-050	.RING SET, PISTON	2	OPT



FIG.120A




FIG.120A (1-B-5) TIMING BELT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12631-89L10	PULLEY, CRANKSHAFT (NT:17)	1	
2	12635-89L00	GUIDE, TIMING BELT	1	
3	12636-89L00	GUIDE, TIMING BELT (LOWER)	1	
4	12637-89L00	NUT, TIMING PULLEY	1	
5	12638-89L00	WASHER, PULLEY NUT LOCK	1	
6	12741-89L00	PULLEY, CAMSHAFT (NT:34)	1	
7	09103-06267	BOLT (6X18)	1	
8	09160-06171	WASHER (6.5X24X4)	1	
9	08341-31039	KEY	1	
10	08341-31039	KEY	1	
11	12625-89L01	BASE, STATOR	1	
12	04211-09149	PIN	2	
13	01550-0625C	BOLT	2	
14	01550-06357	BOLT	2	
15	02122-04127	SCREW	3	
16	12761-93EL0	BELT, TIMING	1	
17	12744-89L00	PLATE, SENSING	1	



FIG.121A




FIG.121A (1-B-6) CAMSHAFT (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121B




FIG.121B (1-B-7) CAMSHAFT (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121C




FIG.121C (1-B-8) CAMSHAFT (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121D




FIG.121D (1-B-9) CAMSHAFT (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121E




FIG.121E (1-B-10) CAMSHAFT (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121F




FIG.121F (1-B-11) CAMSHAFT (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121G




FIG.121G (1-B-12) CAMSHAFT (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121H




FIG.121H (1-B-13) CAMSHAFT (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121J




FIG.121J (1-B-14) CAMSHAFT (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	12700-89L01	CAMSHAFT ASSY	1	W/MANUAL STARTER
1-2	12700-89L21	CAMSHAFT ASSY	1	W/ELECTRIC STARTER
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121K




FIG.121K (1-B-15) CAMSHAFT (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121L




FIG.121L (1-C-2) CAMSHAFT (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.121M




FIG.121M (1-C-3) CAMSHAFT (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.126A




FIG.126A (1-C-4) INLET MANIFOLD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126B




FIG.126B (1-C-5) INLET MANIFOLD (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126C




FIG.126C (1-C-6) INLET MANIFOLD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126D




FIG.126D (1-C-7) INLET MANIFOLD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126E




FIG.126E (1-C-8) INLET MANIFOLD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126F




FIG.126F (1-C-9) INLET MANIFOLD (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126G




FIG.126G (1-C-10) INLET MANIFOLD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126H




FIG.126H (1-C-11) INLET MANIFOLD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126J




FIG.126J (1-C-12) INLET MANIFOLD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126K




FIG.126K (1-C-13) INLET MANIFOLD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126L




FIG.126L (1-C-14) INLET MANIFOLD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.126M




FIG.126M (1-C-15) INLET MANIFOLD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L00	SILENCER	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	



FIG.144A





FIG.144A (1-D-2) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-89L00	HOSE, FUEL(PUMP TO DLVY)	1	
2	15710-50M00	INJECTOR ASSY, FUEL	2	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	2	
4	15734-89L00	SPACER, DELIVERY PIPE	1	
5	15735-89L00	INSULATOR, DELIVERY PIPE	1	
6	15751-89L00	PIPE, DELIVERY	1	
7	09320-08062	CUSHION	2	
8	09401-11425	CLIP	2	
9	01550-0650C	BOLT	2	



FIG.146A



DF20A_P01_017_146A
FUEL PUMP

FIG.146A (1-D-3) FUEL PUMP (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_017

DF20A_P01_017_146A
FUEL PUMP



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146B





FIG.146B (1-D-5) FUEL PUMP (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146C






FIG.146C (1-D-7) FUEL PUMP (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146D




DF20A_P01_017_146D
FUEL PUMP

FIG.146D (1-D-9) FUEL PUMP (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_017



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146E





FIG.146E (1-D-11) FUEL PUMP (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146F




FIG.146F (1-D-13) FUEL PUMP (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

FIG.146F




FIG.146F (1-D-14) FUEL PUMP (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146G




FIG.146G (1-D-15) FUEL PUMP (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

FIG.146G





FIG.146G (1-E-2) FUEL PUMP (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146H




DF20A_P01_017_146H
FUEL PUMP

FIG.146H (1-E-3) FUEL PUMP (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_017



REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146J





FIG.146J (1-E-5) FUEL PUMP (DF20A P40)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L10	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146K



DF20A_P01_017_146K
FUEL PUMP

FIG.146K (1-E-7) FUEL PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

DF20A_P01_017

FIG.146K




FIG.146K (1-E-8) FUEL PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146L




FIG.146L (1-E-9) FUEL PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	

FIG.146L




FIG.146L (1-E-10) FUEL PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.146M





FIG.146M (1-E-11) FUEL PUMP (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JC0	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L00	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L20	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

FIG.160A




FIG.160A (1-E-13) WATER PUMP (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160B




FIG.160B (1-E-14) WATER PUMP (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160C




FIG.160C (1-E-15) WATER PUMP (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160D (1-F-2) WATER PUMP (DF15A P01)




FIG.160E




FIG.160E (1-F-3) WATER PUMP (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160F




FIG.160F (1-F-4) WATER PUMP (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160G




FIG.160G (1-F-5) WATER PUMP (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160H




FIG.160H (1-F-6) WATER PUMP (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160J




FIG.160J (1-F-7) WATER PUMP (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J10	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J10	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J11	KIT, WATER PUMP REPAIR	1	OPT

FIG.160K




FIG.160K (1-F-8) WATER PUMP (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160L




FIG.160L (1-F-9) WATER PUMP (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.160M




FIG.160M (1-F-10) WATER PUMP (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J01	KIT, WATER PUMP REPAIR	1	OPT

FIG.162A




FIG.162A (1-F-11) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17670-91J00	THERMOSTAT (50C)	1	
2	17680-89L00	COVER, THERMOSTAT	1	
3	01550-0620C	BOLT	3	
4	17712-89L10	HOSE, WATER (COOLER TO HOUSING)	1	
5	17712-89L00	HOSE, WATER (HOUSING TO COOLER)	1	
6	09401-08413	CLIP	4	
7	17685-89L00	SEAL, THERMOSTAT COVER	1	
8	18498-94J20	PROTECTOR,FUEL HOSE (L:320)	1	L:320->50
9	09408-00070	CLAMP	1	

FIG.163A




FIG.163A (1-F-12) THROTTLE BODY (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	

FIG.163B




FIG.163B (1-F-13) THROTTLE BODY (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163C




FIG.163C (1-F-14) THROTTLE BODY (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163D




FIG.163D (1-F-15) THROTTLE BODY (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	



FIG.163E




FIG.163E (1-G-2) THROTTLE BODY (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163F




FIG.163F (1-G-3) THROTTLE BODY (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163G




FIG.163G (1-G-4) THROTTLE BODY (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	

FIG.163H




FIG.163H (1-G-5) THROTTLE BODY (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	

FIG.163J




FIG.163J (1-G-6) THROTTLE BODY (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	

FIG.163K




FIG.163K (1-G-7) THROTTLE BODY (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163L




FIG.163L (1-G-8) THROTTLE BODY (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	01550-0620C	BOLT	2	

FIG.163M




FIG.163M (1-G-9) THROTTLE BODY (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	15211-91J00-130	HOSE, IAC	1	
7	09403-12406	CLAMP	1	
8	01550-0612C	BOLT	1	
9	01550-0620C	BOLT	2	

FIG.166A




FIG.166A (1-G-10) THROTTLE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166B




FIG.166B (1-G-11) THROTTLE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166C




FIG.166C (1-G-12) THROTTLE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166D




FIG.166D (1-G-13) THROTTLE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166E




FIG.166E (1-G-14) THROTTLE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



FIG.166F




FIG.166F (1-G-15) THROTTLE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06012	CLIP	1	



[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167B




FIG.167B (1-H-3) RECOIL STARTER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167D




FIG.167D (1-H-5) RECOIL STARTER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167E




FIG.167E (1-H-6) RECOIL STARTER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

This exploded view diagram illustrates the components of a car stereo unit and their assembly sequence, indicated by numbers 1 through 15. The components include:

- 1**: The main stereo unit housing.
- 2**: The front faceplate.
- 3**: A sub-assembly containing a spring, a small bracket, and a circular component.
- 4**: A circular speaker grille.
- 5**: A small screw.
- 6**: Two rectangular mounting brackets.
- 7**: A rectangular component, likely a display or control panel.
- 8**: A small bracket or clip.
- 9**: A screw for securing the front faceplate.
- 10**: A long antenna wire with a coiled end.
- 11**: A screw for securing the main unit.
- 12**: A screw for securing the main unit.
- 13**: A rectangular component, possibly a display or control panel.
- 14**: A small screw.
- 15**: A small connector or plug.

The diagram also includes a warning symbol (a triangle with an exclamation mark) and a note indicating that the stereo unit should be installed in a vehicle with a power window.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167G




FIG.167G (1-H-8) RECOIL STARTER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.167H




FIG.167H (1-H-9) RECOIL STARTER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167J




FIG.167J (1-H-10) RECOIL STARTER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167K




FIG.167K (1-H-11) RECOIL STARTER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

FIG.167L (1-H-12) RECOIL STARTER (DF20AT P01)



DF20A_P01_017_167L
RECOIL STARTER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

FIG.175A




FIG.175A (1-H-14) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-89L00	PUMP ASSY, OIL	1	
2	16510-45H10	FILTER, ENGINE OIL	1	
3	16512-99J00	CAP, OIL FILTER	1	
4	09280-13004	O RING (D:1.9,ID:13)	1	
5	09280-54001	O RING (D:2.4,ID:52.6)	1	
6	09440-18002	SPRING	1	
7	01550-0620C	BOLT	3	
8	01550-0612C	BOLT	1	
9	16910-89L01	GAUGE, OIL LEVEL	1	
10	16930-89L01	GUIDE, OIL LEVEL GAUGE	1	
11	09280-09008	O RING (D:2.1,ID:8.8)	1	
12	16431-89L00	BLOCK, OIL GALLERY	1	
13	59262-94J00	PIN, OIL PUMP	1	
14	02122-0630A	SCREW	3	




FIG.206A (1-H-15) CLUTCH ROD (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L)
				W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	

FIG.206B (1-I-2) CLUTCH ROD (DF9.9BR P01)

DF20A_P01_017

FIG.206C




FIG.206C (1-I-3) CLUTCH ROD (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	

FIG.206D




FIG.206D (1-I-4) CLUTCH ROD (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206E




FIG.206E (1-1-5) CLUTCH ROD (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	



FIG.206F




FIG.206F (1-I-6) CLUTCH ROD (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	

FIG.206G




FIG.206G (1-I-7) CLUTCH ROD (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206H




FIG.206H (1-I-8) CLUTCH ROD (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206J




FIG.206J (1-I-9) CLUTCH ROD (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	



FIG.206K




FIG.206K (1-I-10) CLUTCH ROD (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	

FIG.206L




FIG.206L (1-1-11) CLUTCH ROD (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06012	CLIP	1	
21	67340-89L00	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	

FIG.206M




FIG.206M (1-I-12) CLUTCH ROD (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L00	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	

FIG.210A




FIG.210A (1-I-13) SHIFT ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	23311-95J00	CONNECTOR, CLUTCH ROD	1	
2-1	25111-99J01	ROD, SHIFT (S & L)	1	W/TRANSOM(S) W/TRANSOM(L)
2-2	25111-99J10	ROD, SHIFT (X)	1	W/TRANSOM(X)
3	25311-99J00	CAM, SHIFT	1	
4	09205-02004	SPRING PIN (2.5X12)	2	
5	25211-99JL0	GUIDE, SHIFT ROD	1	
6	25215-99J00	STOPPER, SHIFT ROD GUIDE	1	
7	29141-93J00	NUT, CLUTCH ROD (M6)	1	
8	09160-06082	WASHER (6.5X13X1.0)	1	
9	09280-06012	O RING (D:1.7,ID:5.8)	2	
10	09280-09012	O RING (D:2.3,ID:9)	1	
11	09289-06L02	DUST SEAL (5X17X3.5)	1	



[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

Exploded view diagram of a front wheel hub assembly. The diagram shows the main shaft assembly (1) with various seals (2, 3, 4, 5, 6, 7), a bearing (8), a hub (9), a gear (10), a pinion (11), a spring (12), a nut (13), a washer (14), a pin (15), a pinion (16), a spring (17), a nut (18), a washer (19), a pin (20), a pinion (21), a gear (22), a pinion (23), and a pin (24). A 'FWD' arrow indicates the front of the vehicle.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

Exploded view diagram of a front wheel hub assembly. The main shaft assembly (1) is shown with various seals (2, 3, 4, 5, 6, 7, 8), a bearing (9), a gear (10), a pin (11), a spring (12), a pin (13), a pin (14), a pin (15), a pin (16), a pin (17), a pin (18), a pin (19), a pin (20), a pin (21), a pin (22), a pin (23), and a pin (24). A 'FWD' arrow points to the left.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220B




FIG.220B (1-J-3) TRANSMISSION (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

Exploded view diagram of a front wheel hub assembly. The diagram shows the main shaft assembly (1) with various components labeled 1 through 24. A detailed view of the hub assembly (21) is shown in the upper right, including the hub (22), a bolt (24), and a flange (23). The lower right shows the wheel assembly (10, 11, 12) and the axle (14) with a spring (17) and a nut (18). A 'FWD' arrow indicates the front of the vehicle.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

Exploded view diagram of a front wheel hub assembly. The diagram shows the hub (1) with various seals (2, 3, 4, 5, 6, 7, 8), a bearing (9), a gear (10), a pinion (11), a spring (12), a pin (13), a nut (14), a washer (15), a pin (16), a pin (17), a pin (18), a pin (19), a pin (20), a pin (21), a pin (22), a pin (23), and a pin (24). A 'FWD' arrow points to the left.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	


This exploded view diagram illustrates the assembly of a front wheel hub. The components are numbered as follows:

- 1**: Main hub shaft assembly.
- 2**: Upper hub bearing.
- 3**: Upper hub seal.
- 4**: Lower hub seal.
- 5**: Lower hub seal.
- 6**: Lower hub seal.
- 7**: Lower hub seal.
- 8**: Lower hub seal.
- 9**: Lower hub seal.
- 10**: Lower hub seal.
- 11**: Lower hub seal.
- 12**: Lower hub seal.
- 13**: Lower hub seal.
- 14**: Lower hub seal.
- 15**: Lower hub seal.
- 16**: Lower hub seal.
- 17**: Lower hub seal.
- 18**: Lower hub seal.
- 19**: Lower hub seal.
- 20**: Lower hub seal.
- 21**: Lower hub seal.
- 22**: Lower hub seal.
- 23**: Lower hub seal.
- 24**: Lower hub seal.

The diagram also includes a "FWD" arrow pointing to the left, indicating the front of the vehicle.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220G



DF20A_P01_017_220G
TRANSMISSION

FIG.220G (1-J-13) TRANSMISSION (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.220J





FIG.220J (1-K-2) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220J



DF20A_P01_017_220J
TRANSMISSION


FIG.220J (1-K-3) TRANSMISSION (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV
11-7	09160-17027	WASHER (T:1.7)	1	REV
11-8	09160-17042	WASHER (T:1.8)	1	REV
11-9	09160-17028	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220K



DF20A_P01_017_220K
TRANSMISSION


FIG.220K (1-K-5) TRANSMISSION (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

FIG.220L



DF20A_P01_017_220L
TRANSMISSION

FIG.220L (1-K-7) TRANSMISSION (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_017

FIG.220M




FIG.220M (1-K-8) TRANSMISSION (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-98501	PIN (6X6)	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

FIG.301A




FIG.301A (1-K-10) STARTING MOTOR (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-94J22	STARTING MOTOR	1	
2	31131-94J00	.BRUSH SET, PLUS	1	
3	31135-90J00	.SPRING	4	
4	31151-94J01	.CASE, GEAR	1	
5	31152-90J00	.PLATE, CENTER	1	
6	31153-90J00	.BRACKET, PLANET GEAR	1	
7	31171-96J00	.COVER KIT, DUST	1	
8	31173-94J01	.HOLDER ASSY, BRUSH	1	
9	31191-96J00	.LEVER, SHIFT	1	
10	31220-94J00	.SWITCH, MAGNET	1	
11	31310-90J00	.ARMATURE	1	
12	31320-94J00	.PINION	1	
13	31341-94J00	.SHAFT, PINION	1	
14	31343-90J00	.INTERNAL GEAR	1	
15	31344-90J00	.GEAR, PLANETARY	3	
16	31360-93J01	.WASHER SET	1	
17	31170-94J00	.COVER ASSY, STATER MOTOR REAR	1	
18	31912-89L00	BAND, STARTING MOTOR	1	
19	31918-94J00	DAMPER, LOWER	1	
20	38860-76F01	RELAY, STARTING MOTOR	1	
21	38915-90J00	HOLDER, RELAY	1	
22	01550-08207	BOLT	2	LOWER
23	01550-08307	BOLT	2	
24	08316-10087	NUT	1	

FIG.303A

FIG.303A (1-K-11) MAGNETO (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303B




FIG.303B (1-K-12) MAGNETO (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	



FIG.303C

FIG.303C (1-K-13) MAGNETO (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303D

FIG.303D (1-K-14) MAGNETO (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	




FIG.303E

FIG.303E (1-K-15) MAGNETO (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L00	COIL, STATOR & PULSER	1	
2	01547-0625A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	




FIG.310A

FIG.310A (1-L-2) RECTIFIER/IGNITION COIL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13-1	33920-89LC0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LD0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	




FIG.310B

FIG.310B (1-L-3) RECTIFIER/IGNITION COIL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89LC0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310C

FIG.310C (1-L-4) RECTIFIER/IGNITION COIL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89LC0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310D

FIG.310D (1-L-5) RECTIFIER/IGNITION COIL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13-1	33920-89L80	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89L90	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	




FIG.310E

FIG.310E (1-L-6) RECTIFIER/IGNITION COIL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310F

FIG.310F (1-L-7) RECTIFIER/IGNITION COIL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310G

FIG.310G (1-L-8) RECTIFIER/IGNITION COIL (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89L80	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310H

FIG.310H (1-L-9) RECTIFIER/IGNITION COIL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13-1	33920-89LA0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LB0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	




FIG.310J




FIG.310J (1-L-10) RECTIFIER/IGNITION COIL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	W/ELECTRIC STARTER
8	01550-06167	BOLT	1	W/ELECTRIC STARTER
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13-1	33920-89LE0	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
13-2	33920-89LF0	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
16	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
17	09160-06168	WASHER (6X14X1)	1	



FIG.310K

FIG.310K (1-L-11) RECTIFIER/IGNITION COIL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310L

FIG.310L (1-L-12) RECTIFIER/IGNITION COIL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.310M

FIG.310M (1-L-13) RECTIFIER/IGNITION COIL (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06196	BOLT (6X20)	2	
4	32890-89L01	HOLDER, ELECTRIC PARTS	1	
5	09169-06063	WASHER	2	
6	09320-08051	CUSHION	2	
7	01550-06207	BOLT	2	
8	01550-06167	BOLT	1	
9	33500-07H00	CAP, SPARK PLUG	2	
10	09408-00159	CLAMP	2	
11	33410-89L10	COIL, IGNITION	1	
12	01550-0630C	BOLT	2	
13	33920-89LA0	UNIT, ENGINE CONTROL	1	
14	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
15	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
16	38915-90J00	HOLDER, RELAY	1	
17	09160-06168	WASHER (6X14X1)	1	




FIG.322A




FIG.322A (1-L-14) HARNESS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-0616C	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L60	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L70	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10-1	09407-14407	CLAMP (L:145)	4	W/ELECTRIC STARTER
10-2	09407-14407	CLAMP (L:145)	5	W/MANUAL STARTER
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	

FIG.322B




FIG.322B (1-L-15) HARNESS (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L80	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322C




FIG.322C (2-B-2) HARNESS (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89LA0	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
18-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322D




FIG.322D (2-B-3) HARNESS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-0616C	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L60	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L70	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10-1	09407-14407	CLAMP (L:145)	4	W/ELECTRIC STARTER
10-2	09407-14407	CLAMP (L:145)	5	W/MANUAL STARTER
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	

FIG.322E




FIG.322E (2-B-4) HARNESS (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L80	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322F




FIG.322F (2-B-5) HARNESS (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89LA0	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
18-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322G




FIG.322G (2-B-6) HARNESS (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-0616C	BOLT	2	
5	36610-89L90	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	

FIG.322H





FIG.322H (2-B-7) HARNESS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-0616C	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L60	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L70	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10-1	09407-14407	CLAMP (L:145)	4	W/ELECTRIC STARTER
10-2	09407-14407	CLAMP (L:145)	5	W/MANUAL STARTER
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-0616C	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89L60	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
5-2	36610-89L70	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10-1	09407-14407	CLAMP (L:145)	4	W/ELECTRIC STARTER
10-2	09407-14407	CLAMP (L:145)	5	W/MANUAL STARTER
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	

FIG.322K




FIG.322K (2-B-9) HARNESS (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89L80	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00008	CLIP (ID:20)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	2	
16	01550-06127	BOLT	1	
17-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
17-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322L




FIG.322L (2-B-10) HARNESS (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	36610-89LA0	HARNESS ASSY, WIRING	1	
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	2	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L30	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00296	CLAMP	1	
14	09408-00297	CLAMP	1	
15	01550-0612C	BOLT	4	
16	01550-06127	BOLT	1	
17	36617-89L40	BRACKET, HARNESS	1	
18-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
18-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000

FIG.322M




FIG.322M (2-B-11) HARNESS (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L02	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-0616C	BOLT	2	
5	36610-89L90	HARNESS ASSY, WIRING	1	
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	2	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L30	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00008	CLIP (ID:20)	1	
18	09408-00252	CLAMP	1	
19	09408-00297	CLAMP	1	
20	01550-0612C	BOLT	4	
21	01550-06127	BOLT	1	
22	36617-89L40	BRACKET, HARNESS	1	

FIG.327A




FIG.327A (2-B-12) PTT SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06517	BOLT (6X25)	2	
5	09169-06062	WASHER	2	



FIG.327B




FIG.327B (2-B-13) PTT SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06517	BOLT (6X25)	2	
5	09169-06062	WASHER	2	



FIG.327C




FIG.327C (2-B-14) PTT SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA3	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06517	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.327D




FIG.327D (2-B-15) PTT SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E04	SWITCH ASSY, PTT	1	
4	09116-06517	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

FIG.327E




FIG.327E (2-C-2) PTT SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J20	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA3	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06517	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

FIG.334A




FIG.334A (2-C-3) SENSOR/SWITCH (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

FIG.334B




FIG.334B (2-C-4) SENSOR/SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	



FIG.334C




FIG.334C (2-C-5) SENSOR/SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	



FIG.334D




FIG.334D (2-C-6) SENSOR/SWITCH (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

FIG.334E




FIG.334E (2-C-7) SENSOR/SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	

FIG.334F




FIG.334F (2-C-8) SENSOR/SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	



FIG.334G




FIG.334G (2-C-9) SENSOR/SWITCH (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	

FIG.334H




FIG.334H (2-C-10) SENSOR/SWITCH (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

FIG.334J




FIG.334J (2-C-11) SENSOR/SWITCH (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L03	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

FIG.334K




FIG.334K (2-C-12) SENSOR/SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	

FIG.334L




FIG.334L (2-C-13) SENSOR/SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37163-89L00	PLUG, STARTING SWITCH HOLE	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	



FIG.334M





FIG.334M (2-C-14) SENSOR/SWITCH (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-80002	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00	LABEL, WARNING	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L03	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L01	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	

FIG.335A




DF20A_P01_017_335A
CLAMP BRACKET

FIG.335A (2-C-15) CLAMP BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335B



DF20A_P01_017_335B
CLAMP BRACKET

FIG.335B (2-D-2) CLAMP BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335C





FIG.335C (2-D-3) CLAMP BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335D




DF20A_P01_017_335D
CLAMP BRACKET

FIG.335D (2-D-4) CLAMP BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335E



DF20A_P01_017_335E
CLAMP BRACKET

FIG.335E (2-D-5) CLAMP BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335F





FIG.335F (2-D-6) CLAMP BRACKET (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335G




DF20A_P01_017_335G
CLAMP BRACKET

FIG.335G (2-D-7) CLAMP BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

DF20A_P01_017

FIG.335H




DF20A_P01_017_335H
CLAMP BRACKET

FIG.335H (2-D-8) CLAMP BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335J




DF20A_P01_017_335J
CLAMP BRACKET

FIG.335J (2-D-9) CLAMP BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335K



DF20A_P01_017_335K
CLAMP BRACKET

FIG.335K (2-D-10) CLAMP BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	09306-22006	BUSH (22.6X27X8)	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L00	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

FIG.335L





FIG.335L (2-D-11) CLAMP BRACKET (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

FIG.335M



DF20A_P01_017_335M
CLAMP BRACKET

FIG.335M (2-D-12) CLAMP BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-95J00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

DF20A_P01_017

FIG.336A




FIG.336A (2-D-13) SWIVEL BRACKET (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	


Exploded view diagram of a bicycle rear wheel assembly. The diagram shows the following components and their assembly sequence:

- Hub and Spokes:** The central hub (1) is connected to the spokes (2) which are attached to the rim (3).
- Rim and Tire:** The rim (3) is shown with a tire (4) mounted on it. The tire is secured by a tire cap (5) and a tire cap nut (6).
- Adjustment Components:** The rear wheel assembly includes a rear axle (7) with a rear axle nut (8) and a rear axle cap (9). The rear axle is secured by a rear axle nut (10) and a rear axle cap (11).
- Brake and Cable Components:** The rear wheel assembly includes a rear brake (12) with a rear brake cable (13) and a rear brake cable adjuster (14).
- Other Components:** The diagram also shows a rear fender (15), a rear fender bracket (16), a rear fender cap (17), a rear fender cap nut (18), a rear fender cap washer (19), a rear fender cap spacer (20), a rear fender cap nut (21), a rear fender cap washer (22), a rear fender cap nut (23), a rear fender cap washer (24), a rear fender cap nut (25), a rear fender cap washer (26), a rear fender cap nut (27), a rear fender cap washer (28), a rear fender cap nut (29), a rear fender cap washer (30), a rear fender cap nut (31), a rear fender cap washer (32), a rear fender cap nut (33), a rear fender cap washer (34), a rear fender cap nut (35), a rear fender cap washer (36), and a rear fender cap nut (37).

A "FWD" arrow is located in the bottom left corner of the diagram.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

DF20A_P01_017_336B
SWIVEL BRACKET



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	W/TRANSOM(X)
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

FIG.336B




FIG.336B (2-E-2) SWIVEL BRACKET (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336C




FIG.336C (2-E-3) SWIVEL BRACKET (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)



FIG.336D (2-E-4) SWIVEL BRACKET (DF15A P01)




FIG.336D





FIG.336D (2-E-5) SWIVEL BRACKET (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336E



DF20A_P01_017_336E
SWIVEL BRACKET

FIG.336E (2-E-6) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

DF20A_P01_017

FIG.336E




FIG.336E (2-E-7) SWIVEL BRACKET (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336F




FIG.336F (2-E-8) SWIVEL BRACKET (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
21	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.336G




FIG.336G (2-E-9) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336G





FIG.336G (2-E-10) SWIVEL BRACKET (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)



FIG.336H




DF20A_P01_017_336H
SWIVEL BRACKET

FIG.336H (2-E-11) SWIVEL BRACKET (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

DF20A_P01_017

DF20A_P01_017_336H
SWIVEL BRACKET



DF20A_P01_017

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336J




FIG.336J (2-E-13) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	

FIG.336J (2-E-14) SWIVEL BRACKET (DF20A P40)





FIG.336K



DF20A_P01_017_336K
SWIVEL BRACKET

FIG.336K (2-E-15) SWIVEL BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L) W/TRANSOM(X)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
28	09160-08082	WASHER (8.5X16X1.2)	2	
29	09108-08286	STUD BOLT	2	

DF20A_P01_017

FIG.336K




FIG.336K (2-F-2) SWIVEL BRACKET (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	09159-08059	NUT	2	
31	43759-89L00	HOLDER, DRAIN HOSE	1	
32	09116-06225	BOLT (6X15)	1	

FIG.336L (2-F-3) SWIVEL BRACKET (DF20AT P01)

DF20A_P01_017

FIG.336M




FIG.336M (2-F-4) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L00	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	

FIG.336M





FIG.336M (2-F-5) SWIVEL BRACKET (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

FIG.338A




DF20A_P01_017_338A
TILT CYLINDER

FIG.338A (2-F-6) TILT CYLINDER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA1	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA1	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

FIG.338B




DF20A_P01_017_338B
TILT CYLINDER

FIG.338B (2-F-7) TILT CYLINDER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA1	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA1	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

FIG.338C




DF20A_P01_017_338C
TILT CYLINDER

FIG.338C (2-F-8) TILT CYLINDER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA1	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA1	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_017

FIG.338D



DF20A_P01_017_338D
TILT CYLINDER

FIG.338D (2-F-9) TILT CYLINDER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA1	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA1	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF20A_P01_017

FIG.338E




FIG.338E (2-F-10) TILT CYLINDER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA1	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	..O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA1	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

FIG.340A




FIG.340A (2-F-11) PTT MOTOR (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA1	MOTOR ASSY, PTT	1	
2	31174-89LA0	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340B




FIG.340B (2-F-12) PTT MOTOR (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA1	MOTOR ASSY, PTT	1	
2	31174-89LA0	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340C




FIG.340C (2-F-13) PTT MOTOR (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA1	MOTOR ASSY, PTT	1	
2	31174-89LA0	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	



FIG.340D




FIG.340D (2-F-14) PTT MOTOR (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA1	MOTOR ASSY, PTT	1	
2	31174-89LA0	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.340E




FIG.340E (2-F-15) PTT MOTOR (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA1	MOTOR ASSY, PTT	1	
2	31174-89LA0	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94900	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

FIG.401A




FIG.401A (2-G-2) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-89L02	HOLDER, ENGINE	1	
2	51211-89L00	GASKET, ENGINE HOLDER	1	
3	09116-08151	BOLT (8X30)	3	
4	09202-06023	PIN (6X10)	2	
5	09282-12L04	OIL SEAL (12X25X7)	1	
6	16515-89L10	HOSE, OIL	1	
7	54112-99J01	BOLT, UPR MOUNT (L:123)	2	
8	54113-99JM0	WASHER, UPPER MOUNT BOLT	2	
9	54127-89L00	MOUNT, UPRER SIDE	1	
10	54125-99J00	STOPPER, UPR REVERSE THRUST	2	
11	54130-89L00	MOUNT, UPPER	2	
12	54137-89L00	COVER, UPPER MOUNT	2	
13	09116-08137	BOLT (8X22)	4	
14	09140-10031	NUT	2	
15	01560-08307	BOLT	7	
16	09401-12413	CLIP	1	
17	16520-99J00	STRAINER, OIL	1	
18	09401-13424	CLIP	1	

FIG.405A




FIG.405A (2-G-3) DRIVE SHAFT HOUSING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-89L00-YAY	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-89L10-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4	43112-99E00	.PIPE, EXHAUST	1	
5	52113-89L00	GASKET, DRIVE SHAFT HOUSING	1	
6	09116-08151	BOLT (8X30)	6	
7	09202-06023	PIN (6X10)	2	
8	09168-12017	GASKET (12X17X1)	1	
9	09248-12009	PLUG (12X18.65)	1	
10	54151-99J00	MOUNT, LOWER THRUST	1	
11	54167-99J01	MOUNT, LOWER SIDE	2	
12	54211-99J01-YAY	COVER, LWR MOUNT STBD (BLACK)	1	
13	54221-99J01-YAY	COVER, LWR MOUNT PORT (BLACK)	1	
14	54213-93901	PIN, KNOCK	2	
15	09116-08154	BOLT (8X40)	2	
16	52131-89L00-YAY	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
17	09116-08151	BOLT (8X30)	4	W/TRANSOM(X)
18	09320-13022	BUSH	1	W/TRANSOM(X)

FIG.407A




FIG.407A (2-G-4) GEAR CASE (3 BLADE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	
15-3	58100-89L60-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L70-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-89L50-019	PROPELLER, 3X9-1/4X12 (M1201) (BLACK)	1	
15-6	58100-90L40-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-7	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-8	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	

FIG.407A




FIG.407A (2-G-5) GEAR CASE (3 BLADE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55321-87J11	ANODE (MAGNESIUM)	1	OPT

FIG.407B




FIG.407B (2-G-6) GEAR CASE (4 BLADE)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15	58100-94JB0-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

FIG.410A





FIG.410A (2-G-7) SIDE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410B



DF20A_P01_017_410B
SIDE COVER

FIG.410B (2-G-8) SIDE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410C




FIG.410C (2-G-9) SIDE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410D




FIG.410D (2-G-10) SIDE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410E




FIG.410E (2-G-11) SIDE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410F




FIG.410F (2-G-12) SIDE COVER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410G




FIG.410G (2-G-13) SIDE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410H




FIG.410H (2-G-14) SIDE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

Exploded view diagram of a car's front end assembly, showing various components and their assembly order. The diagram includes a large front bumper (1), a smaller bumper (2), a grille (3), a hood (4), and various fasteners (5-22). A 'FWD' (Front Wheel Drive) label is visible in the bottom left corner.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410K




FIG.410K (2-H-2) SIDE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L20	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410L




FIG.410L (2-H-3) SIDE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L10-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L30	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.410M




FIG.410M (2-H-4) SIDE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09136-06169	SCREW (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09136-06168	SCREW (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04003	CLIP	1	
22	09403-07308	CLAMP	2	
23	17917-87LL0	CONNECTOR, FLUSH WATER	1	

FIG.420A




FIG.420A (2-H-5) ENGINE COVER (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L10	MARK, EMBLEM REAR (9.9)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420B




FIG.420B (2-H-6) ENGINE COVER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L10	MARK, EMBLEM REAR (9.9)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420C




FIG.420C (2-H-7) ENGINE COVER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L10	MARK, EMBLEM REAR (9.9)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	61447-89L00	MARK, EMBLEM POWER TILT	1	
16	68110-89L00	COVER, WEATHER	1	OPT

FIG.420D




FIG.420D (2-H-8) ENGINE COVER (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L20	MARK, EMBLEM REAR (15)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420E





FIG.420E (2-H-9) ENGINE COVER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L20	MARK, EMBLEM REAR (15)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420F



DF20A_P01_017_420F
ENGINE COVER

FIG.420F (2-H-10) ENGINE COVER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L20	MARK, EMBLEM REAR (15)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	61447-89L00	MARK, EMBLEM POWER TILT	1	
16	68110-89L00	COVER, WEATHER	1	OPT

DF20A_P01_017

FIG.420G




FIG.420G (2-H-11) ENGINE COVER (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L20	MARK, EMBLEM REAR (15)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	61447-89L00	MARK, EMBLEM POWER TILT	1	
16	68110-89L00	COVER, WEATHER	1	OPT

FIG.420H




FIG.420H (2-H-12) ENGINE COVER (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L30	MARK, EMBLEM REAR (20)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420J




FIG.420J (2-H-13) ENGINE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L30	MARK, EMBLEM REAR (20)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420K




FIG.420K (2-H-14) ENGINE COVER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L30	MARK, EMBLEM REAR (20)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	68110-89L00	COVER, WEATHER	1	OPT

FIG.420L




FIG.420L (2-H-15) ENGINE COVER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L30	MARK, EMBLEM REAR (20)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	61447-89L00	MARK, EMBLEM POWER TILT	1	
16	68110-89L00	COVER, WEATHER	1	OPT

FIG.420M




FIG.420M (2-I-2) ENGINE COVER (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61443-97L00	STRIPE, ENGINE COVER STBD	1	
7	61453-97L00	STRIPE, ENGINE COVER PORT	1	
8	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
9	61435-89L30	MARK, EMBLEM REAR (20)	1	
10	61446-89L10	DECAL, EFI	1	
11	61458-89L30	LABEL, ENGINE COVER	1	
12	61471-89L00	DECAL, LEAN BURN	1	
13	59800-89L01	TOOL ASSY	1	
14	99011-89L40-055	MANUAL, OWNER'S	1	
15	61447-89L00	MARK, EMBLEM POWER TILT	1	
16	68110-89L00	COVER, WEATHER	1	OPT

FIG.432A




FIG.432A (2-I-3) FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-89L10	TANK ASSY, FUEL (12L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65831-95D00	.FILTER, OUTLET	1	
5	65890-99100	.OUTLET	1	
6	65892-95D00	.O RING	1	
7	65740-95D01	.PLUG, FUEL CONNECTOR	1	
8	65700-89L30	HOSE, FUEL	1	
9	65750-87J11	.SOCKET, FUEL HOSE	1	
10	65750-95500	.SOCKET, FUEL HOSE	1	
11	65770-89L00	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	
13	65720-986L0	PLUG, FUEL CONNECTOR	1	
14	09103-06237	BOLT (6X12.5)	1	
15	09160-06085	WASHER (6.5X15X1)	1	

FIG.442A




FIG.442A (2-I-4) DRAG LINK (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442B




FIG.442B (2-1-5) DRAG LINK (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442C




FIG.442C (2-I-6) DRAG LINK (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442D




FIG.442D (2-I-7) DRAG LINK (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.442E




FIG.442E (2-I-8) DRAG LINK (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	



FIG.442F




FIG.442F (2-I-9) DRAG LINK (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.444A




FIG.444A (2-I-10) TILLER HANDLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444B




FIG.444B (2-I-11) TILLER HANDLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444C




FIG.444C (2-I-12) TILLER HANDLE (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444D




FIG.444D (2-I-13) TILLER HANDLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444E




FIG.444E (2-I-14) TILLER HANDLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.444F





FIG.444F (2-I-15) TILLER HANDLE (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L00-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06026	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05042	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L01	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J00	.NUT	1	
35	37835-95D00	LABEL, STOP	1	
36	21131-94J00	MARK, CLUTCH SHIFT	1	

FIG.450A



DF20A_P01_017_450A
REMOTE CONTROL

FIG.450A (2-J-2) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X20)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

DF20A_P01_017

FIG.450A





FIG.450A (2-J-3) REMOTE CONTROL (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

FIG.450B



DF20A_P01_017_450B
REMOTE CONTROL

FIG.450B (2-J-4) REMOTE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

FIG.450B





FIG.450B (2-J-5) REMOTE CONTROL (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

FIG.450C




DF20A_P01_017_450C
REMOTE CONTROL

FIG.450C (2-J-6) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X20)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

DF20A_P01_017

FIG.450C



DF20A_P01_017_450C
REMOTE CONTROL

FIG.450C (2-J-7) REMOTE CONTROL (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_017

FIG.450D





FIG.450D (2-J-8) REMOTE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

FIG.450D



DF20A_P01_017_450D
REMOTE CONTROL

FIG.450D (2-J-9) REMOTE CONTROL (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

DF20A_P01_017

FIG.450E





FIG.450E (2-J-10) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X20)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

FIG.450E



DF20A_P01_017_450E
REMOTE CONTROL

FIG.450E (2-J-11) REMOTE CONTROL (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-94J01	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	

DF20A_P01_017

FIG.450F




FIG.450F (2-J-12) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	
18	67229-95600	..ROLLER	1	
19	67232-95600	..BUSH	1	
20	67238-87D00	..GEAR, DRIVE	1	
21	67241-99E10	..LEVER, FREE THROTTLE	1	

FIG.450F




FIG.450F (2-J-13) REMOTE CONTROL (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-93J02	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	

FIG.501A




FIG.501A (2-J-14) OPT:METER (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	.ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.501B




FIG.501B (2-J-15) OPT:METER (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	.ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.501C




FIG.501C (2-J-15) OPT:METER (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.501D




FIG.501D (2-K-2) OPT:METER (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.501E




FIG.501E (2-K-3) OPT:METER (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	.ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.501F




FIG.501F (2-K-4) OPT:METER (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	34500-93J00	METER ASSY, HOUR	1	BLACK
1-2	34500-93J11	METER ASSY, HOUR	1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)	1	
3-1	34600-93J00	METER ASSY, VOLTAGE	1	BLACK
3-2	34600-93J11	METER ASSY, VOLTAGE	1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)	1	
5-1	34100-93J20	SPEEDOMETER ASSY	1	MAX 80KM/H BLACK
5-2	34100-93J31	SPEEDOMETER ASSY	1	MAX 80KM/H WHITE
5-3	34100-93J40	SPEEDOMETER ASSY	1	MAX 45KNOTS BLACK
5-4	34100-93J51	SPEEDOMETER ASSY	1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)	1	
7	34191-92E00	.TUBE	1	
8	09407-14407	.CLAMP (L:145)	2	
9	36615-96300	.TERMINAL, RESIN	2	
10	34190-95500	SENDER ASSY, SPEEDOMETER	1	
11	03112-0630B	.SCREW	2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER	1	
13-1	34200-93J20	TACHOMETER ASSY	1	BLACK
13-2	34200-93J32	TACHOMETER ASSY	1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)	1	
15-1	34300-93J00	GAUGE ASSY, FUEL	1	BLACK
15-2	34300-93J11	GAUGE ASSY, FUEL	1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE	1	
17	34360-92E00	.ADAPTER, FUEL GAUGE	1	
18	09471-12103	.BULB (12V,3W,T6.5)	1	

FIG.508A




FIG.508A (2-K-5) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X20)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

FIG.508A




FIG.508A (2-K-6) OPT:REMOTE CONTROL (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508B




FIG.508B (2-K-7) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X20)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

FIG.508B




FIG.508B (2-K-8) OPT:REMOTE CONTROL (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.508C




FIG.508C (2-K-9) OPT:REMOTE CONTROL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	..SPACER	1	
11	37864-94J10	..CAP, PTT SW	1	
12	38500-93J00	..BUZZER ASSY, WARNING	1	
13	67212-95600	..WASHER	1	
14	67214-92E00	..SCREW (5X20)	1	
15	67220-95630	..PLATE ASSY	1	
16	67223-99E10	..KNOB, BRAKE ADJUST	1	
17	67229-95600	..ROLLER	1	
18	67232-95600	..BUSH	1	
19	67238-87D00	..GEAR, DRIVE	1	

This exploded view diagram illustrates the assembly of a car stereo unit. The components are numbered as follows:

- 1**: Main stereo unit housing.
- 2**: Small metal bracket.
- 3**: Mounting plate.
- 4**: Mounting screw.
- 5**: Mounting bracket.
- 6**: Mounting plate.
- 7**: Mounting bracket.
- 8**: Mounting screw.
- 9**: Mounting bracket.
- 10**: Mounting screw.
- 11**: Mounting bracket.
- 12**: Antenna cable.
- 13**: Mounting screw.
- 14**: Antenna cable.
- 15**: Mounting bracket.
- 16**: Mounting screw.
- 17**: Mounting bracket.
- 18**: Mounting screw.
- 19**: Mounting bracket.
- 20**: Mounting screw.
- 21**: Mounting bracket.
- 22**: Mounting screw.
- 23**: Mounting bracket.
- 24**: Mounting bracket.
- 25**: Mounting screw.
- 26**: Mounting bracket.
- 27**: Mounting screw.
- 28**: Mounting bracket.
- 29**: Mounting bracket.
- 30**: Mounting screw.
- 31**: Mounting screw.
- 32**: Mounting bracket.
- 33**: Mounting screw.
- 34**: Mounting bracket.
- 35**: Mounting screw.
- 36**: Mounting bracket.
- 37**: Mounting screw.
- 38**: Mounting bracket.
- 39**: Mounting bracket.
- 40**: Mounting screw.
- 41**: Mounting bracket.
- 42**: Mounting bracket.
- 43**: Mounting screw.
- 44**: Mounting screw.
- 45**: Mounting bracket.
- 46**: Mounting bracket.
- 47**: Mounting bracket.
- 48**: Mounting screw.
- 49**: Mounting bracket.
- 50**: Mounting bracket.
- 51**: Mounting bracket.

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

This exploded view diagram illustrates the assembly of a car stereo unit. The components are numbered as follows:

- 1**: Main stereo unit housing.
- 2**: Small metal bracket.
- 3**: Mounting plate.
- 4**: Mounting screw.
- 5**: Mounting bracket.
- 6**: Mounting plate.
- 7**: Mounting bracket.
- 8**: Mounting screw.
- 9**: Mounting bracket.
- 10**: Mounting screw.
- 11**: Mounting bracket.
- 12**: Antenna cable.
- 13**: Mounting screw.
- 14**: Antenna cable connector.
- 15**: Mounting bracket.
- 16**: Mounting screw.
- 17**: Mounting bracket.
- 18**: Mounting screw.
- 19**: Mounting bracket.
- 20**: Mounting screw.
- 21**: Mounting bracket.
- 22**: Mounting screw.
- 23**: Mounting bracket.
- 24**: Mounting bracket.
- 25**: Mounting screw.
- 26**: Mounting bracket.
- 27**: Mounting screw.
- 28**: Mounting bracket.
- 29**: Mounting bracket.
- 30**: Mounting screw.
- 31**: Mounting screw.
- 32**: Mounting bracket.
- 33**: Mounting screw.
- 34**: Mounting bracket.
- 35**: Mounting screw.
- 36**: Mounting bracket.
- 37**: Mounting screw.
- 38**: Mounting bracket.
- 39**: Mounting bracket.
- 40**: Mounting screw.
- 41**: Mounting bracket.
- 42**: Mounting bracket.
- 43**: Mounting screw.
- 44**: Mounting screw.
- 45**: Mounting bracket.
- 46**: Mounting bracket.
- 47**: Mounting bracket.
- 48**: Mounting screw.
- 49**: Mounting bracket.
- 50**: Mounting bracket.
- 51**: Mounting bracket.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	.SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X20)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	

FIG.508D





FIG.508D (2-K-12) OPT:REMOTE CONTROL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

FIG.513A



DF20A_P01_017_513A
OPT:REMOTE CONTROL PARTS

FIG.513A (2-K-13) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L04	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE	1	
5	19131-89L00	NO.2 ..CONNECTOR	2	
6	19148-89L10	NO.1 ..LEVER, INTERLINK THROTTLE	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L24	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER, R/CON CABLE	1	
23	67467-89J01	..CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

DF20A_P01_017

FIG.513A




FIG.513A (2-K-14) OPT:REMOTE CONTROL PARTS (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L04	PARTS SET, R/CON	1	
2	13513-89L10	.ROD, THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE NO.2	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE NO.1	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L24	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513B




FIG.513B (2-L-2) OPT:REMOTE CONTROL PARTS (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513C




FIG.513C (2-L-3) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L04	PARTS SET, R/CON	1	
2	13513-89L10	.ROD, THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE	1	
5	19131-89L00	NO.2 .CONNECTOR	2	
6	19148-89L10	NO.1 .LEVER, INTERLINK THROTTLE	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L24	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513C




FIG.513C (2-L-4) OPT:REMOTE CONTROL PARTS (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.513D




FIG.513D (2-L-5) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67130-89L04	PARTS SET, R/CON	1	
2	13513-89L10	.ROD,THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11	36610-89L24	.HARNESS ASSY, WIRING	1	
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	.ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L20	.GROMMET, R/CON CABLE	1	
22	67340-89L00	.HOLDER, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	
27	09159-22006	.NUT	1	

FIG.513D




FIG.513D (2-L-6) OPT:REMOTE CONTROL PARTS (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	12	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	

FIG.515A





FIG.515A (2-L-7) OPT:REMOCON CABLE (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515B





FIG.515B (2-L-8) OPT:REMOCON CABLE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515C





FIG.515C (2-L-9) OPT:REMOCON CABLE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515D





FIG.515D (2-L-10) OPT:REMOCON CABLE (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515E





FIG.515E (2-L-11) OPT:REMOCON CABLE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515F





FIG.515F (2-L-12) OPT:REMOCON CABLE (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515G





FIG.515G (2-L-13) OPT:REMOCON CABLE (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515H





FIG.515H (2-L-14) OPT:REMOCON CABLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515J





FIG.515J (2-L-15) OPT:REMOCON CABLE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.515K






FIG.515K (3-B-2) OPT:REMOCON CABLE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

FIG.530A




DF20A_P01_017_530A
OPT:SWITCH

FIG.530A (3-B-3) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_017

FIG.530A




DF20A_P01_017_530A
OPT:SWITCH

FIG.530A (3-B-4) OPT:SWITCH (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_017

FIG.530B




DF20A_P01_017_530B
OPT:SWITCH

FIG.530B (3-B-5) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530B




DF20A_P01_017_530B
OPT:SWITCH

FIG.530B (3-B-6) OPT:SWITCH (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

FIG.530C




DF20A_P01_017_530C
OPT:SWITCH

FIG.530C (3-B-7) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_017

FIG.530C




DF20A_P01_017_530C
OPT:SWITCH

FIG.530C (3-B-8) OPT:SWITCH (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_017

FIG.530D




DF20A_P01_017_530D
OPT:SWITCH

FIG.530D (3-B-9) OPT:SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_017

FIG.530D




DF20A_P01_017_530D
OPT:SWITCH

FIG.530D (3-B-10) OPT:SWITCH (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_017

FIG.530E




DF20A_P01_017_530E
OPT:SWITCH

FIG.530E (3-B-11) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

FIG.530E




DF20A_P01_017_530E
OPT:SWITCH

FIG.530E (3-B-12) OPT:SWITCH (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_017

FIG.530F




DF20A_P01_017_530F
OPT:SWITCH

FIG.530F (3-B-13) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	..SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	..PANEL, IGNITION SW	1	
7	38500-93J90	..BUZZER ASSY, WARNING	1	
8	09407-08401	..CLAMP (L:80)	1	
9	37803-93J04	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J00	..NUT	1	
13	37825-99E00	..PANEL, EMERGENCY SW	1	
14	03122-05165	..SCREW	4	
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	..PANEL, LIGHTING SW	1	

DF20A_P01_017

FIG.530F



DF20A_P01_017_530F
OPT:SWITCH

FIG.530F (3-B-14) OPT:SWITCH (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	37100-96J24	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	..SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E20	..PANEL, IGNITION SWITCH	1	
23	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J00	..NUT	1	
26	03121-0516A	..SCREW	4	
27	38500-93J90	..BUZZER ASSY, WARNING	1	
28	09407-08401	..CLAMP (L:80)	1	

DF20A_P01_017

FIG.544A




FIG.544A (3-B-15) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544B




FIG.544B (3-C-2) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544C




FIG.544C (3-C-3) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544D




FIG.544D (3-C-4) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544E




FIG.544E (3-C-5) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544F




FIG.544F (3-C-6) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544G




FIG.544G (3-C-7) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544H




FIG.544H (3-C-8) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544J




FIG.544J (3-C-9) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.544K




FIG.544K (3-C-10) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67261-93J00	.GRIP, NO.1	1	
3	67263-93J00	.GRIP, NO.2	1	
4	37850-93J10	.SWITCH ASSY, PTT	1	
5	67295-92E10	.SCREW	2	
6	67296-88D10	.SCREW	1	
7	67288-92E20	.WASHER	3	
8	67295-92E00	.SCREW	2	
9	67296-92E70	.SCREW	1	
10	67288-92E40	.WASHER	1	
11	67257-92E00	.CAP, LEVER	1	
12	67251-93J00	.LEVER, HANDLE	1	
13	67296-92E60	.SCREW	2	
14	67288-92E30	.WASHER	2	
15	67253-92E00	.WASHER	1	
16	36890-93J00	.WIRE HARNESS	1	
17	67281-93J00	.DECAL	1	
18	67296-92E30	.SCREW	4	
19	09160-05024	.WASHER (5.5X16X1.5)	4	
20	67287-92E00	.NUT	4	
21	67275-95600	.END, CABLE	2	
22	67273-95600	.SPACER	1	
23	67273-92E00	.GROMMET	1	
24	67274-92E00	.FLANGE	2	
25	67296-95610	.SCREW	4	
26	67271-92E00	.COVER	1	
27	67211-93J00	.COVER	1	
28	67296-92E70	.SCREW	2	
29	67500-93J00	KIT, REMOCON SPACER SINGLE	1	
30	09125-05135	.SCREW (5X65)	4	
31	09160-05029	.WASHER (5.5X12X0.8)	4	
32	09140-05005	.NUT	4	

FIG.545A




FIG.545A (3-C-11) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545A




FIG.545A (3-C-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545B




FIG.545B (3-C-13) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545B




FIG.545B (3-C-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545C




FIG.545C (3-C-15) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545C




FIG.545C (3-D-2) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545D




FIG.545D (3-D-3) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545D




FIG.545D (3-D-4) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545E




FIG.545E (3-D-5) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545E




FIG.545E (3-D-6) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545F




FIG.545F (3-D-7) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545F




FIG.545F (3-D-8) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545G




FIG.545G (3-D-9) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545G





FIG.545G (3-D-10) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545H



DF20A_P01_017_545H
OPT:REMOTE CONTROL ASSY SINGLE (2)

FIG.545H (3-D-11) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

DF20A_P01_017

FIG.545H




FIG.545H (3-D-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545J




FIG.545J (3-D-13) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545J




FIG.545J (3-D-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.545K




FIG.545K (3-D-15) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J13	REMOTE CONTROL ASSY	1	PUSH
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67288-92E10	.WASHER	1	
7	67291-92E00	.SNAP RING	2	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	67294-92E00	.SPACER	1	
11	37721-95500	.SWITCH ASSY, N/R	1	
12	67296-92E11	.SCREW (3X15)	2	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW (5X25)	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT (6X18)	3	
20	67230-92E00	.SHIFT ARM ASSY	1	
21	09125-05042	.SCREW (5X10)	9	
22	67234-92E00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67232-95620	.BUSH	1	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	09140-06020	.NUT	2	
32	67236-92E00	.ROLLER	1	
33	67237-92E01	.SPRING	6	
34	67238-92E00	.GEAR, DRIVE	1	

FIG.545K




FIG.545K (3-E-2) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
35	67239-92E00	.PIN	1	
36	67246-92E00	.SHIFT, DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67253-92E10	.WASHER	1	
39	67252-92E10	.BUSH	1	
40	67253-95600	.WASHER	1	
41	67231-92E00	.GEAR, SHIFT	1	
42	67232-95600	.BUSH	1	
43	67241-92E10	.ROD, FREE ACC	1	
44	67243-92E00	.CAP, HOLE	1	
45	67239-92E10	.PLATE, SHIFT PIN	1	

FIG.546A

FIG.546A (3-E-3) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546B

FIG.546B (3-E-4) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546C





FIG.546C (3-E-5) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF15ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.546D

FIG.546D (3-E-6) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546E

FIG.546E (3-E-7) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.546F

FIG.546F (3-E-8) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF20ATH P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-94J01	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	





FIG.553A




FIG.553A (3-E-9) OPT:ELECTRICAL (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFILER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553B




FIG.553B (3-E-10) OPT:ELECTRICAL (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFILER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553C




FIG.553C (3-E-11) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFIER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.553D




FIG.553D (3-E-12) OPT:ELECTRICAL (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L00	KIT,BATTERY CHARGING	1	
2	32801-89L00	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFILER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

FIG.561A




FIG.561A (3-E-13) OPT:STARTING MOTOR (MANUAL STARTER) (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L06	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L01	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L02	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L05	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89LC0	UNIT, ENGINE CONTROL	1	

FIG.561B




FIG.561B (3-E-14) OPT:STARTING MOTOR (MANUAL STARTER) (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L06	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L01	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L02	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L05	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89L80	UNIT, ENGINE CONTROL	1	

FIG.561C




FIG.561C (3-E-15) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L06	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	..FLYWHEEL, MAGNETO	1	
5	32120-89L00	..COIL, STATOR & PULSER	1	
6	32800-89L01	..RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	..BRACKET, RECTIFIER	1	
8	01550-06167	..BOLT	1	
9	01550-06207	..BOLT	2	
10	01547-0625A	..BOLT	3	
11	09408-00184	..CLAMP	1	
12	33800-89L02	..CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L05	..HARNESS ASSY, WIRING	1	
20	38860-76F01	..RELAY ASSY	1	
21	38915-90J00	..HOLDER, RELAY	1	
22	09407-14407	..CLAMP (L:145)	11	
23	12700-89L21	..CAMSHAFT ASSY	1	
24	33920-89LA0	UNIT, ENGINE CONTROL	1	

FIG.561D




FIG.561D (3-F-2) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L06	STARTER SET, ELECTRIC	1	
2	31101-89L00	.MOTOR SET, STARTING	1	
3	31100-94J22	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5	32120-89L00	.COIL, STATOR & PULSER	1	
6	32800-89L01	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L02	.CABLE SET, STARTER	1	
13	33810-89L02	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19	36610-89L05	.HARNESS ASSY, WIRING	1	
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	11	
23	12700-89L21	.CAMSHAFT ASSY	1	
24	33920-89LE0	UNIT, ENGINE CONTROL	1	

FIG.575A




FIG.575A (3-F-3) OPT:DRAG LINK (DF9.9B P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	



FIG.575B




FIG.575B (3-F-4) OPT:DRAG LINK (DF15A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575C




FIG.575C (3-F-5) OPT:DRAG LINK (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.575D




FIG.575D (3-F-6) OPT:DRAG LINK (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

FIG.583A (3-F-7) OPT:FUEL TANK




FIG.600A





FIG.600A (3-F-8) OPT:MULTI FUNCTION GAUGE (DF9.9BR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	.WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	.WIRE, 2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	.CONNECTOR, BRANCH	1	
15	36665-88L00	.UNIT, RESISTOR FEMALE	1	
16	36665-88L10	.UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	.FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	.FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	.CLAMP	1	
33	09407-14407	.CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

FIG.600B



DF20A_P01_017_600B
OPT:MULTI FUNCTION GAUGE

FIG.600B (3-F-9) OPT:MULTI FUNCTION GAUGE (DF9.9BT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	.WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	.WIRE, 2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	.CONNECTOR, BRANCH	1	
15	36665-88L00	.UNIT, RESISTOR FEMALE	1	
16	36665-88L10	.UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	.FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	.FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	.CLAMP	1	
33	09407-14407	.CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

DF20A_P01_017

FIG.600C




FIG.600C (3-F-10) OPT: MULTI FUNCTION GAUGE (DF15AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	.WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	.WIRE, 2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	.CONNECTOR, BRANCH	1	
15	36665-88L00	.UNIT, RESISTOR FEMALE	1	
16	36665-88L10	.UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	.FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	.FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	.CLAMP	1	
33	09407-14407	.CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

FIG.600D




FIG.600D (3-F-11) OPT: MULTI FUNCTION GAUGE (DF15AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	.WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	.WIRE, 2 EXTENSION	1	
13	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	.CONNECTOR, BRANCH	1	
15	36665-88L00	.UNIT, RESISTOR FEMALE	1	
16	36665-88L10	.UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	.FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	.FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	.CLAMP	1	
33	09407-14407	.CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

FIG.600E





FIG.600E (3-F-12) OPT:MULTI FUNCTION GAUGE (DF20AR P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	..FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	..FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	..CLAMP	1	
33	09407-14407	..CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

FIG.600F



DF20A_P01_017_600F
OPT:MULTI FUNCTION GAUGE

FIG.600F (3-F-13) OPT:MULTI FUNCTION GAUGE (DF20AT P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34000-96L41	KIT, SINGLE GAUGE MECH	1	
2	34011-96L11	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L10	ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36663-98J10	..WIRE, GAUGE POWER (6M)	1	
10	09481-05501	..FUSE (5A)	1	
11	36001-88L00	SET, WIRE	1	
12	36662-88L10	..WIRE, 2 EXTENSION	1	
13	36663-88L00	..HARNESS ASSY, NETWORK POWER	1	
14	36664-88L00	..CONNECTOR, BRANCH	1	
15	36665-88L00	..UNIT, RESISTOR FEMALE	1	
16	36665-88L10	..UNIT, RESISTOR MALE	1	
17	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
18	36662-88L10	WIRE, 2 EXTENSION	1	
19	36662-88L20	WIRE, 6 EXTENSION	1	
20	36662-88L30	WIRE, 15 EXTENSION	1	
21	36662-88L00	WIRE, 25 EXTENSION	1	
22	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
23	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
24	36665-88L00	UNIT, RESISTOR FEMALE	1	
25	36665-88L10	UNIT, RESISTOR MALE	1	
26	36663-98J00	WIRE, GAUGE POWER (2.5M)	1	
27	09481-05501	..FUSE (5A)	1	
28	36663-98J10	WIRE, GAUGE POWER (6M)	1	
29	09481-05501	..FUSE (5A)	1	
30	36664-88L00	CONNECTOR, BRANCH	1	
31	36660-89L01	SET, ENG TO INTERFACE WIRE	1	
32	29404-93J10	..CLAMP	1	
33	09407-14407	..CLAMP (L:145)	4	
34	36667-96L20	WIRE, GAUGE EXT	1	
35	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
36	36990-87D00	TERMINAL / SLEEVE SET	1	

DF20A_P01_017

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		12741-89L00	120A-6		121M-6
		12744-89L00	120A-17	12891-94J00	121A-7
		12761-93EL0	120A-16		121B-7
		12840-93E01	121A-3		121C-7
			121B-3		121D-7
11110-89L01	111A-1		121C-3		121E-7
11115-93E00-001	111A-19		121D-3		121F-7
11141-89L00	111A-2		121E-3		121G-7
11162-89L00	111A-14		121F-3		121H-7
11170-89L00	111A-13		121G-3		121J-7
11174-89L00	111A-16		121H-3		121K-7
11261-93J00	111A-5		121J-3		121L-7
11291-91B50	113A-6		121K-3		121M-7
11300-89L03	113A-1		121L-3	12911-94J01	121A-8
11382-93E00	111A-10		121M-3		121B-8
12100-89L10-050	116A-10	12842-49201	121A-4		121C-8
12111-89L00-0B0	116A-1		121B-4		121D-8
12140-89L10	116A-2		121C-4		121E-8
12140-89L10-050	116A-11		121D-4		121F-8
12151-89L00	116A-3		121E-4		121G-8
12160-89L11	116A-5		121F-4		121H-8
12163-89L02	116A-6		121G-4		121J-8
12220-89L00	116A-7		121H-4		121K-8
12341-89L10	116A-8		121J-4		121L-8
12625-89L01	120A-11		121K-4		121M-8
12631-89L10	120A-1		121L-4	12915-94J50	121A-9
12635-89L00	120A-2		121M-4		121B-9
12636-89L00	120A-3	12843-27A00	121A-5		121C-9
12637-89L00	120A-4		121B-5		121D-9
12638-89L00	120A-5		121C-5		121E-9
12700-89L01	121A-1-1		121D-5		121F-9
	121D-1-1		121E-5		121G-9
	121H-1-1		121F-5		121H-9
	121J-1-1		121G-5		121J-9
12700-89L21	121A-1-2		121H-5		121K-9
	121B-1		121J-5		121L-9
	121C-1		121K-5		121M-9
	121D-1-2		121L-5	12921-89L00	121A-10
	121E-1		121M-5		121B-10
	121F-1	12861-89L00	121A-6		121C-10
	121G-1		121B-6		121D-10
	121H-1-2		121C-6		121E-10
	121J-1-2		121D-6		121F-10
	121K-1		121E-6		121G-10
	121L-1		121F-6		121H-10
	121M-1		121G-6		121J-10
	561A-23		121H-6		121K-10
	561B-23		121J-6		121L-10
	561C-23		121K-6		121M-10
	561D-23		121L-6	12931-78G00	121A-11

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	121B-11		126D-8		163F-2
	121C-11		126E-8		163G-2
	121D-11		126F-8		163H-2
	121E-11		126G-8		163J-2
	121F-11		126H-10		163K-2
	121G-11		126J-10		163L-2
	121H-11		126K-10	13421-89L00	163M-2
	121J-11		126L-10		163A-5
	121K-11		126M-10		163B-5
	121L-11	13119-89L00	126A-2		163C-5
	121M-11		126B-2		163D-5
12932-24400	121A-12		126C-2		163E-5
	121B-12		126D-2		163F-5
	121C-12		126E-2		163G-5
	121D-12		126F-2		163H-5
	121E-12		126G-2		163J-5
	121F-12		126H-2		163K-5
	121G-12		126J-2		163L-5
	121H-12		126K-2		163M-5
	121J-12		126L-2	13425-33G00	163A-3
	121K-12		126M-2		163B-3
	121L-12	13300-89L01	163A-1		163C-3
	121M-12		163D-1		163D-3
12933-71C00	121A-13		163G-1		163E-3
	121B-13		163H-1		163F-3
	121C-13		163J-1		163G-3
	121D-13		163M-1		163H-3
	121E-13	13300-89L11	163B-1		163J-3
	121F-13		163C-1		163K-3
	121G-13		163E-1		163L-3
	121H-13		163F-1		163M-3
	121J-13		163K-1	13513-89L10	166A-1
	121K-13		163L-1		166B-1
	121L-13	13326-89L00	163A-4		166C-1
	121M-13		163B-4		166D-1
13111-89L00	126A-1		163C-4		166E-1
	126B-1		163D-4		166F-1
	126C-1		163E-4		513A-2
	126D-1		163F-4		513B-2
	126E-1		163G-4		513C-2
	126F-1		163H-4		513D-2
	126G-1		163J-4	13640-32G20	334A-1
	126H-1		163K-4		334B-1
	126J-1		163L-4		334C-1
	126K-1		163M-4		334D-1
	126L-1	13420-16HA0	163A-2		334E-1
	126M-1		163B-2		334F-1
13116-94J00	126A-8		163C-2		334G-1
	126B-8		163D-2		334H-1
	126C-8		163E-2		334J-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
13650-52G00	334K-1		126G-5		146J-25
	334L-1		126H-5		146K-25
	334M-1		126J-5		146L-25
	334A-12		126K-5		146M-25
	334B-11		126L-5	15192-89L00	146A-26
	334C-11	13820-89L00	126M-5		146B-26
	334D-12		126D-9		146C-26
	334E-11		126E-9		146D-26
	334F-11		126F-9		146E-26
	334G-11		126G-9		146F-26
	334H-12	13820-89L10	126A-9		146G-26
	334J-12		126B-9		146H-26
	334K-11		126C-9		146J-26
	334L-11	13831-89L00	126A-11		146K-26
	334M-11		126B-11		146L-26
13655-89L01	334A-13		126C-11		146M-26
	334B-12		126D-11	15192-89L10	146A-27
	334C-12		126E-11		146B-27
	334D-13		126F-11		146C-27
	334E-12		126G-11		146D-27
	334F-12		126H-11		146E-27
	334G-12		126J-11		146F-27
	334H-13		126K-11		146G-27
	334J-13		126L-11		146H-27
	334K-12		126M-11		146J-27
	334L-12	13832-89L00	126H-7		146K-27
13684-89L00	334M-12		126J-7		146L-27
	146A-1		126K-7		146M-27
	146B-1		126L-7	15192-89L20	146A-28
	146C-1		126M-7		146B-28
	146D-1	15100-89L10	146J-24		146C-28
	146E-1		146A-24		146D-28
	146F-1	15100-89L20	146B-24		146E-28
	146G-1		146C-24		146F-28
	146H-1		146D-24		146G-28
	146J-1		146E-24		146H-28
	146K-1		146F-24		146J-28
	146L-1		146G-24		146K-28
	146M-1		146H-24		146L-28
	126H-6		146K-24		146M-28
	126J-6		146L-24	15192-89L30	146A-29
	126K-6	15191-89L00	146M-24		146B-29
	126L-6		146A-25		146C-29
	126M-6		146B-25		146D-29
	126A-5		146C-25		146E-29
	126B-5		146D-25		146F-29
13811-89L00	126C-5		146E-25		146G-29
	126D-5		146F-25		146H-29
	126E-5		146G-25		146J-29
	126F-5		146H-25		146K-29

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15192-89L40	146L-29	15211-91J00-130	163A-6		146C-35
	146M-29		163B-6		146D-35
	146A-30		163C-6		146E-35
	146B-30		163D-6		146F-35
	146C-30		163E-6		146G-35
	146D-30		163F-6		146H-35
	146E-30		163G-6		146J-35
	146F-30		163H-6		146K-35
	146G-30		163J-6		146L-35
	146H-30		163K-6		146M-35
	146J-30	15217-89L00	163L-6	15421-89L01	146A-36
	146K-30		163M-6		146B-36
	146L-30		146A-3		146C-36
	146M-30		146B-3		146D-36
	146A-31		146C-3		146E-36
15193-89L00	146B-31		146D-3		146F-36
	146C-31		146E-3		146G-36
	146D-31		146F-3		146H-36
	146E-31		146G-3		146J-36
	146F-31		146H-3		146K-36
	146G-31		146J-3		146L-36
	146H-31		146K-3		146M-36
	146J-31		146L-3	15422-89L00	146A-37
	146K-31		146M-3		146B-37
	146L-31	15218-89L00	146A-4		146C-37
15194-89L00	146M-31		146B-4		146D-37
	146A-32		146C-4		146E-37
	146B-32		146D-4		146F-37
	146C-32		146E-4		146G-37
	146D-32		146F-4		146H-37
	146E-32		146G-4		146J-37
	146F-32		146H-4		146K-37
	146G-32		146J-4		146L-37
	146H-32		146K-4		146M-37
	146J-32		146L-4	15600-89L00	146A-5
15200-89L10	146K-32	15410-87L00	146M-4		146B-5
	146L-32		146A-33		146C-5
	146M-32		146B-33		146D-5
	146A-2		146C-33		146E-5
	146B-2		146D-33		146F-5
	146C-2		146E-33		146G-5
	146D-2		146F-33		146H-5
	146E-2		146G-33		146J-5
	146F-2		146H-33		146K-5
	146G-2		146J-33		146L-5
	146H-2		146K-33	15629-89L00	146M-5
	146J-2		146L-33		146A-8
	146K-2		146M-33		146B-8
	146L-2	15419-87J00	146A-35		146C-8
	146M-2		146B-35		146D-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	146E-8	15770-89L02	146A-7		160F-1
	146F-8		146B-7		160G-1
	146G-8		146C-7		160H-1
	146H-8		146D-7		160J-1
	146J-8		146E-7		160K-1
15676-89L00	146K-8		146F-7	17413-94J00	160L-1
	146L-8		146G-7		160M-1
	146M-8		146H-7		160A-2
	146A-44		146J-7		160B-2
	146B-44		146K-7		160C-2
	146C-44	15790-89L00	146L-7		160D-2
	146D-44		146M-7		160E-2
	146E-44		146A-9		160F-2
	146F-44		146B-9		160G-2
	146G-44		146C-9		160H-2
	146H-44		146D-9		160K-2
	146J-44		146E-9		160L-2
	146K-44		146F-9		160M-2
	146L-44		146G-9	17413-94J10	160J-2
	146M-44		146H-9	17461-939M0	160A-3
15681-89L00	144A-1		146J-9		160B-3
15685-89L00	146A-38		146K-9		160C-3
	146B-38		146L-9		160D-3
	146C-38		146M-9		160E-3
	146D-38	16400-89L00	175A-1		160F-3
	146E-38	16431-89L00	175A-12		160G-3
	146F-38	16440-11D00	113A-5		160H-3
	146G-38	16510-45H10	175A-2		160J-3
	146H-38	16512-99J00	175A-3		160K-3
	146J-38	16515-89L10	401A-6		160L-3
	146K-38	16520-99J00	401A-17		160M-3
15690-89L02	146L-38	16910-89L01	175A-9	17471-99J00	160A-4
	146M-38	16930-89L01	175A-10		160B-4
	146A-6	17400-99J01	160A-19		160C-4
	146B-6		160B-19		160D-4
	146C-6		160C-19		160E-4
	146D-6		160D-19		160F-4
	146E-6		160E-19		160G-4
	146F-6		160F-19		160H-4
	146G-6		160G-19		160K-4
	146H-6		160H-19		160L-4
	146J-6		160K-19		160M-4
	146K-6		160L-19	17471-99J10	160J-4
	146L-6		160M-19	17472-99J00	160A-5
	146M-6	17400-99J11	160J-19		160B-5
15710-50M00	144A-2	17411-94J00	160A-1		160C-5
15716-65DT0	144A-3		160B-1		160D-5
15734-89L00	144A-4		160C-1		160E-5
15735-89L00	144A-5		160D-1		160F-5
15751-89L00	144A-6		160E-1		160G-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	160H-5		160K-7-3		160M-10
	160J-5		160L-7-3	17632-99J30	160A-11
	160K-5		160M-7-3		160B-11
	160L-5	17563-94J00	160A-8		160C-11
	160M-5		160B-8		160D-11
17473-94J00	160A-6		160C-8		160E-11
	160B-6		160D-8		160F-11
	160C-6		160E-8		160G-11
	160D-6		160F-8		160H-11
	160E-6		160G-8		160J-11
	160F-6		160H-8		160K-11
	160G-6		160J-8		160L-11
	160H-6		160K-8		160M-11
	160J-6		160L-8	17670-91J00	162A-1
	160K-6		160M-8	17680-89L00	162A-2
17561-99J00	160L-6	17564-99J00	160A-9	17685-89L00	162A-7
	160M-6		160B-9	17712-89L00	162A-5
	160A-7-1		160C-9	17712-89L10	162A-4
	160B-7-1		160D-9	17913-93J00	405A-1
	160C-7-1		160E-9	17914-93J00	405A-2
	160D-7-1		160F-9	17917-87L0	410A-22
	160E-7-1		160G-9		410B-22
	160F-7-1		160H-9		410C-23
	160G-7-1		160J-9		410D-22
	160H-7-1		160K-9		410E-22
17561-99J10	160J-7-1		160L-9		410F-23
	160K-7-1		160M-9		410G-23
	160L-7-1	17565-99J00	160A-18		410H-22
	160M-7-1		160B-18		410J-22
	160A-7-2		160C-18		410K-22
	160B-7-2		160D-18		410L-23
	160C-7-2		160E-18	18100-94JN0	410M-23
	160D-7-2		160F-18		167A-1
	160E-7-2		160G-18		167B-1
	160F-7-2		160H-18		167C-1
17561-99J20	160G-7-2		160J-18		167D-1
	160H-7-2		160K-18		167E-1
	160J-7-2		160L-18		167F-1
	160K-7-2		160M-18		167G-1
	160L-7-2	17631-99J20	160A-10		167H-1
	160M-7-2		160B-10		167J-1
	160A-7-3		160C-10		167K-1
	160B-7-3		160D-10		167L-1
	160C-7-3		160E-10		167M-1
	160D-7-3		160F-10	18121-94JL0	167A-2
	160E-7-3		160G-10		167B-2
	160F-7-3		160H-10		167C-2
	160G-7-3		160J-10		167D-2
	160H-7-3		160K-10		167E-2
	160J-7-3		160L-10		167F-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
18130-93E01	167G-2	18280-93E00	167J-6	19120-99J11	334K-13
	167H-2		167K-6		334L-13
	167J-2		167L-6		334M-13
	167K-2		167M-6		166A-2
	167L-2		167A-7		166B-2
	167M-2		167B-7		166C-2
	167A-3		167C-7		166D-2
	167B-3		167D-7		166E-2
	167C-3		167E-7		166F-2
	167D-3		167F-7		513A-3
18132-89L00	167E-3	18290-94J01	167G-7	19122-99J00	513B-3
	167F-3		167H-7		513C-3
	167G-3		167J-7		513D-3
	167H-3		167K-7		166A-3
	167J-3		167L-7		166B-3
	167K-3		167M-7		166C-3
	167L-3		167A-10		166D-3
	167M-3		167B-10		166E-3
	167A-5		167C-10		166F-3
	167B-5		167D-10		513A-4
18142-93E00	167C-5	18498-87JC0	167E-10	19131-89L00	513B-4
	167D-5		167F-10		513C-4
	167E-5		167G-10		513D-4
	167F-5		167H-10		166A-4
	167G-5		167J-10		166B-4
	167H-5		167K-10		166C-4
	167J-5		167L-10		166D-4
	167K-5		167M-10		166E-4
	167L-5		146A-10		166F-4
	167M-5		146B-10		513A-5
18210-95L00	167A-4	18590-58M00	146C-10	19148-89L10	513B-5
	167B-4		146D-10		513C-5
	167C-4		146E-10		513D-5
	167D-4		146F-10		166A-5
	167E-4		146G-10		166B-5
	167F-4		146H-10		166C-5
	167G-4		146J-10		166D-5
	167H-4		146K-10		166E-5
	167J-4		146L-10		166F-5
	167K-4		146M-10		513A-6
18122-89L00	167L-4	23111-89L00	162A-8	19150-89L00	513B-6
	167M-4		334A-14		513C-6
	167A-6		334B-13		513D-6
	167B-6		334C-13		166A-6
	167C-6		334D-14		166B-6
	167D-6		334E-13		166C-6
	167E-6		334F-13		166D-6
	167F-6		334G-13		166E-6
	167G-6		334H-14		166F-6
	167H-6		334J-14		513A-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
19185-99J00	513B-7	21131-94J00	206C-3	23111-89L10	206F-5-1
	513C-7		206D-3		206G-5-1
	513D-7		206H-3		206H-5-1
	166A-7		206F-3		206J-5-1
	166B-7		206G-3		206K-5-1
	166C-7		206H-3		206L-5-1
	166D-7		206J-3		206M-5-1
	166E-7		206K-3		206A-5-2
	166F-7		206L-3		206B-5-2
	513A-8		206M-3		206C-5-2
20000	513B-8	21210-89L01	444A-36	23115-89L00	206D-5-2
	513C-8		444B-36		206E-5-2
	513D-8		444C-36		206F-5-2
			444D-36		206G-5-2
			444E-36		206H-5-2
			444F-36		206J-5-2
			206A-4		206K-5-2
			206B-4		206L-5-2
			206C-4		206M-5-2
			206D-4		206A-6
21110-89L10	206B-1	22511-99011	206E-4	23115-89L10	206D-6
	206C-1		206F-4		206G-6
	206E-1		206G-4		206H-6
	206F-1		206H-4		206J-6
	206K-1		206J-4		206M-6
	206L-1		206K-4		206B-6
	513A-9		206L-4		206C-6
	513B-9		206M-4		206E-6
	513C-9		336A-1		206F-6
	513D-9		336B-1		206K-6
21111-89L00	206A-1	23211-89L00	336C-1-1	23311-95J00	206L-6
	206D-1		336C-1-2		513A-10
	206G-1		336D-1		513B-10
	206H-1		336E-1		513C-10
	206J-1		336F-1-1		513D-10
	206M-1		336F-1-2		206A-7
	206A-2		336G-1-1		206B-7
	206B-2		336G-1-2		206C-7
	206C-2		336H-1		206D-7
	206D-2		336J-1		206E-7
21122-89L00	206E-2	23111-89L00	336K-1	25111-99J01	206F-7
	206F-2		336L-1-1		206G-7
	206G-2		336L-1-2		206H-7
	206H-2		336M-1-1		206J-7
	206J-2		336M-1-2		206K-7
	206K-2		206A-5-1		206L-7
	206L-2		206B-5-1		206M-7
	206M-2		206C-5-1		210A-1
	206A-3		206D-5-1		210A-2-1
	206B-3		206E-5-1		210A-2-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
25211-99JL0	210A-5		336H-21	31151-94J01	301A-4
25215-99J00	210A-6		336J-21	31152-90J00	301A-5
25311-99J00	210A-3		336K-21	31153-90J00	301A-6
29103-93J00	327C-6		336L-11	31170-94J00	301A-17
	327E-6		336M-11	31171-96J00	301A-7
29141-93J00	160A-13	30000		31173-94J01	301A-8
	160B-13			31174-89LA0	340A-2
	160C-13				340B-2
	160D-13				340C-2
	160E-13				340D-2
	160F-13		31000-89L06		340E-2
	160G-13			31191-96J00	301A-9
	160H-13			31192-94J01	338A-11
	160J-13				338B-11
	160K-13		31100-94J22		338C-11
	160L-13				338D-11
	160M-13				338E-11
	210A-7			31193-94J00	338A-10
	335A-12				338B-10
	335B-12	31101-89L00			338C-10
	335D-12				338D-10
	335E-12				338E-10
	335H-12			31220-94J00	301A-10
	335J-12	31123-89J10		31281-94J01	338A-12
	335K-12				338B-12
29162-93J10	335A-18				338C-12
	335B-18				338D-12
	335C-22				338E-12
	335D-18	31123-94J01		31310-90J00	301A-11
	335E-18			31311-94J00	340A-9
	335F-22				340B-9
	335G-22				340C-9
	335H-18				340D-9
	335J-18	31131-94J00			340E-9
	335K-18	31133-94900		31320-94J00	301A-12
	335L-22			31341-94J00	301A-13
	335M-22			31343-90J00	301A-14
29404-93J10	600A-32			31344-90J00	301A-15
	600B-32			31360-93J01	301A-16
	600C-32	31135-90J00		31912-89L00	301A-18
	600D-32	31135-94900		31918-94J00	301A-19
	600E-32			32000-89L00	553A-1
	600F-32				553B-1
29440-93J00	336A-21				553C-1
	336B-21				553D-1
	336C-11	31136-94J00		32102-89L00	303E-4
	336D-21				561A-4
	336E-21				561B-4
	336F-11				561C-4
	336G-11				561D-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
32102-89L10	303A-4		561B-7		310C-9
	303B-4		561C-7		310D-9
	303C-4		561D-7		310E-9
	303D-4	32815-89L10	553A-4		310F-9
32120-89L00	303E-1		553B-4		310G-9
	561A-5		553C-4		310H-9
	561B-5		553D-4		310J-9
	561C-5	32890-89L01	310A-4		310K-9
	561D-5		310B-4		310L-9
32120-89L10	303A-1		310C-4		310M-9
	303B-1		310D-4	33634-96J00	322A-13
	303C-1		310E-4		322B-8
32800-89L01	303D-1		310F-4		322C-8
	310A-1		310G-4		322D-13
	310B-1		310H-4		322E-8
	310C-1		310J-4		322F-8
	310D-1		310K-4		322G-13
	310E-1		310L-4		322H-13
	310F-1		310M-4		322J-13
	310G-1	32916-89L00	322A-11		322K-8
	310H-1		322B-7		322L-8
	310J-1		322C-7		322M-13
	310K-1		322D-11	33799-97E00	340A-6
	310L-1		322E-7		340B-6
	310M-1		322F-7		340C-6
	561A-6		322G-11		340D-6
	561B-6		322H-11		340E-6
	561C-6		322J-11	33800-89L02	561A-12
	561D-6		322K-7		561B-12
32800-94J11	553A-3		322L-7		561C-12
	553B-3		322M-11		561D-12
	553C-3	33220-84M10	303A-9	33810-89L02	322A-1
	553D-3		303B-9		322B-1
32801-89L00	553A-2		303C-9		322C-1
	553B-2		303D-9		322D-1
	553C-2		303E-9		322E-1
	553D-2	33410-89L10	310A-11		322F-1
32815-89L00	310A-2		310B-11		322G-1
	310B-2		310C-11		322H-1
	310C-2		310D-11		322J-1
	310D-2		310E-11		322K-1
	310E-2		310F-11		322L-1
	310F-2		310G-11		322M-1
	310G-2		310H-11		561A-13
	310H-2		310J-11		561B-13
	310J-2		310K-11		561C-13
	310K-2		310L-11		561D-13
	310L-2		310M-11	33833-91J00	444A-21
	310M-2	33500-07H00	310A-9		444B-21
	561A-7		310B-9		444C-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
33920-89L80	444D-21	34100-93J31	501D-5-1	34193-96L00	501F-7
	444E-21		501E-5-1		600A-4
	444F-21		501F-5-1		600B-4
	310D-13-1		501A-5-2		600C-4
33920-89L90	310E-13	34100-93J40	501B-5-2	34200-93J20	600D-4
	310F-13		501C-5-2		600E-4
	310G-13		501D-5-2		600F-4
	561B-24		501E-5-2		501A-13-1
33920-89LA0	310D-13-2	34100-93J51	501F-5-2	34200-93J32	501B-13-1
	310H-13-1		501A-5-3		501C-13-1
	310K-13		501B-5-3		501D-13-1
	310L-13		501C-5-3		501E-13-1
33920-89LB0	310M-13	34100-93J51	501D-5-3	34211-96L00	501F-13-1
	561C-24		501E-5-3		501A-13-2
	310H-13-2		501F-5-3		501B-13-2
	310A-13-1		501A-5-4		501C-13-2
33920-89LC0	310B-13	34112-96L00	501B-5-4	34300-93J00	501D-13-2
	310C-13		501C-5-4		501E-13-2
	561A-24		501D-5-4		501F-13-2
	310A-13-2		501E-5-4		600A-5
33920-89LE0	310J-13-1	34190-87D00	501F-5-4	34300-93J11	600B-5
	561D-24		600A-3		600C-5
	310J-13-2		600B-3		600D-5
	310A-14		600C-3		600E-5
33920-89LF0	310B-14	34190-88L00	600D-3	34310-92E00	600F-5
	310C-14		600E-3		501A-15-1
	310D-14		600F-3		501B-15-1
	310E-14		501A-12		501C-15-1
33925-89L00	310F-14	34190-88L00	501B-12	34360-92E00	501D-15-1
	310G-14		501C-12		501E-15-1
	310H-14		501D-12		501F-15-1
	310J-14		501E-12		501A-15-2
34000-96L41	310K-14	34190-95500	501F-12	34360-92E00	501B-15-2
	310L-14		600A-17		501C-15-2
	310M-14		600B-17		501D-15-2
	600A-1		600C-17		501E-15-2
34011-96L11	600B-1	34190-95500	600D-17	34360-92E00	501F-15-2
	600C-1		600E-17		501A-16
	600D-1		600F-17		501B-16
	600E-1		501A-10		501C-16
34100-93J20	600F-1	34191-92E00	501B-10	34500-93J00	501D-16
	600A-2		501C-10		501E-16
	600B-2		501D-10		501F-16
	600C-2		501E-10		501A-17
34100-93J20	600D-2	34191-92E00	501F-10		501B-17
	600E-2		501A-7		501C-17
	600F-2		501B-7		501D-17
	501A-5-1		501C-7		501E-17
34100-93J20	501B-5-1	34191-92E00	501D-7		501F-17
	501C-5-1		501E-7		501A-1-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
34500-93J11	501B-1-1	36610-89L05	334D-4	36616-89L03	600B-8
	501C-1-1		334E-4		600C-8
	501D-1-1		334F-4		600D-8
	501E-1-1		334G-4		600E-8
34600-93J00	501F-1-1	36610-89L24	334H-4	36617-89L01	600F-8
	501A-1-2		334J-4		334A-10
	501B-1-2		334K-4		334B-9
	501C-1-2		334L-4		334C-9
34600-93J11	501D-1-2	36610-89L60	334M-4	36617-89L10	334D-10
	501E-1-2		561A-19		334E-9
	501F-1-2		561B-19		334F-9
	501A-3-1		561C-19		334G-9
34825-96L00	501B-3-1	36610-89L70	561D-19	36617-89L20	334H-10
	501C-3-1		513A-11		334J-10
	501D-3-1		513B-11		334K-9
	501E-3-1		513C-11		334L-9
36001-88L00	501F-3-1	36610-89L80	513D-11	36617-89L30	334M-9
	501A-3-2		322A-5-1		322A-14
	501B-3-2		322D-5-1		322B-9
	501C-3-2		322H-5-1		322D-14
36001-88L00	501D-3-2	36610-89L90	322J-5-1	36617-89L40	322E-9
	501E-3-2		322A-5-2		322H-14
	501F-3-2		322D-5-2		322J-14
	600A-6		322H-5-2		322K-9
36360-99J10	600B-6	36615-96300	322J-5-2	36617-91J00	322A-12
	600C-6		322B-2		322D-12
	600D-6		322E-2		322G-12
	600E-6		322K-2		322H-12
36360-99J10	600F-6	36615-96300	322G-5	36617-91J00	322J-12
	600A-11		322M-5		322M-12
	600B-11		322C-2		561A-14
	600C-11		322F-2		561B-14
36360-99J10	600D-11	36615-96300	322L-2	36617-91J00	561C-14
	600E-11		303A-12		561D-14
	600F-11		303B-12		322C-10
	334A-3		303C-12		322F-10
36367-89L00	334B-3	36617-89L30	303D-12	36617-89L40	322L-10
	334C-3		322A-9		322C-9
	334D-3		322D-9		322F-9
	334E-3		322G-9		322G-14
36367-89L00	334F-3	36617-89L40	322H-9	36617-89L40	322L-9
	334G-3		322J-9		322M-14
	334H-3		322M-9		322C-17
	334J-3		501A-9		322F-17
36367-89L00	334K-3	36617-89L40	501B-9	36617-89L40	322G-22
	334L-3		501C-9		322L-17
	334M-3		501D-9		322M-22
	334A-4		501E-9		322A-15
36367-89L00	334B-4	36617-89L40	501F-9	36617-89L40	322B-10
	334C-4		600A-8		322D-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36618-43410	322E-10		450E-2		600B-20
	322G-15		450F-3		600C-20
	322H-15		508A-2		600D-20
	322J-15		508B-2		600E-20
	322K-10		508C-2		600F-20
	322M-15		508D-2	36663-88L00	600A-13
	322A-8	36634-93910	553A-13		600A-23
	322B-5		553B-13		600B-13
	322C-5		553C-13		600B-23
	322D-8		553D-13		600C-13
36620-93J02	322E-5	36646-93J01	450B-2		600C-23
	322F-5		450D-2		600D-13
	322G-8		450F-2		600D-23
	322H-8	36660-89L01	600A-31		600E-13
	322J-8		600B-31		600E-23
	322K-5		600C-31		600F-13
	322L-5		600D-31	36663-98J00	600F-23
	322M-8		600E-31		600A-26
	513A-12		600F-31		600B-26
	513B-12	36661-96L10	600A-7		600C-26
36620-93J10	513C-12		600B-7		600D-26
	513D-12		600C-7		600E-26
	450B-54		600D-7	36663-98J10	600F-26
	450D-54		600E-7		600A-9
	450F-54		600F-7		600A-28
	322B-17-1	36662-88L00	600A-21		600B-9
	322C-18-1		600B-21		600B-28
	322E-17-1		600C-21		600C-9
	322F-18-1		600D-21		600C-28
	322K-17-1		600E-21		600D-9
36620-93J40	322L-18-1		600F-21		600D-28
	322B-17-2	36662-88L10	600A-12		600E-9
	322C-18-2		600A-18		600E-28
	322E-17-2		600B-12		600F-9
	322F-18-2		600B-18		600F-28
	322K-17-2		600C-12	36664-88L00	600A-14
	322L-18-2		600C-18		600A-30
	450A-52		600D-12		600B-14
	450C-52		600D-18		600B-30
	450E-52		600E-12		600C-14
36620-94J01	546A-1		600E-18		600C-30
	546B-1		600F-12		600D-14
	546C-1		600F-18		600D-30
	546D-1	36662-88L20	600A-19		600E-14
	546E-1		600B-19		600E-30
	546F-1		600C-19		600F-14
	450A-2		600D-19	36665-88L00	600F-30
	450B-3		600E-19		600A-15
	450C-2		600F-19		600A-24
	450D-3	36662-88L30	600A-20		600B-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	600B-24		335F-10		530F-2
	600C-15		335G-9	37110-93J11	530F-18
	600C-24		335G-10		450B-4
	600D-15		335L-9		450D-4
	600D-24		335L-10		450F-4
	600E-15		335M-9	37110-94J02	450A-3
	600E-24	36895-87D01	335M-10		450C-3
	600F-15		335C-11		450E-3
	600F-24		335F-11		508A-3
36665-88L10	600A-16		335G-11		508B-3
	600A-25		335L-11		508C-3
	600B-16		335M-11		508D-3
	600B-25	36990-87D00	546A-3	37139-99E00	530A-6
	600C-16		546B-3		530B-6
	600C-25		546C-3		530C-6
	600D-16		546D-3		530D-6
	600D-25		546E-3		530E-6
	600E-16		546F-3		530F-6
	600E-25		553A-17	37139-99E20	530A-22
	600F-16		553B-17		530B-22
	600F-25		553C-17		530C-22
36667-96L20	600A-34		553D-17		530D-22
	600B-34		600A-36		530E-22
	600C-34		600B-36		530F-22
	600D-34		600C-36	37141-99E00	450A-4-1
	600E-34		600D-36		450B-5-1
	600F-34		600E-36		450C-4-1
36682-92E00	600A-35		600F-36		450D-5-1
	600B-35	37100-96J00	530A-1		450E-4-1
	600C-35		530B-1		450F-5-1
	600D-35		530C-1		508A-4-1
	600E-35		530D-1		508B-4-1
	600F-35		530E-1		508C-4-1
36740-94J00	553A-10		530F-1		508D-4-1
	553B-10	37100-96J24	530A-17		530A-3-1
	553C-10		530B-17		530A-19-1
	553D-10		530C-17		530B-3-1
36890-93J00	544A-16		530D-17		530B-19-1
	544B-16		530E-17		530C-3-1
	544C-16		530F-17		530C-19-1
	544D-16	37110-93J01	530A-2		530D-3-1
	544E-16		530A-18		530D-19-1
	544F-16		530B-2		530E-3-1
	544G-16		530B-18		530E-19-1
	544H-16		530C-2		530F-3-1
	544J-16		530C-18		530F-19-1
	544K-16		530D-2	37141-99E10	450A-4-2
36894-87D00	335C-9		530D-18		450B-5-2
	335C-10		530E-2		450C-4-2
	335F-9		530E-18		450D-5-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450E-4-2		530A-3-4		530D-3-6
	450F-5-2		530A-19-4		530D-19-6
	508A-4-2		530B-3-4		530E-3-6
	508B-4-2		530B-19-4		530E-19-6
	508C-4-2		530C-3-4		530F-3-6
	508D-4-2		530C-19-4		530F-19-6
	530A-3-2		530D-3-4	37141-99E60	450A-4-7
	530A-19-2		530D-19-4		450B-5-7
	530B-3-2		530E-3-4		450C-4-7
	530B-19-2		530E-19-4		450D-5-7
	530C-3-2		530F-3-4		450E-4-7
	530C-19-2	37141-99E40	530F-19-4		450F-5-7
	530D-3-2		450A-4-5		508A-4-7
	530D-19-2		450B-5-5		508B-4-7
	530E-3-2		450C-4-5		508C-4-7
	530E-19-2		450D-5-5		508D-4-7
37141-99E20	530F-3-2		450E-4-5		530A-3-7
	530F-19-2		450F-5-5		530A-19-7
	450A-4-3		508A-4-5		530B-3-7
	450B-5-3		508B-4-5		530B-19-7
	450C-4-3		508C-4-5		530C-3-7
	450D-5-3		508D-4-5		530C-19-7
	450E-4-3		530A-3-5		530D-3-7
	450F-5-3		530A-19-5		530D-19-7
	508A-4-3		530B-3-5		530E-3-7
	508B-4-3		530B-19-5		530E-19-7
	508C-4-3		530C-3-5		530F-3-7
	508D-4-3		530C-19-5		530F-19-7
	530A-3-3		530D-3-5	37141-99E70	450A-4-8
	530A-19-3		530D-19-5		450B-5-8
	530B-3-3		530E-3-5		450C-4-8
	530B-19-3		530E-19-5		450D-5-8
	530C-3-3		530F-3-5		450E-4-8
	530C-19-3		530F-19-5		450F-5-8
	530D-3-3	37141-99E50	450A-4-6		508A-4-8
	530D-19-3		450B-5-6		508B-4-8
	530E-3-3		450C-4-6		508C-4-8
	530E-19-3		450D-5-6		508D-4-8
	530F-3-3		450E-4-6		530A-3-8
	530F-19-3		450F-5-6		530A-19-8
37141-99E30	450A-4-4		508A-4-6		530B-3-8
	450B-5-4		508B-4-6		530B-19-8
	450C-4-4		508C-4-6		530C-3-8
	450D-5-4		508D-4-6		530C-19-8
	450E-4-4		530A-3-6		530D-3-8
	450F-5-4		530A-19-6		530D-19-8
	508A-4-4		530B-3-6		530E-3-8
	508B-4-4		530B-19-6		530E-19-8
	508C-4-4		530C-3-6		530F-3-8
	508D-4-4		530C-19-6		530F-19-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37141-99E80	450A-4-9		508A-4-11		530B-4
	450B-5-9		508B-4-11		530B-20
	450C-4-9		508C-4-11		530C-4
	450D-5-9		508D-4-11		530C-20
	450E-4-9		530A-3-11		530D-4
	450F-5-9		530A-19-11		530D-20
	508A-4-9		530B-3-11		530E-4
	508B-4-9		530B-19-11		530E-20
	508C-4-9		530C-3-11		530F-4
	508D-4-9		530C-19-11		530F-20
	530A-3-9		530D-3-11	37149-93J00	450A-6
	530A-19-9		530D-19-11		450B-7
	530B-3-9		530E-3-11		450C-6
	530B-19-9		530E-19-11		450D-7
	530C-3-9		530F-3-11		450E-6
	530C-19-9		530F-19-11		450F-7
	530D-3-9	37141-99EB0	450A-4-12		508A-6
	530D-19-9		450B-5-12		508B-6
	530E-3-9		450C-4-12		508C-6
	530E-19-9		450D-5-12		508D-6
	530F-3-9		450E-4-12		530A-5
37141-99E90	530F-19-9		450F-5-12		530A-21
	450A-4-10		508A-4-12		530B-5
	450B-5-10		508B-4-12		530B-21
	450C-4-10		508C-4-12		530C-5
	450D-5-10		508D-4-12		530C-21
	450E-4-10		530A-3-12		530D-5
	450F-5-10		530A-19-12		530D-21
	508A-4-10		530B-3-12		530E-5
	508B-4-10		530B-19-12		530E-21
	508C-4-10		530C-3-12		530F-5
	508D-4-10		530C-19-12	37161-89L02	530F-21
	530A-3-10		530D-3-12		334A-5
	530A-19-10		530D-19-12		334D-5
	530B-3-10		530E-3-12		334G-5
	530B-19-10		530E-19-12		334H-5
	530C-3-10		530F-3-12		334J-5
	530C-19-10		530F-19-12		334M-5
	530D-3-10	37143-99E00	450A-5		561A-15
	530D-19-10		450B-6		561B-15
	530E-3-10		450C-5		561C-15
	530E-19-10		450D-6		561D-15
	530F-3-10		450E-5	37163-89L00	334A-6
	530F-19-10		450F-6		334B-5
37141-99EA0	450A-4-11		508A-5		334C-5
	450B-5-11		508B-5		334D-6
	450C-4-11		508C-5		334E-5
	450D-5-11		508D-5		334F-5
	450E-4-11		530A-4		334H-6
	450F-5-11		530A-20		334J-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37210-93J00	334K-5	37726-89L00	334H-11	37823-92E01	530A-23
	334L-5		334J-11		530B-10
	513A-15		334K-10		530B-23
	513B-15		334L-10		530C-10
	513C-15		334M-10		530C-23
37212-93J00	513D-15	37801-98300	334A-8	37826-92J00	530D-10
	530A-15		334B-7		530D-23
	530B-15		334C-7		530E-10
	530C-15		334D-8		530E-23
	530D-15		334E-7		530F-10
37721-89L00	530E-15	37803-93J04	334F-7	37825-99E00	530F-23
	530F-15		334G-7		450A-8
	530A-16		334H-8		450B-10
	530B-16		334J-8		450C-8
	530C-16		334K-7		450D-10
37721-93J91	530D-16	37820-80002	334L-7	37850-90J00	450E-8
	530E-16		334M-7		450F-10
	530F-16		553A-11		444A-34
	334A-7		553B-11		444B-34
	334B-6		553C-11		444C-34
37721-95500	334C-6	37820-93J04	553D-11	37850-93J10	444D-34
	334D-7		530A-9		444E-34
	334E-6		530B-9		444F-34
	334F-6		530C-9		444A-32
	334G-6		530D-9		444B-32
37725-89L01	334H-7	37826-92J00	530E-9	37850-94JA3	444C-32
	334J-7		530F-9		444D-32
	334K-6		334A-2		444E-32
	334L-6		334B-2		444F-32
	334M-6		334C-2		444A-35
37725-89L01	450B-8	37820-93J04	334D-2	37850-94JA3	444B-35
	450D-8		334E-2		444C-35
	450F-8		334F-2		444D-35
	545A-11		334G-2		444E-35
	545B-11		334H-2		444F-35
37725-89L01	545C-11	37820-93J04	334J-2	37850-94JA3	450B-12
	545D-11		334K-2		450D-12
	545E-11		334L-2		450F-12
	545F-11		334M-2		544A-4
	545G-11		450A-7		544B-4
37725-89L01	545H-11	37820-93J04	450B-9	37850-94JA3	544C-4
	545J-11		450C-7		544D-4
	545K-11		450D-9		544E-4
	334A-11		450E-7		544F-4
	334B-10		450F-9		544G-4
37725-89L01	334C-10	37826-92J00	508A-7	37850-94JA3	544H-4
	334D-11		508B-7		544J-4
	334E-10		508C-7		544K-4
	334F-10		508D-7		327C-3
	334G-10		530A-10		327E-3

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
37850-99E04	450F-11	37851-89L00	327A-3	38500-93J90	508D-12
	508A-9		327B-3		450B-13
	508B-9		327D-3		450D-13
	508C-9		327C-10		450F-13
	508D-9		327E-10		530A-7
37852-94JA0	530A-12	37859-90J00	327C-4	38860-76F01	530A-27
	530A-25		327E-4		530B-7
	530B-12		450A-10		530B-27
	530B-25		450B-51		530C-7
	530C-12		450C-10		530C-27
37826-97J00	530C-25	37864-94J10	450D-51	38860-76F01	530D-7
	530D-12		450E-10		530D-27
	530D-25		450F-51		530E-7
	530E-12		508A-10		530E-27
	530E-25		508B-10		530F-7
37830-89L01	530F-12	38100-89LA1	508C-10	38915-90J00	530F-27
	530F-25		508D-10		301A-20
	444A-34		450A-11		310A-15
	444B-34		450C-11		310B-15
	444C-34		450E-11		310C-15
37835-95D00	444D-34	38410-93J20	508A-11	38915-90J00	310D-15
	444E-34		508B-11		310E-15
	444F-34		508C-11		310F-15
	444A-32		508D-11		310G-15
	444B-32		338A-14		310H-15
37850-90J06	444C-32	38415-89L00	338B-14	38915-90J00	310J-15
	444E-32		338C-14		310K-15
	444F-32		338D-14		310L-15
	444A-35		338E-14		310M-15
	444B-35		340A-1		561A-20
37850-93J10	444C-35	38500-93J00	340B-1	38915-90J00	561B-20
	444D-35		340C-1		561C-20
	444E-35		340D-1		561D-20
	444F-35		340E-1		301A-21
	450B-12		327A-1		310A-16
37850-94JA3	450D-12	38500-93J00	327B-1	38915-90J00	310B-16
	450F-12		327C-1		310C-16
	544A-4		327D-1		310D-16
	544B-4		327E-1		310E-16
	544C-4		327A-2		310F-16
37850-94JA3	544D-4	38500-93J00	327B-2	38915-90J00	310G-16
	544E-4		327C-2		310H-16
	544F-4		327D-2		310J-16
	544G-4		327E-2		310K-16
	544H-4		450A-12		310L-16
37850-94JA3	544J-4	38500-93J00	450C-12	38915-90J00	310M-16
	544K-4		450E-12		561A-21
	327C-3		508A-12		561B-21
	327E-3		508B-12		561C-21
			508C-12		561D-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
39600-89L00	553A-9 553B-9 553C-9 553D-9		335E-7 335K-7 513A-16 513B-16		335E-3 335H-3 335J-3 335K-3
39601-95D00	553A-12 553B-12		513C-16 513D-16	41212-91J00	335A-4 335B-4
39602-93900	553C-12 553D-12 553A-14 553B-14	41130-90L00	335A-7 335D-7 335H-7 335J-7		335C-5 335D-4 335E-4 335F-5
39950-88L02	553C-14 553D-14 600A-22 600B-22	41130-94JA1	335C-7 335F-7 335G-7 335L-7		335G-5 335H-4 335J-4 335K-4
	600C-22 600D-22 600E-22 600F-22	41135-93J11	335M-7 335C-8 335F-8 335G-8 335L-8	41213-94J01	335L-5 335M-5 335A-5 335B-5 335C-6
		41161-94400	335M-8 442A-1 442B-1 442C-1 442D-1		335D-5 335E-5 335F-6 335G-6 335H-5
40000			442E-1 442F-1 575A-1 575B-1 575C-1 575D-1		335J-5 335K-5 335L-6 335M-6 335C-14 335F-14
41111-89L00-YAY	335A-1 335B-1 335D-1 335E-1 335H-1			41221-94JA0	335G-14 335L-14 335M-14 335C-15 335F-15
	335J-1 335K-1 335C-1 335F-1 335G-1	41210-89LA0	335C-28 335F-28 335G-28 335L-28 335M-28	41222-94JA0	
	335L-1 335M-1 335A-2 335B-2 335D-2 335E-2	41210-99JL1	335A-25 335B-25 335D-25 335E-25 335H-25	41225-89L00	335G-15 335L-15 335M-15 336A-9 336B-9
	335E-2 335H-2 335J-2 335K-2 335C-2	41211-95J00	335J-25 335K-25 335C-4 335F-4 335G-4		336D-9 336E-9 336H-9 336J-9 336K-9
41121-89L00-YAY	335F-2 335G-2 335L-2 335M-2		335L-4 335M-4 335A-3 335B-3	41226-94JA0	335C-16 335F-16 335G-16 335L-16
41130-89L00	335B-7	41211-99JL0	335D-3		335M-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
43111-89L00-YAY	336A-2-1 336B-2-1 336D-2-1 336E-2-1		336H-19 336J-19 336K-19 336L-9	43517-89L00	336H-33 336J-33 336M-20 336A-34
	336H-2-1 336J-2-1 336K-2-1	43412-93900	336M-9 336A-20 336B-20 336C-10 336D-20		336D-34 336G-21 336H-34 336J-34 336M-21
43111-89L11-YAY	336A-2-2 336B-2-2 336D-2-2		336E-20 336F-10 336G-10 336H-20 336J-20	43711-94JA0	336C-3 336F-3 336G-3 336L-3 336M-3
	336E-2-2 336H-2-2 336J-2-2 336K-2-2		336C-2-2 336F-2-2 336G-2-2 336L-2-2 336M-2-2	43711-99J00	336A-3 336B-3 336D-3 336E-3 336H-3
43111-89LA0-YAY	336C-2-2 336F-2-2 336G-2-2 336L-2-2 336M-2-2	43415-89L00	336K-20 336L-10 336M-10 336A-28 336D-28		336J-3 336K-3 336A-4-1 336B-4-1 336C-4-1
43111-89LB0-YAY	336C-2-1 336F-2-1 336G-2-1 336L-2-1 336M-2-1	43420-89L00	336D-29 336G-16 336H-29 336J-29 336M-16	43750-99J60-YAY	336D-4-1 336E-4-1 336F-4-1 336G-4-1 336H-4-1
43112-99E00	405A-4 336A-7 336B-7 336C-7 336D-7		336E-7 336F-7 336G-7 336H-7 336J-7 336K-7	43425-89L00	336J-4-1 336K-4-1 336L-4-1 336M-4-1 336A-4-2 336B-4-2
43211-87JL0	336B-7 336C-7 336D-7 336E-7 336F-7 336G-7 336H-7 336J-7 336K-7	43512-89L00	336A-30 336D-30 336G-17 336H-30 336J-30 336M-17	43750-99J70-YAY	336C-4-2 336D-4-2 336E-4-2 336F-4-2 336G-4-2 336H-4-2
	336L-7 336M-7 336A-27 336D-27 336H-27 336J-27	43515-88L00	336A-31 336D-31 336G-18 336H-31 336J-31 336M-18		336J-4-2 336K-4-2 336L-4-2 336M-4-2
43411-89LA0	336G-14 336M-14 336A-19 336B-19		336C-32 336G-19 336H-32 336J-32 336M-19	43755-99J00	336B-27 336C-14 336E-27 336F-14 336K-27
43411-939L0	336C-9 336D-19 336E-19 336F-9 336G-9	43516-89J00	336A-33 336D-33 336G-20		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
43759-89L00	336L-14	45261-89L00	335A-13	48000-89LA1	336E-25
	513A-17		335B-13		336H-25
	513B-17		335D-13		336J-25
	513C-17		335E-13		336K-25
	513D-17		335H-13		338A-1
45212-89L00	336B-31	45269-89L00	335J-13	48121-94JA0	338B-1
	336C-18		335K-13		338C-1
	336E-31		335A-23		338D-1
	336F-18		335B-23		338E-1
	336K-31		335D-23		338A-16
45231-89L00	336L-18	45420-89L00	335E-23	48321-97E01	338B-16
	513A-18		335H-23		338C-16
	513B-18		335J-23		338D-16
	513C-18		335K-23		338E-16
	513D-18		335A-19		338A-17
45241-89L00	336A-10	45421-94JA0	335B-19	48510-94600	338B-17
	336B-10		335D-19		338C-17
	336D-10		335E-19		338D-17
	336E-10		335H-19		338E-17
	336H-10		335J-19		338A-18
45247-99J00	336J-10	45710-89L00	335K-19	48572-94J00	338B-18
	336K-10		335C-17		338C-18
	336A-11		335F-17		338D-18
	336B-11		335G-17		338E-18
	336D-11		335L-17		338A-5
45250-89L03	336E-11	45722-94J11	335M-17	48664-87D00	338B-5
	336H-11		335A-20		338C-5
	336J-11		335B-20		338D-5
	336K-11		335D-20		338E-5
	336A-12		335E-20		338A-4
45250-89L03	336B-12	45710-89L10	335H-20	48582-97E00	338B-4
	336D-12		335J-20		338C-4
	336E-12		335K-20		338D-4
	336H-12		336A-24-1		338E-4
	336J-12		336B-24-1		338A-8
45250-89L03	336K-12	45722-94J11	336D-24-1	48583-95E00	338B-8
	336A-14		336E-24-1		338C-8
	336B-14		336H-24-1		338D-8
	336D-14		336J-24-1		338E-8
	336E-14		336K-24-1		338A-13
45250-89L03	336H-14	45722-94J11	336A-24-2	48664-87D00	338B-13
	336J-14		336B-24-2		338C-13
	336K-14		336D-24-2		338D-13
	336A-15		336E-24-2		338E-13
	336B-15		336H-24-2		338A-6
45250-89L03	336D-15	45722-94J11	336J-24-2	48664-87D00	338B-6
	336E-15		336K-24-2		338C-6
	336H-15		336A-25		338D-6
	336J-15		336B-25		338E-6
	336K-15		336D-25		338A-9

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
48681-87J11	338A-15	55331-99J10	410B-18	55332-99J10	338E-19-2
	338B-9		410C-18		407A-23
	338B-15		410D-18		407B-24
	338C-9		410E-18		407A-21
	338C-15		410F-18		407B-21
48864-89LA0	338D-9	56120-99J41-YAY	410G-18	56130-99J30	407A-22
	338D-15		410H-18		407B-22
	338E-9		410J-18		407A-10
	338E-15		410K-18		407B-10
	338A-3		410L-18		220A-21
50000	338B-3	55321-87J01	410M-18	57100-90L30	220B-21
	338C-3		405A-10		220C-21
	338D-3		405A-11		220D-21
	338E-3		405A-12		220E-21
	338A-2		405A-14		220F-21
51110-89L02	338B-2	55321-87J11	405A-13	57100-90L40	220G-21
	338C-2		407A-1		220H-21
	338D-2		407B-1		220J-21
	338E-2		111A-7		220K-21
	401A-1		335C-20-1		220L-21
51211-89L00	401A-2	55321-87J11	335F-20-1	57100-90L40	220M-21
	405A-3-1		335G-20-1		220A-23
	405A-3-2		335L-20-1		220B-23
	405A-5		335M-20-1		220C-23
	405A-16		336C-20-1		220D-23
51211-89L00-YAY	401A-7	55321-87J11	336F-20-1	57100-90L40	220E-23
	401A-8		336G-25-1		220F-23
	401A-10		336L-20-1		220G-23
	401A-9		336M-25-1		220H-23
	401A-11		338A-19-1		220J-23
51211-89L00-YAY	401A-12	55321-87J11	338B-19-1	57100-90L40	220K-23
	410A-17		338C-19-1		220L-23
	410B-17		338D-19-1		220M-23
	410C-17		338E-19-1		220A-1-2
	410D-17		407A-6		220B-1-2
51211-89L00-YAY	410E-17	55321-87J11	407B-6	57100-90L40	220C-1-2
	410F-17		335C-20-2		220D-1-2
	410G-17		335F-20-2		220E-1-2
	410H-17		335G-20-2		220F-1-2
	410J-17		335L-20-2		220G-1-2
51211-89L00-YAY	410K-17	55321-87J11	335M-20-2	57100-90L40	220H-1-2
	410L-17		336C-20-2		220J-1-2
	410M-17		336F-20-2		220K-1-2
	410A-18		336G-25-2		220L-1-2
			336L-20-2		220M-1-2
54145-89L01		55321-87J11	336M-25-2	57100-90L40	220A-1-1
			338A-19-2		220B-1-1
			338B-19-2		220C-1-1
			338C-19-2		220D-1-1
			338D-19-2		220E-1-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
57100-90L50	220F-1-1	57610-99JL0	220H-10	57633-93901	220H-20
	220G-1-1		220J-10		220J-20
	220H-1-1		220K-10		220K-20
	220J-1-1		220L-10		220L-20
	220K-1-1		220M-10		220M-20
	220L-1-1		220A-14		407B-23
	220M-1-1		220B-14		58100-89L00-019
	220A-1-3		220C-14		58100-89L20-019
	220B-1-3		220D-14		58100-89L50-019
	220C-1-3		220E-14		58100-89L60-019
57311-99J10	220D-1-3	57621-99J11	220F-14	59262-94J00	407A-15-1
	220E-1-3		220G-14		407A-15-2
	220F-1-3		220H-14		407A-15-5
	220G-1-3		220J-14		407A-15-3
	220H-1-3		220K-14		407A-15-4
	220J-1-3		220L-14		407A-15-6
	220K-1-3		220M-14		407A-15-7
	220L-1-3		220A-15		407A-15-8
	220M-1-3		220B-15		407B-15
	220A-8		220C-15		407A-16
57510-99J11	220B-8	57631-93901	220D-15	59441-99J00	407B-16
	220C-8		220E-15		407A-8
	220D-8		220F-15		407B-8
	220E-8		220G-15		175A-13
	220F-8		220H-15		220A-17
	220G-8		220J-15		220B-17
	220H-8		220K-15		220C-17
	220J-8		220L-15		220D-17
	220K-8		220M-15		220E-17
	220L-8		220A-19		220F-17
57521-99J10	220M-8	57632-94J00	220B-19	59800-89L01	220G-17
	220A-9		220C-19		220H-17
	220B-9		220D-19		220J-17
	220C-9		220E-19		220K-17
	220D-9		220F-19		220L-17
	220E-9		220G-19		220M-17
	220F-9		220H-19		220A-18
	220G-9		220J-19		220B-18
	220H-9		220K-19		220C-18
	220J-9		220L-19		220D-18
57521-99J10	220K-9	57632-98501	220M-19	59800-89L01	220E-18
	220L-9		407A-17		220F-18
	220M-9		407B-17		220G-18
	220A-10		220A-20		220H-18
	220B-10		220B-20		220J-18
	220C-10		220C-20		220K-18
	220D-10		220D-20		220L-18
	220E-10		220E-20		220M-18
	220F-10		220F-20		420A-13
	220G-10		220G-20		420B-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
60000	420G-13	61151-91J11	410H-5	61433-89L01	410K-9
	420H-13		410J-5		410L-9
	420J-13		410K-5		410M-9
	420K-13		410L-5		420A-2
	420L-13		410M-5		420B-2
	420M-13		146A-43		420C-2
			146B-43		420D-2
			146C-43		420E-2
			146D-43		420F-2
			146E-43		420G-2
61112-89L10	410A-4	61400-89L40-YAY	410F-43	61435-89L10	420H-2
	410B-4		146G-43		420J-2
	410C-4		146H-43		420K-2
	410D-4		146J-43		420L-2
	410E-4		146K-43		420M-2
	410F-4		146L-43		420A-9
	410G-4		146M-43		420B-9
	410H-4		410A-14		420C-9
	410J-4		410B-14		420D-9
	410K-4		410C-14		420E-9
61124-89L20	410L-4	61400-89L40-YAY	410D-14	61435-89L30	420F-9
	410M-4		410E-14		420G-9
	410B-13		410F-14		420H-9
	410C-13		410G-14		420J-9
	410D-13		410H-14		420K-9
	410E-13		410I-14		420L-9
	410F-13		410J-14		420M-9
	410G-13		410K-14		420A-6
	410H-13		410L-14		420B-6
	410I-13		410M-14		420C-6
61124-89L30	410J-13	61412-89L00	420A-1	61446-89L10	420D-6
	410K-13		420B-1		420E-6
	410L-13		420C-1		420F-6
	410M-13		420D-1		420G-6
	410N-13		420E-1		420H-6
	410O-13		420F-1		420J-6
	410P-13		420G-1		420K-6
	410Q-13		420H-1		420L-6
	410R-13		420I-1		420M-6
	410S-13		420J-1		420A-10
61134-89L00	410T-13	61412-89L00	420K-1	61446-89L10	420B-10
	410U-13		420L-1		420C-10
	410V-13		420M-1		420D-10
	410W-13		420N-1		420E-10
	410X-13		420O-1		420F-10
	410Y-13		420P-1		420G-10
	410Z-13		420Q-1		420H-10
	410A-14		420R-1		420J-10
	410B-14		420S-1		420K-10
	410C-14		420T-1		420L-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61447-89L00	420M-10	61494-89L10	167J-13	61622-90L00	420L-5
	420C-15		167K-13		420M-5
	420F-15		167L-13		420A-4
	420G-15		167M-13		420B-4
61453-97L00	420L-15	61610-90L00	126A-12	61810-89L20-QGF	420C-4
	420M-15		126B-12		420D-4
	420A-7		126C-12		420E-4
	420B-7		126D-12		420F-4
61458-89L30	420C-7	61616-93EL0	126E-12	61820-89L00-QGF	420G-4
	420D-7		126F-12		420H-4
	420E-7		126G-12		420J-4
	420F-7		126H-13		420K-4
61471-89L00	420G-7	61619-89L00	126J-13	61827-89L00	420L-4
	420H-7		126K-13		420M-4
	420J-7		126L-13	61820-89L10-QGF	410A-1
	420K-7		126M-13		410B-1
61472-97J00	420L-7	61619-89L00	410A-10		410D-1
	420M-7		410B-10		410E-1
	420A-11		410C-10		410H-1
	420B-11		410D-10		410J-1
61477-89L00	420C-11	61619-89L00	410E-10	61820-89L10-QGF	410K-1
	420D-11		410F-10		410C-1
	420E-11		410G-10		410F-1
	420F-11		410H-10		410G-1
61478-89L00	420G-11	61619-89L00	410J-10	61820-89L10-QGF	410L-1
	420H-11		410K-10		410M-1
	420J-11		410L-10		410A-2
	420K-11		410M-10		410B-2
61479-89L00	420L-11	61619-89L00	410A-11	61820-89L10-QGF	410D-2
	420M-11		410B-11		410E-2
	420A-12		410C-11		410G-2
	420B-12		410D-11		410H-2
61480-89L00	420C-12	61619-89L00	410E-11	61820-89L10-QGF	410J-2
	420D-12		410F-11		410K-2
	420E-12		410G-11		410M-2
	420F-12		410H-11		410C-2
61481-89L00	420G-12	61619-89L00	410J-11	61820-89L10-QGF	410F-2
	420H-12		410K-11		410L-2
	420J-12		410L-11		410A-15
	420K-12		410M-11		410B-15
61482-89L00	420L-12	61619-89L00	420A-5	61820-89L10-QGF	410C-15
	420M-12		420B-5		410D-15
	167A-13		420C-5		410E-15
	167B-13		420D-5		410F-15
61483-89L00	167C-13	61619-89L00	420E-5	61820-89L10-QGF	410G-15
	167D-13		420F-5		410H-15
	167E-13		420G-5		410J-15
	167F-13		420H-5		410K-15
61484-89L00	167G-13	61619-89L00	420J-5	61820-89L10-QGF	410L-15
	167H-13		420K-5		410M-15

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
61831-89L00-QGF	410A-6	63131-99J11-YAY	444C-23	63241-986B0	444E-10
	410B-6		444D-23		444F-10
	410C-6		444E-23		444A-11
	410D-6		444F-23		444B-11
63111-89L00-YAY	410E-6	63133-89L00	444A-24	63244-94J00	444C-11
	410F-6		444B-24		444D-11
	410G-6		444C-24		444E-11
	410H-6		444D-24		444F-11
63114-99J01	410J-6	63210-89L11	444E-24	63610-89L00	444A-12
	410K-6		444F-24		444B-12
	410L-6		444A-25		444C-12
	410M-6		444B-25		444D-12
63115-99J00	444A-1	63215-93110	444C-25	65000-89L10	444E-12
	444B-1		444D-25		444F-12
	444C-1		444E-25		444A-14
	444D-1		444F-25		444B-14
63115-99J10	444E-1	63220-89L00	444A-6	65000-95D01	444C-14
	444F-1		444B-6		444D-14
	444A-22		444C-6		444E-14
	444B-22		444D-6		444F-14
63116-99J00	444C-22	63225-93200	444E-6	65000-95D01	444A-15
	444D-22		444F-6		444B-15
	444E-22		444A-31		444C-15
	444F-22		444B-31		444D-15
63116-99J10	444A-3	63225-98601	444C-31	65000-95D01	444E-15
	444B-3		444D-31		444F-15
	444C-3		444E-31	65000-89L10	432A-1
	444D-3		444F-31		583A-1
63121-99J00-YAY	444E-3	63240-94J10	444A-7	65000-89L30	583A-2
	444F-3		444B-7		432A-2
	444A-2		444C-7		432A-3
	444B-2		444D-7		583A-3
63122-99J00	444C-2	63240-94J10	444E-7	65000-89L30	583A-8
	444D-2		444F-7		432A-8
	444E-2		444A-9	65000-89L30	432A-13
	444F-2		444B-9		432A-7
63122-99J00	444A-4	63240-94J10	444C-9	65000-89L30	583A-4
	444B-4		444D-9		432A-9
	444C-4		444E-9		583A-9
	444D-4		444F-9		432A-10
63122-99J00	444E-4	63240-94J10	444A-8	65000-89L30	583A-10
	444F-4		444B-8		432A-11
	444A-5		444C-8		583A-11
	444B-5		444D-8		432A-12
63122-99J00	444C-5	63240-94J10	444E-8	65000-89L30	583A-12
	444D-5		444F-8		444A-26
	444E-5		444A-10		444B-26
	444F-5		444B-10		444C-26
63122-99J00	444A-23	63240-94J10	444C-10	65000-89L30	444D-26
	444B-23		444D-10		444E-26

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
65831-95D00	444F-26	67211-93J00	508D-1	67223-92E00	545C-2
	432A-4		544A-27		545D-2
	583A-5		544B-27		545E-2
	583A-6		544C-27		545F-2
65890-95D00	432A-5	67130-89L04	544D-27	67223-92E00	545G-2
65890-99100	432A-6		544E-27		545H-2
65892-95D00	583A-7		544F-27		545J-2
67130-89L04	513A-1		544G-27		545K-2
	513B-1	67140-95600	544H-27	67223-92E00	545A-3
	513C-1		544J-27		545B-3
	513D-1		544K-27		545C-3
67140-95600	515A-1	67212-95600	450A-13	67223-92E00	545D-3
	515B-1		450B-14		545E-3
	515C-1		450C-13		545F-3
	515D-1		450D-14		545G-3
67200-93J13	515E-1	67214-92E00	450E-13	67223-99E10	545H-3
	515F-1		450F-14		545J-3
	515G-1		508A-13		545K-3
	515H-1		508B-13		450A-16
67200-93J13	515J-1	67214-92E00	508C-13	67224-92E00	450B-17
	515K-1		508D-13		450C-16
	544A-1		450A-14		450D-17
	544B-1	67220-95630	450C-14		450E-16
67200-93J13	544C-1		450E-14	67224-92E00	450F-17
	544D-1		508A-14		508A-16
	544E-1		508B-14		508B-16
	544F-1		508C-14		508C-16
67200-93J13	544G-1	67220-95630	508D-14	67224-92E00	508D-16
	544H-1		450A-15		545A-9
	544J-1		450B-16		545B-9
	544K-1		450C-15		545C-9
67200-93J51	545A-1	67221-92E00	450D-16	67226-92E00	545D-9
	545B-1		450E-15		545E-9
	545C-1		450F-16		545F-9
	545D-1		508A-15		545G-9
67200-93J51	545E-1	67221-92E00	508B-15	67226-92E00	545H-9
	545F-1		508C-15		545J-9
	545G-1		508D-15		545K-9
	545H-1		545A-8		545A-15
67200-93J51	545J-1	67222-92E00	545B-8	67226-92E10	545B-15
	545K-1		545C-8		545C-15
	450B-1		545D-8		545D-15
	450D-1		545E-8		545E-15
67200-94J20	450F-1	67222-92E00	545F-8	67226-92E10	545F-15
	450A-1		545G-8		545G-15
	450C-1		545H-8		545H-15
	450E-1		545J-8		545J-15
67200-94J20	508A-1	67222-92E00	545K-8	67226-92E10	545K-15
	508B-1		545A-2		545A-16
	508C-1		545B-2		545B-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67227-92E00	545C-16	67232-95600	545C-41	67235-92E00	545C-22
	545D-16		545D-41		545D-22
	545E-16		545E-41		545E-22
	545F-16		545F-41		545F-22
67227-92E00	545G-16	67232-95600	545G-41	67235-92E00	545G-22
	545H-16		545H-41		545H-22
	545J-16		545J-41		545J-22
	545K-16		545K-41		545K-22
67227-92E00	545A-24	67232-95600	450A-18	67235-92E00	545A-27
	545B-24		450B-19		545B-27
	545C-24		450C-18		545C-27
	545D-24		450D-19		545D-27
67228-92E00	545E-24	67232-95600	450E-18	67235-92E00	545E-27
	545F-24		450F-19		545F-27
	545G-24		508A-18		545G-27
	545H-24		508B-18		545H-27
67228-92E00	545J-24	67232-95600	508C-18	67235-92E00	545J-27
	545K-24		508D-18		545K-27
	545A-18		545A-42		545A-32
	545B-18		545B-42		545B-32
67229-95600	545C-18	67232-95620	545C-42	67237-92E01	545C-32
	545D-18		545D-42		545D-32
	545E-18		545E-42		545E-32
	545F-18		545F-42		545F-32
67229-95600	545G-18	67232-95620	545G-42	67237-92E01	545G-32
	545H-18		545H-42		545H-32
	545J-18		545J-42		545J-32
	545K-18		545K-42		545K-32
67229-95600	450A-17	67232-95620	545A-28	67237-92E01	545A-33
	450B-18		545B-28		545B-33
	450C-17		545C-28		545C-33
	450D-18		545D-28		545D-33
67230-92E00	450E-17	67233-92E00	545E-28	67238-87D00	545E-33
	450F-18		545F-28		545F-33
	508A-17		545G-28		545G-33
	508B-17		545H-28		545H-33
67230-92E00	508C-17	67233-92E00	545J-28	67238-87D00	545J-33
	508D-17		545K-28		545K-33
	545A-20		545A-26		450A-19
	545B-20		545B-26		450B-20
67231-92E00	545C-20	67234-92E00	545C-26	67238-92E00	450C-19
	545D-20		545D-26		450D-20
	545E-20		545E-26		450E-19
	545F-20		545F-26		450F-20
67231-92E00	545G-20	67234-92E00	545G-26	67238-92E00	508A-19
	545H-20		545H-26		508B-19
	545J-20		545J-26		508C-19
	545K-20		545K-26		508D-19
67231-92E00	545A-41	67234-92E00	545A-22	67238-92E00	545A-34
	545B-41		545B-22		545B-34

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67239-92E00	545C-34	67243-92E00	450C-20	67246-92E00	450C-23
	545D-34		450D-21		450D-24
	545E-34		450E-20		450E-23
	545F-34		450F-21		450F-24
	545G-34		508A-20		508A-23
	545H-34		508B-20		508B-23
	545J-34		508C-20		508C-23
	545K-34		508D-20		508D-23
	545A-35		545A-44		545A-36
	545B-35		545B-44		545B-36
67239-92E10	545C-35	67243-95600	545C-44	67251-93J00	545C-36
	545D-35		545D-44		545D-36
	545E-35		545E-44		545E-36
	545F-35		545F-44		545F-36
	545G-35		545G-44		545G-36
	545H-35		545H-44		545H-36
	545J-35		545J-44		545J-36
	545K-35		545K-44		545K-36
	545A-45		450A-21		544A-12
	545B-45		450B-22		544B-12
67240-92E00	545C-45	67244-95600	450C-21	67251-99E20	544C-12
	545D-45		450D-22		544D-12
	545E-45		450E-21		544E-12
	545F-45		450F-22		544F-12
	545G-45		508A-21		544G-12
	545H-45		508B-21		544H-12
	545J-45		508C-21		544J-12
	545K-45		508D-21		544K-12
	545A-17		450A-22		450A-24
	545B-17		450B-23		450B-25
67241-92E10	545C-17	67245-92E00	450C-22	67252-92E10	450C-24
	545D-17		450D-23		450D-25
	545E-17		450E-22		450E-24
	545F-17		450F-23		450F-25
	545G-17		508A-22		508A-24
	545H-17		508B-22		508B-24
	545J-17		508C-22		508C-24
	545K-17		508D-22		508D-24
	545A-43		545A-23		545A-39
	545B-43		545B-23		545B-39
67241-99E10	545C-43	67245-95600	545C-23	67252-95600	545C-39
	545D-43		545D-23		545D-39
	545E-43		545E-23		545E-39
	545F-43		545F-23		545F-39
	545G-43		545G-23		545G-39
	545H-43		545H-23		545H-39
	545J-43		545J-23		545J-39
	545K-43		545K-23		545K-39
	450A-20		450A-23		450A-25
	450B-21		450B-24		450B-26

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67253-92E00	450C-25	67256-95600	450C-27	67261-93J00	450C-31
	450D-26		450D-28		450D-32
	450E-25		450E-27		450E-31
	450F-26		450F-28		450F-32
	508A-25		508A-27		508A-31
	508B-25		508B-27		508B-31
	508C-25		508C-27		508C-31
	508D-25		508D-27		508D-31
	544A-15		450A-28		544A-2
	544B-15		450B-29		544B-2
67253-92E10	544C-15	67257-92E00	450C-28	67261-99E10	544C-2
	544D-15		450D-29		544D-2
	544E-15		450E-28		544E-2
	544F-15		450F-29		544F-2
	544G-15		508A-28		544G-2
	544H-15		508B-28		544H-2
	544J-15		508C-28		544J-2
	544K-15		508D-28		544K-2
	545A-38		544A-11		450A-32
	545B-38		544B-11		450B-33
67253-95600	545C-38	67257-99E10	544C-11	67263-93J00	450C-32
	545D-38		544D-11		450D-33
	545E-38		544E-11		450E-32
	545F-38		544F-11		450F-33
	545G-38		544G-11		508A-32
	545H-38		544H-11		508B-32
	545J-38		544J-11		508C-32
	545K-38		544K-11		508D-32
	450A-26		450A-29		544A-3
	450B-27		450B-30		544B-3
67258-99E00	450C-26	67259-87D00	450C-29	67264-95600	544C-3
	450D-27		450D-30		544D-3
	450E-26		450E-29		544E-3
	450F-27		450F-30		544F-3
	508A-26		508A-29		544G-3
	508B-26		508B-29		544H-3
	508C-26		508C-29		544J-3
	508D-26		508D-29		544K-3
	545A-40		450A-30		450A-34
	545B-40		450B-31		450B-35
67255-99E10	545C-40	67259-87D00	450C-30	67267-93J00	450C-34
	545D-40		450D-31		450D-35
	545E-40		450E-30		450E-34
	545F-40		450F-31		450F-35
	545G-40		508A-30		508A-34
	545H-40		508B-30		508B-34
	545J-40		508C-30		508C-34
	545K-40		508D-30		508D-34
	450A-27		450A-31		450A-35
	450B-28		450B-32		450B-36

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67269-92E00	450C-35	67274-92E00	544C-22	67284-94L00	450C-38
	450D-36		544D-22		450D-52
	450E-35		544E-22		450E-38
	450F-36		544F-22		450F-52
	508A-35		544G-22		508A-38
	508B-35		544H-22		508B-38
	508C-35		544J-22		508C-38
	508D-35		544K-22		508D-38
	545A-29		544A-24		450A-39
	545B-29		544B-24		450B-53
67271-92E00	545C-29	67275-95600	544C-24	67286-92E00	450C-39
	545D-29		544D-24		450D-53
	545E-29		544E-24		450E-39
	545F-29		544F-24		450F-53
	545G-29		544G-24		508A-39
	545H-29		544H-24		508B-39
	545J-29		544J-24		508C-39
	545K-29		544K-24		508D-39
	544A-26		450A-37		545A-19
	544B-26		450B-38		545B-19
67273-92E00	544C-26	67287-92E00	450C-37	67288-92E00	545C-19
	544D-26		450D-38		545D-19
	544E-26		450E-37		545E-19
	544F-26		450F-38		545F-19
	544G-26		508A-37		545G-19
	544H-26		508B-37		545H-19
	544J-26		508C-37		545J-19
	544K-26		508D-37		545K-19
	544A-23		544A-21		544A-20
	544B-23		544B-21		544B-20
67273-95600	544C-23	67281-93J00	544C-21	67288-92E00	544C-20
	544D-23		544D-21		544D-20
	544E-23		544E-21		544E-20
	544F-23		544F-21		544F-20
	544G-23		544G-21		544G-20
	544H-23		544H-21		544H-20
	544J-23		544J-21		544J-20
	544K-23		544K-21		544K-20
	450A-36		544A-17		545A-4
	450B-37		544B-17		545B-4
67282-94L00	450C-36	67282-94L00	544C-17	67288-92E10	545C-4
	450D-37		544D-17		545D-4
	450E-36		544E-17		545E-4
	450F-37		544F-17		545F-4
	508A-36		544G-17		545G-4
	508B-36		544H-17		545H-4
	508C-36		544J-17		545J-4
	508D-36		544K-17		545K-4
	544A-22		450A-38		545A-6
	544B-22		450B-52		545B-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67288-92E20	545C-6	67292-94300	545C-37	67295-92E00	515C-2
	545D-6		545D-37		515D-2
	545E-6		545E-37		515E-2
	545F-6		545F-37		515F-2
	545G-6		545G-37		515G-2
	545H-6		545H-37		515H-2
	545J-6		545J-37		515J-2
	545K-6		545K-37		515K-2
	544A-7		450A-40		544A-8
	544B-7		450B-39		544B-8
67288-92E30	544C-7	67294-92E00	450C-40	67296-88D10	544C-8
	544D-7		450D-39		544D-8
	544E-7		450E-40		544E-8
	544F-7		450F-39		544F-8
	544G-7		508A-40		544G-8
	544H-7		508B-40		544H-8
	544J-7		508C-40		544J-8
	544K-7		508D-40		544K-8
	544A-14		545A-5		544A-5
	544B-14		545B-5		544B-5
67288-92E40	544C-14	67294-92E00	545C-5	67296-88D10	544C-5
	544D-14		545D-5		544D-5
	544E-14		545E-5		544E-5
	544F-14		545F-5		544F-5
	544G-14		545G-5		544G-5
	544H-14		545H-5		544H-5
	544J-14		545J-5		544J-5
	544K-14		545K-5		544K-5
	544A-10		545A-10		544A-6
	544B-10		545B-10		544B-6
67291-92E00	544C-10	67294-95600	545C-10	67294-95600	544C-6
	544D-10		545D-10		544D-6
	544E-10		545E-10		544E-6
	544F-10		545F-10		544F-6
	544G-10		545G-10		544G-6
	544H-10		545H-10		544H-6
	544J-10		545J-10		544J-6
	544K-10		545K-10		544K-6
	545A-7		450A-41		545A-13
	545B-7		450B-40		545A-30
67291-92E10	545C-7	67291-92E10	450C-41	67291-92E10	545B-13
	545D-7		450D-40		545B-30
	545E-7		450E-41		545C-13
	545F-7		450F-40		545C-30
	545G-7		508A-41		545D-13
	545H-7		508B-41		545D-30
	545J-7		508C-41		545E-13
	545K-7		508D-41		545E-30
	545A-37		515A-2		545F-13
	545B-37		515B-2		545F-30

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67296-90J10	545G-13	67296-92E60	544K-18	67296-95600	508D-33
	545G-30		544A-13		450A-44
	545H-13		544B-13		450B-43
	545H-30		544C-13		450C-44
	545J-13		544D-13		450D-43
	545J-30		544E-13		450E-44
	545K-13		544F-13		450F-43
	545K-30		544G-13		508A-44
	450A-42		544H-13		508B-44
	450B-41		544J-13		508C-44
67296-92E11	450C-42	67296-92E70	544K-13	67296-95610	508D-44
	450D-41		544A-9		450A-45
	450E-42		544A-28		450B-44
	450F-41		544B-9		450C-45
	508A-42		544B-28		450D-44
	508B-42		544C-9		450E-45
	508C-42		544C-28		450F-44
	508D-42		544D-9		508A-45
	450B-15		544D-28		508B-45
	450D-15		544E-9		508C-45
67296-92E20	450F-15	67296-94300	544E-28	67296-95621	508D-45
	545A-12		544F-9		544A-25
	545B-12		544F-28		544B-25
	545C-12		544G-9		544C-25
	545D-12		544G-28		544D-25
	545E-12		544H-9		544E-25
	545F-12		544H-28		544F-25
	545G-12		544J-9		544G-25
	545H-12		544J-28		544H-25
	545J-12		544K-9		544J-25
67296-92E30	545K-12	67296-94310	544K-28	67297-95600	544K-25
	545A-14		450A-43		515A-3
	545B-14		450B-42		515B-3
	545C-14		450C-43		515C-3
	545D-14		450D-42		515D-3
	545E-14		450E-43		515E-3
	545F-14		450F-42		515F-3
	545G-14		508A-43		515G-3
	545H-14		508B-43		515H-3
	545J-14		508C-43		515J-3
67296-92E30	545K-14	67296-94310	508D-43	67297-95600	515K-3
	544A-18		450A-33		450A-46
	544B-18		450B-34		450B-45
	544C-18		450C-33		450C-46
	544D-18		450D-34		450D-45
	544E-18		450E-33		450E-46
	544F-18		450F-34		450F-45
	544G-18		508A-33		508A-46
	544H-18		508B-33		508B-46
	544J-18		508C-33		508C-46

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67320-93J00	508D-46	67320-93J50	515K-4-5	67467-89J01	513D-22
	515A-4-1		515A-4-6		166A-11
	515B-4-1		515B-4-6		166B-11
	515C-4-1		515C-4-6		166C-11
	515D-4-1		515D-4-6		166D-11
	515E-4-1		515E-4-6		166E-11
	515F-4-1		515F-4-6		166F-11
	515G-4-1		515G-4-6		206B-18
	515H-4-1		515H-4-6		206C-18
	515J-4-1		515J-4-6		206E-18
67320-93J10	515K-4-1	67320-93J60	515K-4-6	67500-93J00	206F-18
	515A-4-2		515A-4-7		206K-18
	515B-4-2		515B-4-7		206L-18
	515C-4-2		515C-4-7		513A-23
	515D-4-2		515D-4-7		513B-23
	515E-4-2		515E-4-7		513C-23
	515F-4-2		515F-4-7		513D-23
	515G-4-2		515G-4-7		544A-29
	515H-4-2		515H-4-7		544B-29
	515J-4-2		515J-4-7		544C-29
67320-93J20	515K-4-2	67320-93J70	515K-4-7	67701-99J02	544D-29
	515A-4-3		515A-4-8		544E-29
	515B-4-3		515B-4-8		544F-29
	515C-4-3		515C-4-8		544G-29
	515D-4-3		515D-4-8		544H-29
	515E-4-3		515E-4-8		544J-29
	515F-4-3		515F-4-8		544K-29
	515G-4-3		515G-4-8		442A-2
	515H-4-3		515H-4-8		442B-2
	515J-4-3		515J-4-8		442C-2
67320-93J30	515K-4-3	67320-93J80	515K-4-8	67721-93E10	442D-2
	515A-4-4		515A-4-9		442E-2
	515B-4-4		515B-4-9		442F-2
	515C-4-4		515C-4-9		575A-2
	515D-4-4		515D-4-9		575B-2
	515E-4-4		515E-4-9		575C-2
	515F-4-4		515F-4-9		575D-2
	515G-4-4		515G-4-9		442A-3
	515H-4-4		515H-4-9		442B-3
	515J-4-4		515J-4-9		442C-3
67320-93J40	515K-4-4	67340-89L00	515K-4-9	67725-96J00	442D-3
	515A-4-5		206B-21		442E-3
	515B-4-5		206C-21		442F-3
	515C-4-5		206E-21		575A-3
	515D-4-5		206F-21		575B-3
	515E-4-5		206K-21		575C-3
	515F-4-5		206L-21		575D-3
	515G-4-5		513A-22		442A-4
	515H-4-5		513B-22		442B-4
	515J-4-5		513C-22		442C-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	442D-4		167M-12	99000-81158-50M	167A-8
	442E-4	69911-91J50	335A-24		167B-8
	442F-4		335B-24		167C-8
	575A-4		335C-27		167D-8
	575B-4		335D-24		167E-8
67726-99E00	575C-4		335E-24		167F-8
	575D-4		335F-27		167G-8
	442A-5		335G-27		167H-8
	442B-5		335H-24		167J-8
	442C-5		335J-24		167K-8
	442D-5		335K-24		167L-8
	442E-5		335L-27		167M-8
	442F-5		335M-27	99011-89L40-055	420A-14
	575A-5				420B-14
	575B-5				420C-14
67728-99E00	575C-5				420D-14
	575D-5	70000			420E-14
	442A-6				420F-14
	442B-6				420G-14
	442C-6				420H-14
	442D-6	77811-54GB0-0PG	420A-8		420J-14
	442E-6		420B-8		420K-14
	442F-6		420C-8		420L-14
	575A-6		420D-8		420M-14
	575B-6		420E-8		
	575C-6		420F-8		
68110-89L00	575D-6		420G-8		
	420A-15		420H-8	00000	
	420B-15		420J-8		
	420C-16		420K-8		
	420D-15		420L-8	01547-06167	513A-33
	420E-15		420M-8		513B-33
	420F-16		450A-47		513C-33
	420G-16		450B-46		513D-33
	420H-15		450C-47		561A-17
	420J-15		450D-46		561B-17
	420K-15		450E-47		561C-17
	420L-16		450F-46		561D-17
69711-93E10	420M-16		508A-47	01547-0616C	206B-22
	167A-12		508B-47		206C-22
	167B-12		508C-47		206E-22
	167C-12		508D-47		206F-22
	167D-12				206K-22
	167E-12				206L-22
	167F-12				322A-4
	167G-12				322D-4
	167H-12				322G-4
	167J-12	90000			322H-4
	167K-12				322J-4
	167L-12				322M-4

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
01547-0625A	303E-2		206E-15		146C-20
	561A-10		206F-9		146D-20
	561B-10		206F-15		146E-20
	561C-10		206G-17		146F-20
	561D-10		206H-17		146G-20
01547-0630A	303A-2		206J-17		146H-20
	303B-2		206K-9		146J-20
	303C-2		206K-15		146K-20
	303D-2		206L-9		146L-20
01550-05127	303A-3		206L-15		146M-20
	303B-3		206M-17		166A-10
	303C-3		322A-20		166B-10
	303D-3		322B-15		166C-10
	303E-3		322C-15		166D-10
01550-06127	322A-21		322D-20		166E-10
	322B-16		322E-15		166F-10
	322C-16		322F-15		334A-9
	322D-21		322G-20		334B-8
	322E-16		322H-20		334C-8
	322F-16		322J-20		334D-9
	322G-21		322K-15		334E-8
	322H-21		322L-15		334F-8
	322J-21		322M-20		334G-8
	322K-16	01550-06167	303A-10		334H-9
	322L-16		303B-10		334J-9
	322M-21		303C-10		334K-8
	513A-34		303D-10		334L-8
	513B-34		303E-10		334M-8
	513C-34		310A-8	01550-06207	310A-7
	513D-34		310B-8		310B-7
01550-0612C	163A-8		310C-8		310C-7
	163D-8		310D-8		310D-7
	163G-8		310E-8		310E-7
	163H-8		310F-8		310F-7
	163J-8		310G-8		310G-7
	163M-8		310H-8		310H-7
	166A-9		310J-8		310J-7
	166B-9		310K-8		310K-7
	166C-9		310L-8		310L-7
	166D-9		310M-8		310M-7
	166E-9		513A-35		553A-6
	166F-9		513B-35		553B-6
	175A-8		513C-35		553C-6
	206A-17		513D-35		553D-6
	206B-9		561A-8		561A-9
	206B-15		561B-8		561B-9
	206C-9		561C-8		561C-9
	206C-15		561D-8		561D-9
	206D-17	01550-0616C	146A-20	01550-0620C	111A-15
	206E-9		146B-20		146A-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	146B-21		146A-11		310C-12
	146C-21		146A-22		310D-12
	146D-21		146B-11		310E-12
	146E-21		146B-22		310F-12
	146F-21		146C-11		310G-12
	146G-21		146C-22		310H-12
	146H-21		146D-11		310J-12
	146J-21		146D-22		310K-12
	146K-21		146E-11		310L-12
	146L-21		146E-22		310M-12
	146M-21		146F-11	01550-06357	113A-2
	162A-3		146F-22		120A-14
	163A-9		146G-11	01550-0650C	144A-9
	163B-7		146G-22	01550-08207	113A-7
	163C-7		146H-11		301A-22
	163D-9		146H-22		553A-5
	163E-7		146J-11		553B-5
	163F-7		146J-22		553C-5
	163G-9		146K-11		553D-5
	163H-9		146K-22	01550-0820C	111A-9
	163J-9		146L-11	01550-08307	301A-23
	163K-7		146L-22	01560-08307	401A-15
	163L-7		146M-11	01560-08757	113A-3
	163M-9		146M-22	01580-08407	126A-3
	167A-11		206A-18		126B-3
	167B-11		206B-16		126C-3
	167C-11		206C-16		126D-3
	167D-11		206D-18		126E-3
	167E-11		206E-16		126F-3
	167F-11		206F-16		126G-3
	167G-11		206G-18		126H-3
	167H-11		206H-18		126J-3
	167J-11		206J-18		126K-3
	167K-11		206K-16		126L-3
	167L-11		206L-16		126M-3
	167M-11		206M-18	02122-04127	120A-15
	175A-7	01550-0630C	167A-9	02122-0630A	175A-14
	334A-15		167B-9	02142-0616C	410A-16
	334B-14		167C-9		410B-16
	334C-14		167D-9		410C-16
	334D-15		167E-9		410D-16
	334E-14		167F-9		410E-16
	334F-14		167G-9		410F-16
	334G-14		167H-9		410G-16
	334H-15		167J-9		410H-16
	334J-15		167K-9		410J-16
	334K-14		167L-9		410K-16
	334L-14		167M-9		410L-16
	334M-14		310A-12		410M-16
01550-0625C	120A-13		310B-12	02142-06207	206A-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	206B-17		420K-3		120A-10
	206C-17		420L-3		303A-7
	206D-19		420M-3		303B-7
	206E-17	03542-06209	146A-23		303C-7
	206F-17		146B-23		303D-7
	206G-19		146C-23	09100-06178	303E-7
	206H-19		146D-23		335A-9
	206J-19		146E-23		335B-9
	206K-17		146F-23		335D-9
	206L-17		146G-23		335E-9
	206M-19		146H-23		335H-9
03112-0630B	501A-11		146J-23		335J-9
	501B-11		146K-23	09100-08232	335K-9
	501C-11		146L-23		336A-23
	501D-11		146M-23		336B-23
	501E-11	04211-09149	120A-12		336C-13
	501F-11	04211-11129	111A-12		336D-23
03121-0516A	530A-26		113A-4		336E-23
	530B-26	04221-05109	126A-4		336F-13
	530C-26		126B-4		336G-13
	530D-26		126C-4		336H-23
	530E-26		126D-4		336J-23
03122-05165	530F-26		126E-4		336K-23
	530A-14		126F-4		336L-13
	530B-14		126G-4		336M-13
	530C-14		126H-4		450A-48
	530D-14		126J-4		450B-47
	530E-14		126K-4		450C-48
	530F-14		126L-4		450D-47
03142-04169	160A-12		126M-4		450E-48
	160B-12	08110-60020	220A-2		450F-47
	160C-12		220B-2		508A-48
	160D-12		220C-2		508B-48
	160E-12		220D-2		508C-48
	160F-12		220E-2		508D-48
	160G-12		220F-2	09100-08311	335A-15
	160H-12		220G-2		335B-15
	160J-12		220H-2		335C-24
	160K-12		220J-2		335D-15
	160L-12		220K-2		335E-15
	160M-12		220L-2		335F-24
03542-05169	420A-3		220M-2		335G-24
	420B-3	08110-60050	407A-11		335H-15
	420C-3		407B-11		335J-15
	420D-3	08316-10087	301A-24		335K-15
	420E-3	08322-0106A	303A-11		335L-24
	420F-3		303B-11		335M-24
	420G-3		303C-11	09103-06237	432A-14
	420H-3		303D-11	09103-06267	120A-7
	420J-3	08341-31039	120A-9	09103-06281	111A-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	335C-21		310E-3	09116-06517	126A-7
	335F-21		310F-3		126B-7
	335G-21		310G-3		126C-7
	335L-21		310H-3		126D-7
	335M-21		310J-3		126E-7
	336C-21		310K-3		126F-7
	336F-21		310L-3		126G-7
	336G-26		310M-3		126H-9
	336L-21	09116-06225	336A-35		126J-9
	336M-26		336B-32		126K-9
	338A-20		336C-19		126L-9
	338B-20		336D-35		126M-9
	338C-20		336E-32		146A-12
	338D-20		336F-19		146B-12
	338E-20		336G-22		146C-12
	407A-7		336H-35		146D-12
09108-06141	407B-7		336J-35		146E-12
	160A-14		336K-32		146F-12
	160B-14		336L-19		146G-12
	160C-14		336M-22		146H-12
	160D-14		444A-27		146J-12
	160E-14		444B-27		146K-12
	160F-14		444C-27		146L-12
	160G-14		444D-27		146M-12
	160H-14		444E-27		327A-4
	160J-14		444F-27		327B-4
	160K-14		513A-25		327C-8
	160L-14		513B-25		327D-4
	160M-14		513C-25		327E-8
09108-08286	336B-29		513D-25	09116-08128	335C-18
	336C-16	09116-06227	407A-14		335F-18
	336E-29		407B-14		335G-18
	336F-16	09116-06229	220A-24		335L-18
	336K-29		220B-24		335M-18
	336L-16		220C-24	09116-08137	401A-13
	513A-24		220D-24	09116-08150	338A-21
	513B-24		220E-24		338B-21
	513C-24		220F-24		338C-21
	513D-24		220G-24		338D-21
09111-10067	336A-26		220H-24		338E-21
	336B-26		220J-24	09116-08151	401A-3
	336D-26		220K-24		405A-6
	336E-26		220L-24		405A-17
	336H-26		220M-24		407A-5
	336J-26	09116-06234	206A-9		407B-5
	336K-26		206D-9		444A-16
09116-06196	310A-3		206G-9		444B-16
	310B-3		206H-9		444C-16
	310C-3		206J-9		444D-16
	310D-3		206M-9		444E-16

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	444F-16		508B-49		410J-3
09116-08154	405A-15		508C-49		410K-3
09116-08155	444A-28		508D-49		410L-3
	444B-28	09126-06006	545A-25	09140-05005	410M-3
	444C-28		545B-25		327C-7
	444D-28		545C-25		327E-7
	444E-28		545D-25		544A-32
	444F-28		545E-25		544B-32
09119-08L01	111A-4		545F-25		544C-32
09119-08L02	111A-3		545G-25		544D-32
09125-05042	444A-29		545H-25		544E-32
	444B-29		545J-25		544F-32
	444C-29		545K-25		544G-32
	444D-29	09126-06026	444A-17		544H-32
	444E-29		444B-17		544J-32
	444F-29		444C-17		544K-32
	545A-21		444D-17	09140-06020	450A-50
	545B-21		444E-17		450B-49
	545C-21		444F-17		450C-50
	545D-21	09136-05041	340A-8		450D-49
	545E-21		340B-8		450E-50
	545F-21		340C-8		450F-49
	545G-21		340D-8		508A-50
	545H-21		340E-8		508B-50
	545J-21		444A-18		508C-50
	545K-21		444B-18		508D-50
09125-05046	327C-5		444C-18		545A-31
	327E-5		444D-18		545B-31
09125-05135	544A-30		444E-18		545C-31
	544B-30		444F-18		545D-31
	544C-30	09136-06168	410A-8		545E-31
	544D-30		410B-8		545F-31
	544E-30		410C-8		545G-31
	544F-30		410D-8		545H-31
	544G-30		410E-8		545J-31
	544H-30		410F-8		545K-31
	544J-30		410G-8	09140-08023-XC0	335A-16
	544K-30		410H-8		335B-16
09125-06063	335C-12		410J-8		335C-25
	335F-12		410K-8		335D-16
	335G-12		410L-8		335E-16
	335L-12		410M-8		335F-25
	335M-12	09136-06169	410A-3		335G-25
09126-05003	450A-49		410B-3		335H-16
	450B-48		410C-3		335J-16
	450C-49		410D-3		335K-16
	450D-48		410E-3		335L-25
	450E-49		410F-3		335M-25
	450F-48		410G-3	09140-10031	401A-14
	508A-49		410H-3	09140-14008	303A-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09141-12005	303B-5	09160-05029	544G-19		166E-12
	303C-5		544H-19		166F-12
	303D-5		544J-19		206B-19
	303E-5		544K-19		206C-19
	407A-18		206B-11		206E-19
09148-06008	407B-18		206C-11		206F-19
	444A-13		206E-11		206K-19
	444B-13		206F-11		206L-19
	444C-13		206K-11		513A-30
	444D-13		206L-11		513B-30
09159-08059	444E-13		513A-28	09160-06082	513C-30
	444F-13		513B-28		513D-30
	336B-30		513C-28		160A-15
	336C-17		513D-28		160B-15
	336E-30		544A-31		160C-15
	336F-17		544B-31		160D-15
	336K-30		544C-31		160E-15
	336L-17		544D-31		160F-15
	513A-26		544E-31		160G-15
	513B-26		544F-31		160H-15
09159-08L02	513C-26		544G-31		160J-15
	513D-26		544H-31		160K-15
	336A-36		544J-31		160L-15
	336D-36		544K-31		160M-15
	336G-23	09160-06046	166A-8		210A-8
09159-22006	336H-36		166B-8		335A-10
	336J-36		166C-8		335B-10
	336M-23		166D-8		335D-10
	335A-8		166E-8		335E-10
	335B-8		166F-8		335H-10
	335C-13		206A-10		335J-10
	335D-8		206B-10		335K-10
	335E-8		206C-10		336A-17
	335F-13		206D-10		336B-17
	335G-13		206E-10		336D-17
	335H-8		206F-10		336E-17
	335J-8		206G-10		336H-17
	335K-8		206H-10		336J-17
	335L-13		206J-10		336K-17
	335M-13		206K-10	09160-06085	432A-15
	513A-27		206L-10		206A-11
	513B-27		206M-10		206D-11
	513C-27		513A-29		206G-11
	513D-27		513B-29		206H-11
09160-05024	544A-19		513C-29		206J-11
	544B-19		513D-29		206M-11
	544C-19		166A-12		450A-51
	544D-19		166B-12		450B-50
	544E-19		166C-12		450C-51
	544F-19		166D-12		450D-50

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	450E-51	09160-08170	513B-20	09160-17028	220A-11-9
	450F-50		513C-20		220B-11-9
	508A-51		513D-20		220D-11-9
	508B-51		335A-22		220E-11-9
	508C-51		335B-22		220H-11-9
09160-06168	508D-51		335C-26	09160-17039	220J-11-9
	310A-17		335D-22		220K-11-9
	310B-17		335E-22		220A-11-2
	310C-17		335F-26		220B-11-2
	310D-17		335G-26		220D-11-2
	310E-17		335H-22		220E-11-2
	310F-17		335J-22		220H-11-2
	310G-17		335K-22		220J-11-2
	310H-17		335L-26		220K-11-2
	310J-17	09160-12066	335M-26	09160-17040	220A-11-4
09160-06171	310K-17		407A-19		220B-11-4
	310L-17		407B-19		220D-11-4
	310M-17		303A-6		220E-11-4
	120A-8		303B-6		220H-11-4
09160-08081	335A-17	09160-15057	303C-6		220J-11-4
	335B-17		303D-6		220K-11-4
	335C-23		303E-6		220A-11-6
	335D-17		220A-11-1		220B-11-6
	335E-17		220B-11-1		220D-11-6
	335F-23	09160-17024	220D-11-1	09160-17041	220E-11-6
	335G-23		220E-11-1		220H-11-6
	335H-17		220H-11-1		220J-11-6
	335J-17		220J-11-1		220K-11-6
	335K-17		220K-11-1	09160-17042	220A-11-8
	335L-23	09160-17025	220A-11-3		220B-11-8
	335M-23		220B-11-3		220D-11-8
	336A-22		220D-11-3		220E-11-8
	336B-22		220E-11-3		220H-11-8
	336B-28		220H-11-3		220J-11-8
09160-08082	336C-12		220J-11-3	09160-17053	220K-11-8
	336C-15		220K-11-3		220C-11-1
	336D-22		220A-11-5		220F-11-1
	336E-22		220B-11-5		220G-11-1
	336E-28		220D-11-5		220L-11-1
	336F-12		220E-11-5	09160-17054	220M-11-1
	336F-15		220H-11-5		220C-11-2
	336G-12		220J-11-5		220F-11-2
	336H-22		220K-11-5		220G-11-2
	336J-22		220A-11-7		220L-11-2
	336K-22	09160-17027	220B-11-7	09160-17055	220M-11-2
	336K-28		220D-11-7		220C-11-3
	336L-12		220E-11-7		220F-11-3
	336L-15		220H-11-7		220G-11-3
	336M-12		220J-11-7		220L-11-3
	513A-20		220K-11-7		220M-11-3

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09160-17056	220C-11-4	09160-20043	220J-5-2	09160-25041	220L-12-4
	220F-11-4		220K-5-2		220M-12-4
	220G-11-4		220L-5-2		220A-12-5
	220L-11-4		220M-5-2		220B-12-5
	220M-11-4		220A-5-3		220C-12-5
09160-17057	220C-11-5		220B-5-3		220D-12-5
	220F-11-5		220C-5-3		220E-12-5
	220G-11-5		220D-5-3		220F-12-5
	220L-11-5		220E-5-3		220G-12-5
	220M-11-5		220F-5-3		220H-12-5
09160-17058	220C-11-6		220G-5-3		220J-12-5
	220F-11-6		220H-5-3		220K-12-5
	220G-11-6		220J-5-3		220L-12-5
	220L-11-6		220K-5-3		220M-12-5
	220M-11-6		220L-5-3	09160-25042	220A-12-6
09160-17059	220C-11-7	09160-20044	220M-5-3		220B-12-6
	220F-11-7		220A-5-4		220C-12-6
	220G-11-7		220B-5-4		220D-12-6
	220L-11-7		220C-5-4		220E-12-6
	220M-11-7		220D-5-4		220F-12-6
09160-17060	220C-11-8		220E-5-4		220G-12-6
	220F-11-8		220F-5-4		220H-12-6
	220G-11-8		220G-5-4		220J-12-6
	220L-11-8		220H-5-4		220K-12-6
	220M-11-8		220J-5-4		220L-12-6
09160-17061	220C-11-9	09160-21009	220K-5-4	09160-27012	220M-12-6
	220F-11-9		220L-5-4		336A-5
	220G-11-9		220M-5-4		336A-8
	220L-11-9		220A-6		336B-5
	220M-11-9		220B-6		336B-8
09160-20027	220A-4		220C-6		336C-5
	220B-4		220D-6		336C-8
	220C-4		220E-6		336D-5
	220D-4		220F-6		336D-8
	220E-4		220G-6		336E-5
	220F-4		220H-6		336E-8
	220G-4		220J-6		336F-5
	220H-4		220K-6		336F-8
	220J-4		220L-6		336G-5
	220K-4		220M-6		336G-8
09160-20042	220L-4	09160-25040	220A-12-4		336H-5
	220M-4		220B-12-4		336H-8
	220A-5-2		220C-12-4		336J-5
	220B-5-2		220D-12-4		336J-8
	220C-5-2		220E-12-4		336K-5
	220D-5-2		220F-12-4		336K-8
	220E-5-2		220G-12-4		336L-5
	220F-5-2		220H-12-4		336L-8
	220G-5-2		220J-12-4		336M-5
	220H-5-2		220K-12-4		336M-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09161-04012	410A-12		146H-13		220D-13
	410B-12		146J-13		220E-13
	410C-12		146K-13		220F-13
	410D-12		146L-13		220G-13
	410E-12		146M-13		220H-13
	410F-12	09169-06063	327A-5		220J-13
	410G-12		327B-5		220K-13
	410H-12		327C-9		220L-13
	410J-12		327D-5		220M-13
	410K-12		327E-9		220A-5-5
09161-08019	410L-12		310A-5		220B-5-5
	410M-12		310B-5		220C-5-5
	336A-37		310C-5		220D-5-5
	336D-37		310D-5		220E-5-5
	336G-24		310E-5		220F-5-5
	336H-37		310F-5		220G-5-5
	336J-37		310G-5		220H-5-5
	336M-24		310H-5		220J-5-5
	444A-19		310J-5		220K-5-5
	444B-19		310K-5		220L-5-5
	444C-19	09180-06186	310L-5	09181-20246	220M-5-5
	444D-19		310M-5		220A-5-6
	444E-19		206A-13		220B-5-6
	444F-19		206D-13		220C-5-6
	206A-12		206G-13		220D-5-6
09164-14008	206D-12		206H-13		220E-5-6
	206G-12		206J-13		220F-5-6
	206H-12		206M-13		220G-5-6
	206J-12		206A-14		220H-5-6
	206M-12		206B-12		220J-5-6
09168-12017	405A-8		206C-12	09181-20248	220K-5-6
	126A-6		206D-14		220L-5-6
	126B-6		206E-12		220M-5-6
	126C-6		206F-12		220A-5-7
	126D-6		206G-14		220B-5-7
	126E-6	09180-06366	206H-14		220C-5-7
	126F-6		206J-14		220D-5-7
	126G-6		206K-12		220E-5-7
	126H-8		206L-12		220F-5-7
	126J-8		206M-14		220G-5-7
	126K-8		335A-11		220H-5-7
	126L-8		335B-11		220J-5-7
	126M-8		335D-11		220K-5-7
	146A-13		335E-11		220L-5-7
	146B-13		335H-11		220M-5-7
	146C-13	09181-15241	335J-11	09181-20251	220A-5-1
	146D-13		335K-11		220B-5-1
	146E-13		220A-13		220C-5-1
	146F-13		220B-13		220D-5-1
	146G-13		220C-13		220E-5-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09181-25160	220F-5-1	09200-05014	220H-12-7		206D-8
	220G-5-1		220J-12-7		206E-8
	220H-5-1		220K-12-7		206F-8
	220J-5-1		220L-12-7		206G-8
	220K-5-1		220M-12-7		206H-8
	220L-5-1		336A-18		206J-8
	220M-5-1		336B-18		206K-8
	220A-12-1		336D-18		206L-8
	220B-12-1		336E-18		206M-8
	220C-12-1		336H-18		336A-13
	220D-12-1	09200-06061	336J-18		336B-13
	220E-12-1		336K-18		336D-13
	220F-12-1		336A-16		336E-13
	220G-12-1		336B-16		336H-13
	220H-12-1		336D-16		336J-13
	220J-12-1		336E-16		336K-13
	220K-12-1		336H-16		513A-19
	220L-12-1		336J-16		513B-19
	220M-12-1		336K-16		513C-19
	220A-12-2	09202-04008	160A-17	09204-02004	513D-19
09181-25162	220B-12-2		160B-17		407A-20
	220C-12-2		160C-17		407B-20
	220D-12-2		160D-17	09205-02004	210A-4
	220E-12-2		160E-17		335C-19
	220F-12-2		160F-17	09205-03004	335F-19
	220G-12-2		160G-17		335G-19
	220H-12-2		160H-17	09205-06021	335L-19
	220J-12-2		160J-17		335M-19
	220K-12-2		160K-17		335A-6
	220L-12-2		160L-17		335B-6
09181-25164	220M-12-2	09202-04025	160M-17		335C-3
	220A-12-3		220A-16		335D-6
	220B-12-3		220B-16		335E-6
	220C-12-3		220C-16		335F-3
	220D-12-3		220D-16		335G-3
	220E-12-3		220E-16		335H-6
	220F-12-3		220F-16		335J-6
	220G-12-3		220G-16		335K-6
	220H-12-3		220H-16		335L-3
	220J-12-3		220J-16		335M-3
09181-25181	220K-12-3	09202-06023	220K-16	09229-04005	410A-20
	220L-12-3		220L-16		410B-20
	220M-12-3		220M-16		410C-20
	220A-12-7		401A-4		410D-20
	220B-12-7		405A-7		410E-20
	220C-12-7		407A-4		410F-20
	220D-12-7		407B-4		410G-20
	220E-12-7	09204-01002	206A-8		410H-20
	220F-12-7		206B-8		410J-20
	220G-12-7		206C-8		410K-20

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09248-08001	410L-20	09263-20024	407B-2		336D-6
	410M-20		220A-7		336E-6
	407A-9		220B-7		336F-6
	407B-9		220C-7		336G-6
	405A-9		220D-7		336H-6
	444A-30		220E-7		336J-6
	444B-30		220F-7		336K-6
	444C-30		220G-7		336L-6
	444D-30		220H-7		336M-6
	444E-30		220J-7	09283-25096	121A-2
09251-05006	444F-30	09280-06012	220K-7		121B-2
	146A-14		220L-7		121C-2
	146B-14		220M-7		121D-2
	146C-14		210A-9		121E-2
	146D-14		09280-09008		121F-2
	146E-14		09280-09012		121G-2
	146F-14		09280-13004		121H-2
	146G-14		09280-17003		121J-2
	146H-14		09280-22019		121K-2
	146J-14		09280-26005		121L-2
09251-09007	146K-14	09280-54001	146B-39	09283-32039	121M-2
	146L-14		146C-39		116A-9
	146M-14		146D-39		121A-14
	410A-19		146E-39		121B-14
	410B-19		146F-39		121C-14
	410C-19		146G-39		121D-14
	410D-19		146H-39		121E-14
	410E-19		146J-39		121F-14
	410F-19		146K-39		121G-14
	410G-19		146L-39		121H-14
09260-12003	410H-19	09280-57002	146M-39	09289-06L02	121J-14
	410J-19		175A-5		121K-14
	410K-19		407A-12		121L-14
	410L-19		407B-12		121M-14
	410M-19		401A-5		210A-11
	206A-15	09282-12L04	220A-22	09289-17L02	407A-13
	206B-13		220B-22		407B-13
	206C-13		220C-22	09306-22006	335A-14
	206D-15		220D-22		335B-14
	206E-13		220E-22		335D-14
	206F-13		220F-22		335E-14
	206G-15		220G-22		335H-14
	206H-15		220H-22		335J-14
	206J-15		220J-22		335K-14
	206K-13		220K-22	09320-08051	310A-6
	206L-13		220L-22		310B-6
	206M-15		220M-22		310C-6
09262-25003	407A-3	09282-27002	336A-6		310D-6
	407B-3		336B-6		310E-6
	407A-2		336C-6		310F-6
09263-17048					

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	310G-6		146G-16		166C-13
	310H-6		146H-16		166D-13
	310J-6		146J-16		166E-13
	310K-6		146K-16		166F-13
	310L-6		146L-16		206B-20
09320-08062	310M-6	09352-50823-600	146M-16		206C-20
09320-09052	144A-7		146A-17		206E-20
	126A-10		146B-17		206F-20
	126B-10		146C-17		206K-20
	126C-10		146D-17		206L-20
	126D-10		146E-17		513A-31
	126E-10		146F-17		513B-31
	126F-10		146G-17		513C-31
	126G-10		146H-17		513D-31
	126H-12		146J-17	09401-08412	146A-18
	126J-12		146K-17		146B-18
	126K-12		146L-17		146C-18
	126L-12		146M-17		146D-18
	126M-12	09380-12002	338A-22		146E-18
	146A-15		338B-22		146F-18
	146B-15		338C-22		146G-18
	146C-15		338D-22		146H-18
	146D-15		338E-22		146J-18
	146E-15	09380-15001	220A-3		146K-18
	146F-15		220B-3		146L-18
	146G-15		220C-3		146M-18
	146H-15		220D-3	09401-08413	162A-6
	146J-15		220E-3	09401-10412	146A-19
	146K-15		220F-3		146B-19
	146L-15		220G-3		146C-19
09320-11017	146M-15		220H-3		146D-19
	410A-7		220J-3		146E-19
	410B-7		220K-3		146F-19
	410C-7		220L-3		146G-19
	410D-7		220M-3		146H-19
	410E-7	09381-16001	116A-4		146J-19
	410F-7	09385-04003	410A-21		146K-19
	410G-7		410B-21		146L-19
	410H-7		410C-21		146M-19
	410J-7		410D-21	09401-11423	146A-34
	410K-7		410E-21		146A-40
	410L-7		410F-21		146B-34
	410M-7		410G-21		146B-40
09320-13022	405A-18		410H-21		146C-34
09321-08022	146A-16		410J-21		146C-40
	146B-16		410K-21		146D-34
	146C-16		410L-21		146D-40
	146D-16		410M-21		146E-34
	146E-16	09385-06012	166A-13		146E-40
	146F-16		166B-13		146F-34

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	146F-40		146E-42		553B-15
	146G-34		146F-42		553C-15
	146G-42		146G-42		553D-15
	146H-34		146H-42		561A-16
	146H-40		146J-42		561B-16
	146J-34		146K-42		561C-16
	146J-40		146L-42		561D-16
	146K-34		146M-42	09407-14407	303A-8
	146K-40	09403-12406	163A-7		303B-8
	146L-34		163D-7		303C-8
	146L-40		163G-7		303D-8
	146M-34		163H-7		303E-8
	146M-40		163J-7		322A-3
09401-11425	144A-8		163M-7		322A-10-1
09401-12413	111A-17		167C-15		322A-10-2
	401A-16		167F-15		322B-6
09401-13423	146A-41		167G-15		322C-6
	146B-41		167L-15		322D-3
	146C-41		167M-15		322D-10-1
	146D-41	09403-12415	167A-14		322D-10-2
	146E-41		167B-14		322E-6
	146F-41		167C-14		322F-6
	146G-41		167D-14		322G-3
	146H-41		167E-14		322G-10
	146J-41		167F-14		322H-3
	146K-41		167G-14		322H-10-1
	146L-41		167H-14		322H-10-2
	146M-41		167J-14		322J-3
09401-13424	401A-18		167K-14		322J-10-1
09403-07308	410C-22		167L-14		322J-10-2
	410F-22		167M-14		322K-6
	410G-22	09407-08401	530A-8		322L-6
	410L-22		530A-28		322M-3
	410M-22		530B-8		322M-10
09403-08404	322A-16		530B-28		338A-23
	322B-11		530C-8		338B-23
	322C-11		530C-28		338C-23
	322D-16		530D-8		338D-23
	322E-11		530D-28		338E-23
	322F-11		530E-8		501A-8
	322G-16		530E-28		501B-8
	322H-16		530F-8		501C-8
	322J-16	09407-14403	530F-28		501D-8
	322K-11		322A-2		501E-8
	322L-11		322D-2		501F-8
	322M-16		322G-2		513A-32
09403-11320	146A-42		322H-2		513B-32
	146B-42		322J-2		513C-32
	146C-42		322M-2		513D-32
	146D-42		553A-15		553A-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	553A-16		561A-11		206L-14
	553B-7		561B-11		206M-16
	553B-16		561C-11	09440-12027	444A-20
	553C-7		561D-11		444B-20
	553C-16	09408-00252	322A-18		444C-20
	553D-7		322D-18		444D-20
	553D-16		322G-18		444E-20
	561A-18		322H-18		444F-20
	561A-22		322J-18	09440-18002	175A-6
	561B-18		322M-18	09441-17001	335A-21
	561B-22	09408-00296	322B-13		335B-21
	561C-18		322C-13		335D-21
	561C-22		322E-13		335E-21
	561D-18		322F-13		335H-21
	561D-22		322K-13		335J-21
	600A-33		322L-13		335K-21
	600B-33	09408-00297	322A-19	09471-12028	501A-6
	600C-33		322B-14		501A-14
	600D-33		322C-14		501B-6
	600E-33		322D-19		501B-14
09408-00008	600F-33		322E-14		501C-6
	322A-17		322F-14		501C-14
	322B-12		322G-19		501D-6
	322D-17		322H-19		501D-14
	322E-12		322J-19		501E-6
	322G-17		322K-14		501E-14
	322H-17		322L-14		501F-6
	322J-17		322M-19		501F-14
	322K-12	09420-03009	160A-16	09471-12103	501A-2
	322M-17		160B-16		501A-4
09408-00024	322C-12		160C-16		501A-18
	322F-12		160D-16		501B-2
	322L-12		160E-16		501B-4
09408-00070	162A-9		160F-16		501B-18
09408-00159	310A-10		160G-16		501C-2
	310B-10		160H-16		501C-4
	310C-10		160J-16		501C-18
	310D-10		160K-16		501D-2
	310E-10		160L-16		501D-4
	310F-10		160M-16		501D-18
	310G-10	09440-09041	206A-16		501E-2
	310H-10		206B-14		501E-4
	310J-10		206C-14		501E-18
	310K-10		206D-16		501F-2
	310L-10		206E-14		501F-4
	310M-10		206F-14		501F-18
09408-00184	553A-8		206G-16	09481-05501	600A-10
	553B-8		206H-16		600A-27
	553C-8		206J-16		600A-29
	553D-8		206K-14		600B-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	600B-27		322J-7		
	600B-29		322K-4		
	600C-10		322L-4		
	600C-27		322M-7		
	600C-29		513A-14		
	600D-10	09482-00L04	513B-14		
	600D-27		513C-14		
	600D-29		513D-14		
	600E-10		111A-18		
	600E-27				
	600E-29				
	600F-10				
	600F-27				
	600F-29				
09481-10501	322A-6				
	322B-3				
	322C-3				
	322D-6				
	322E-3				
	322F-3				
	322G-6				
	322H-6				
	322J-6				
	322K-3				
	322L-3				
	322M-6				
	450A-53				
	450B-55				
	450C-53				
	450D-55				
	450E-53				
	450F-55				
	513A-13				
	513B-13				
	513C-13				
	513D-13				
	546A-2				
	546B-2				
	546C-2				
	546D-2				
	546E-2				
	546F-2				
09481-30501	322A-7				
	322B-4				
	322C-4				
	322D-7				
	322E-4				
	322F-4				
	322G-7				
	322H-7				

SUZUKI DF9.9B/15A/20A PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material & Training Group, Service Material In-house Production Project
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2016 All Rights Reserved

SUZUKI MOTOR CORPORATION