

SUZUKI

PARTS CATALOGUE

DF9. 9B/15A/20A

DF9.9B/BR

DF9.9BT/BTH

DF15A/AR

DF15AT

DF20A/AR

DF20AT/ATH



OUTBOARD MOTOR

P01/P40

2018-11

1ST EDITION

PREFACE

When it becomes necessary to replace parts on SUZUKI OUTBOARD MOTORS, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DF9.9B/15A/20A production start 2018.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E. NO.	: Engine number	OS	: Over size
F. NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	W/	: with
LH(PORT)	: Left hand side	S, L	: Transom type
RH(STBD)	: Right hand side	SUS	: Stainless steel
~123456	: Up to E. NO. 02002F-123456		
123456~	: From E. NO. 02002F-123456		

12 x 34 x 5.6..... Figures in the description column
| | |
ID OD T(or W, L)
show the dimensions of parts.

→12345-56781 (Parts No.) : indicates that the parts number was changed to 12345-56781 and the new parts are interchangeable with the former ones but the former ones are not interchangeable with new ones.

←12345-56781 (Parts No.) : indicates that the former and new parts are interchangeable with each other and both are usable.

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.

5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.

5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. SPECIFICATION CODE

This catalogue contains the parts for the model designed for the following spec. ;

spec. code :	DF9.9B	: P1	DF9.9BR	: P1
	DF9.9BT	: P1	DF9.9BTH	: P1
	DF15A	: P1	DF15AR	: P1
	DF15AT	: P1		
	DF20A	: P1, P40	DF20AR	: P1
	DF20AT	: P1	DF20ATH	: P1

7. MODEL NAME AND ENGINE NUMBER

MODEL	DESTINATION	TYPE	TRANSOM	ENGINE NO.
DF9.9B	P01	00995F	S, L, X	00995F-910001~
DF9.9BR	P01	00995F	S, L, X	00995F-910001~
DF9.9BT	P01	00995F	S, L, X	00995F-910001~
DF9.9BTH	P01	00995F	S, L, X	00995F-910001~
DF15A	P01	01504F	S, L, X	01504F-910001~
DF15AR	P01	01504F	S, L, X	01504F-910001~
DF15AT	P01	01504F	S, L, X	01504F-910001~
DF20A	P01, P40	02002F	S, L, X	02002F-910001~
DF20AR	P01	02002F	S, L, X	02002F-910001~
DF20AT	P01	02002F	S, L, X	02002F-910001~
DF20ATH	P01	02002F	S, L, X	02002F-910001~

MILLIMETER → INCH CONVERSION CHART


	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.214	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read

	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...


23 millimeters equal 0.906 inch

FIG.111A




3DGM_PVL_018_111A
CYLINDER HEAD

FIG.113A




3DGM_PVL_018_113A
CYLINDER BLOCK

FIG.116A




3DGM_PVL_018_116A
CRANKSHAFT

FIG.120A




3DGM_PVL_018_120A
PISTON SET

FIG.121A




3DGM_PVL_018_121A
CAMSHAFT

FIG.121B




3DGM_PVL_018_121B
CAMSHAFT

FIG.126A




3DGM_PVL_018_126A
PISTON MANIFOLD

FIG.126B




3DGM_PVL_018_126B
PISTON MANIFOLD

FIG.126C




DFCML_PVL_012_102C
FUEL MANIFOLD

FIG.144A




DFCML_PVL_012_104A
FUEL INJECTOR

FIG.146A




DFCML_PVL_012_106A
FUEL PUMP

FIG.146B




DFCML_PVL_012_106B
FUEL PUMP

FIG.160A




DFCML_PVL_012_108A
WATER PUMP

FIG.160B




DFCML_PVL_012_108B
WATER PUMP

FIG.162A



DFCML_PVL_012_108A
WATER PUMP

FIG.163A



DFCML_PVL_012_108A
WATER PUMP

FIG.163B




FIG.163B
THROTTLE CONTROL

FIG.166A




FIG.166A
THROTTLE CONTROL

FIG.167A




FIG.167A
THROTTLE CONTROL

FIG.167B




FIG.167B
THROTTLE CONTROL

FIG.175A




FIG.175A
THROTTLE CONTROL

FIG.206A




FIG.206A
THROTTLE CONTROL

FIG.206B




FIG.206B
THROTTLE CONTROL

FIG.210A






FIG.210A
THROTTLE CONTROL

FIG.220A




DFGM_PRL_018_3034
PFA4383520V

FIG.220B




DFGM_PRL_018_3035
PFA4383520V

FIG.301A




DFGM_PRL_018_3014
PFA4383520V

FIG.303A




DFGM_PRL_018_3034
MAGNETO

FIG.303B




DFGM_PRL_018_3035
MAGNETO

FIG.310A




DFGM_PRL_018_3104
RECYCLATION CODE

FIG.310B



DFGM_PRL_018_3105
RECYCLATION CODE

FIG.310C



DFGM_PRL_018_310C
RECYCLATION CODE

FIG.310D




FIG.310D
REF. 014_310D
REF. 014_310D

FIG.310E




FIG.310E
REF. 014_310E
REF. 014_310E

FIG.310F




FIG.310F
REF. 014_310F
REF. 014_310F

FIG.310G




FIG.310G
REF. 014_310G
REF. 014_310G

FIG.322A




FIG.322A
REF. 014_322A
REF. 014_322A

FIG.322B




FIG.322B
REF. 014_322B
REF. 014_322B

FIG.322C




FIG.322C
REF. 014_322C
REF. 014_322C

FIG.322D




FIG.322D
REF. 014_322D
REF. 014_322D

FIG.327A




FIG.327A
PTT SWITCH

FIG.327B




FIG.327B
PTT SWITCH

FIG.334A




FIG.334A
SENSOR SWITCH

FIG.334B




FIG.334B
SENSOR SWITCH

FIG.334C




FIG.334C
SENSOR SWITCH

FIG.334D




FIG.334D
SENSOR SWITCH

FIG.335A




FIG.335A
CLAMP BRACKET

FIG.335B






FIG.335B
CLAMP BRACKET

FIG.335C




DFGM_P01_018_335C
CLAMP SH4C027

FIG.335D




DFGM_P01_018_335D
CLAMP SH4C027

FIG.336A




DFGM_P01_018_336A
SHRIEL SH4C027

FIG.336B




DFGM_P01_018_336B
SHRIEL SH4C027

FIG.336C




DFGM_P01_018_336C
SHRIEL SH4C027

FIG.336D




DFGM_P01_018_336D
SHRIEL SH4C027

FIG.336E




DFGM_P01_018_336E
SHRIEL SH4C027

FIG.338A




DFGM_P01_018_338A
TILT CYLINDER

FIG.340A




DCBM_REL_018_340A
PTT MOTOR

FIG.401A




DCBM_REL_018_401A
PTT MOTOR

FIG.405A




DCBM_REL_018_405A
PTT MOTOR

FIG.405B




DCBM_REL_018_405B
PTT MOTOR

FIG.407A




DCBM_REL_018_407A
GEAR CASE

FIG.407B




DCBM_REL_018_407B
GEAR CASE

FIG.407C



DCBM_REL_018_407C
GEAR CASE

FIG.407D



DCBM_REL_018_407D
GEAR CASE

FIG.407E




FIG. 407E
SEAL GASKET

FIG.407F




FIG. 407F
SEAL GASKET

FIG.407G




FIG. 407G
SEAL GASKET

FIG.410A




FIG. 410A
SIDE COVER

FIG.410B




FIG. 410B
SIDE COVER

FIG.410C




FIG. 410C
SIDE COVER

FIG.410D




FIG. 410D
SIDE COVER

FIG.410E




FIG. 410E
SIDE COVER

FIG.420A




FIG.420A
ENGINE COVER

FIG.420B




FIG.420B
ENGINE COVER

FIG.420C




FIG.420C
ENGINE COVER

FIG.420D




FIG.420D
ENGINE COVER

FIG.420E




FIG.420E
ENGINE COVER

FIG.420F




FIG.420F
ENGINE COVER

FIG.420G




FIG.420G
ENGINE COVER

FIG.432A




FIG.432A
FUEL TANK

FIG.442A




FIG.442A
TELEPHONE

FIG.444A




FIG.444A
TELEPHONE

FIG.444B




FIG.444B
TELEPHONE

FIG.450A




FIG.450A
TELEPHONE

FIG.450B




FIG.450B
TELEPHONE

FIG.501A




FIG.501A
TELEPHONE

FIG.503A




FIG.503A
TELEPHONE

FIG.513A




FIG.513A
TELEPHONE

FIG.515A





FIG.515A
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.515B





FIG.515B
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.521A




FIG.521A
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.530A




FIG.530A
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.544A




FIG.544A
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.544B




FIG.544B
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.544C




FIG.544C
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.545A




FIG.545A
OPTHEMATIC CONTROL ASSY (SINGLE) (1)

FIG.545B




FIG. 545B
OPT. REMOTE CONTROL ASSY (SINGLE-CH)

FIG.545C




FIG. 545C
OPT. REMOTE CONTROL ASSY (SINGLE-CH)

FIG.546A




FIG. 546A
OPT. REMOTE CONTROL (ELECTRIC STARTER)

FIG.553A




FIG. 553A
OPT. ELECTRICAL MANUAL STARTER

FIG.561A




FIG. 561A
OPT. STARTING MOTOR (MANUAL STARTER)

FIG.561B




FIG. 561B
OPT. STARTING MOTOR (MANUAL STARTER)

FIG.561C




FIG. 561C
OPT. STARTING MOTOR (MANUAL STARTER)

FIG.561D




FIG. 561D
OPT. STARTING MOTOR (MANUAL STARTER)

FIG.575A




FIG.575A
OPTICAL FIBER CABLE

FIG.583A




FIG.583A
OPTICAL FIBER CABLE

FIG.583B




FIG.583B
OPTICAL FIBER CABLE

FIG.600A




FIG.600A
OPTICAL FIBER CABLE

FIG.600B




FIG.600B
OPTICAL FIBER CABLE

FIG.600C




FIG.600C
OPTICAL FIBER CABLE

FIG.111A




FIG.111A (1-B-2) CYLINDER HEAD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11110-89L01	HEAD, CYLINDER	1	
2	11141-89L00	GASKET, CYLINDER HEAD	1	
3	09119-08L02	BOLT (8X72)	6	
4	09119-08L01	BOLT (8X77)	2	
5	11261-93J00	COVER, PROTECTION ANODE	1	
6	09280-22019	O RING (D:1.9,ID:21.8)	1	
7	55321-87J01	ANODE, PROTECTION	1	
8	09103-06281	BOLT (6X14)	1	
9	01550-0820C	BOLT	1	
10	11382-93E00	CAP, OIL FILLER	1	
11	09280-17003	O RING (D:3.1,ID:16.8)	1	
12	04211-11129	PIN	2	
13	11170-89L00	COVER, CYLINDER HEAD	1	
14	11162-89L00	GASKET, CYLINDER HEAD COVER	1	
15	01550-0620C	BOLT	6	
16	11174-89L00	HOSE, BREATHER	1	
17	09401-12413	CLIP	2	
18	09482-00661	SPARK PLUG (MR6K-9)	2	NGK
19	11115-93E00-001	GUIDE, VALVE (OS:0.3)	4	OPT

FIG.113A




FIG.113A (1-B-3) CYLINDER BLOCK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11300-89L03	BLOCK ASSY, CYLINDER	1	
2	01550-06357	.BOLT	6	
3	01560-08757	.BOLT	4	
4	04211-11129	.PIN	2	
5	16440-11D00	REGULATOR ASSY, ENGINE	1	
6	11291-91B50	HOOK, ENGINE	1	OPT
7	01550-08207	BOLT	1	OPT

FIG.116A




FIG.116A (1-B-4) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-89L10-0B0	PISTON	2	
2	12140-89L10	RING SET, PISTON	2	
3	12151-89L00	PIN, PISTON	2	
4	09381-16001	CIRCLIP (OD:18)	4	
5	12160-89L11	CONNROD ASSY	2	
6	12163-89L02	.BOLT, CONNROD	4	
7	12220-89L00	CRANKSHAFT	1	
8	12341-89L10	BEARING, CRANKSHAFT	4	
9	09283-32048	OIL SEAL (32X44X6.5)	2	
10	12100-89L30-050	PISTON SET (OS:0.50)	2	OPT
11	12140-89L10-050	.RING SET, PISTON	2	OPT



FIG.120A (1-B-5) TIMING BELT




FIG.121A




FIG.121A (1-B-6) CAMSHAFT (MANUAL STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L01	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40

FIG.121B




FIG.121B (1-B-7) CAMSHAFT (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12700-89L21	CAMSHAFT ASSY	1	
2	09283-25096	OIL SEAL (25X44X7)	1	
3	12840-93E01	ARM, ROCKER	4	
4	12842-49201	.SCREW, TAPPET ADJUSTING	4	
5	12843-27A00	.NUT, TAPPET ADJUSTING	4	
6	12861-89L00	SHAFT, ROCKER ARM	1	
7	12891-94J00	SPRING, ROCKER SHAFT	1	
8	12911-94J01	VALVE, INTAKE	2	
9	12915-94J50	VALVE, EXHAUST	2	
10	12921-89L00	SPRING, VALVE	4	
11	12931-78G00	RETAINER, VALVE SPRING	4	
12	12932-24400	COTTER, VALVE	8	
13	12933-71C00	SEAT, VALVE SPRING	4	
14	09289-05012	OIL SEAL (5.5X11.5X9.3)	4	

FIG.126A




FIG.126A (1-B-8) INLET MANIFOLD (DF9.9B)(DF9.9BR)(DF9.9BT)(DF9.9BTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L10	PIPE, AIR INLET	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L10	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	

DF9.9B P01
DF9.9BR P01
DF9.9BT P01
DF9.9BTH P01



FIG.126B




FIG.126B (1-B-9) INLET MANIFOLD (DF15A)(DF15AR)(DF15AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L10	PIPE, AIR INLET	1	
6	09169-06062	WASHER	1	
7	09116-06517	BOLT (6X25)	1	
8	13116-94J00	CAP, INLET MANIFOLD	1	
9	13820-89L00	HOLDER, RESTRICTOR	1	
10	09320-09052	CUSHION	2	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	61494-89L10	LABEL, OIL & CLEARANCE	1	

DF15A P01
DF15AR P01
DF15AT P01



FIG.126C




FIG.126C (1-B-10) INLET MANIFOLD (DF20A)(DF20AR)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13111-89L00	MANIFOLD, INLET	1	
2	13119-89L00	GASKET, INLET MANIFOLD	1	
3	01580-08407	BOLT	2	
4	04221-05109	PIN	2	
5	13811-89L10	PIPE, AIR INLET	1	
6	13710-89L00	ARRESTER, FLAME	1	
7	13832-89L00	SEAL, SILENCER	1	
8	09169-06062	WASHER	1	
9	09116-06517	BOLT (6X25)	1	
10	13116-94J00	CAP, INLET MANIFOLD	1	
11	13831-89L00	CUSHION, AIR INLET PIPE	1	
12	09320-09052	CUSHION	2	
13	61494-89L10	LABEL, OIL & CLEARANCE	1	

DF20A P01
DF20A P40
DF20AR P01
DF20AT P01
DF20ATH P01



FIG.144A




FIG.144A (1-B-11) FUEL INJECTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15681-89L00	HOSE, FUEL(PUMP TO DLVY)	1	
2	15710-50M00	INJECTOR ASSY, FUEL	2	
3	15716-65DT0	.GROMMET SET, FUEL INJECTOR	2	
4	15734-89L00	SPACER, DELIVERY PIPE	1	
5	15735-89L00	INSULATOR, DELIVERY PIPE	1	
6	15751-89L00	PIPE, DELIVERY	1	
7	09320-08062	CUSHION	2	
8	09401-11425	CLIP	2	
9	01550-0650C	BOLT	2	



FIG.146A





FIG.146A (1-B-12) FUEL PUMP (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JB1	PROTECTOR (L:200)	1	
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	



DF20A_P01_019

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L20	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L01	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L21	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	

FIG.146A




FIG.146A (1-B-14) FUEL PUMP (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

- DF9.9B P01
- DF9.9BR P01
- DF9.9BT P01
- DF9.9BTH P01
- DF15A P01
- DF15AR P01
- DF15AT P01
- DF20A P01
- DF20AR P01
- DF20AT P01
- DF20ATH P01

FIG.146B




FIG.146B (1-B-15) FUEL PUMP (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13684-89L00	HOSE, DRAIN	1	
2	15200-89L10	PUMP ASSY, FUEL (H)	1	
3	15217-89L00	CUSHION, FUEL PUMP (H)	1	
4	15218-89L00	BRACKET, FUEL PUMP (H)	1	
5	15600-89L00	SEPARATOR ASSY, FUEL VAPOR	1	
6	15690-89L02	CHAMBER, EVAPORATION	1	
7	15770-89L02	COOLER, FUEL	1	
8	15629-89L00	.SCREW, FUEL DRAIN	1	
9	15790-89L00	BRACKET, FUEL COOLER	1	
10	18498-87JB1	PROTECTOR (L:450)	1	L:450->200
11	01550-0625C	BOLT	2	
12	09116-06517	BOLT (6X25)	1	
13	09169-06062	WASHER	1	
14	09251-05006	CAP (OD:11)	1	
15	09320-09052	CUSHION	3	
16	09321-08022	CUSHION	1	
17	09352-50823-600	HOSE (5X8.2X600)	1	L:600->420
18	09401-08412	CLIP	1	
19	09401-10412	CLIP	1	
20	01550-0616C	BOLT	2	
21	01550-0620C	BOLT	2	
22	01550-0625C	BOLT	2	
23	03542-06209	SCREW	3	
24	15100-89L10	PUMP ASSY, FUEL (L)	1	
25	15191-89L00	HOSE, FUEL (CONN TO FILTER)	1	
26	15192-89L01	HOSE, FUEL (FILTER TO PUMP(L))	1	
27	15192-89L10	HOSE, FUEL (PUMP (L) TO SEP)	1	
28	15192-89L21	HOSE, FUEL (PUMP (H) TO SEP)	1	
29	15192-89L30	HOSE, FUEL (PUMP (H) TO 3WAY)	1	
30	15192-89L40	HOSE, FUEL (SEPARATOR TO EVAP)	1	

FIG.146B




FIG.146B (1-C-2) FUEL PUMP (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
31	15193-89L00	HOSE, FUEL (SEPARATOR TO COOLER)	1	
32	15194-89L00	HOSE, FUEL (COOLER TO PUMP(H))	1	
33	15410-87L00	FILTER, FUEL (L)	1	
34	09401-11423	.CLIP	1	
35	15419-87J00	.CAP, FUEL FILTER	1	
36	15421-89L01	BRACKET, FUEL FILTER	1	
37	15422-89L00	CLAMP, FUEL FILTER	1	
38	15685-89L00	CLAMP, FUEL HOSE	1	
39	09280-26005	O RING (D:2.4,ID:26.2)	1	
40	09401-11423	CLIP	12	
41	09401-13423	CLIP	4	
42	09403-11320	CLAMP	2	
43	61151-91J11	CUSHION, FUEL FILTER BRACKET	1	
44	15676-89L00	CUSHION, VAPOR SEPARATOR	1	

DF20A P40

FIG.160A




FIG.160A (1-C-3) WATER PUMP (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J00	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J00	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J02	KIT, WATER PUMP REPAIR	1	OPT

- DF9.9B P01
- DF9.9BR P01
- DF9.9BT P01
- DF9.9BTH P01
- DF15A P01
- DF15AR P01
- DF15AT P01
- DF20A P01
- DF20AR P01
- DF20AT P01
- DF20ATH P01

FIG.160B




FIG.160B (1-C-4) WATER PUMP (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17411-94J00	CASE, WATER PUMP	1	
2	17413-94J10	SLEEVE, WATER PUMP CASE	1	
3	17461-939M0	IMPELLER, WATER PUMP	1	
4	17471-99J10	PANEL, PUMP CASE UNDER	1	
5	17472-99J00	GASKET, PUMP CASE PANEL	1	
6	17473-94J00	GASKET, WATER PUMP CASE	1	
7-1	17561-99J00	TUBE, WATER (S)	1	W/TRANSOM(S)
7-2	17561-99J10	TUBE, WATER (L)	1	W/TRANSOM(L)
7-3	17561-99J20	TUBE, WATER (X)	1	W/TRANSOM(X)
8	17563-94J00	BUSH, WATER TUBE MIDDLE	1	
9	17564-99J00	BUSH, WATER PUMP CASE	1	
10	17631-99J20	FILTER, WATER PORT SIDE	1	
11	17632-99J30	FILTER, WATER STBD SIDE	1	
12	03142-04169	SCREW	1	
13	29141-93J00	NUT, WATER PUMP CASE	4	
14	09108-06141	STUD BOLT	4	
15	09160-06082	WASHER (6.5X13X1.0)	4	
16	09420-03009	KEY	1	
17	09202-04008	PIN (4X9)	2	
18	17565-99J00	GUIDE, WATER TUBE	1	
19	17400-99J12	KIT, WATER PUMP REPAIR	1	OPT

DF20A P40

FIG.162A




FIG.162A (1-C-5) THERMOSTAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17670-91J01	THERMOSTAT (50C)	1	
2	17680-89L00	COVER, THERMOSTAT	1	
3	01550-0620C	BOLT	3	
4	17712-89L11	HOSE, WATER (COOLER TO HOUSING)	1	
5	17712-89L02	HOSE, WATER (HOUSING TO COOLER)	1	
6	09401-08413	CLIP	4	
7	17685-89L00	SEAL, THERMOSTAT COVER	1	
8	09408-00070	CLAMP	1	

FIG.163A




FIG.163A (1-C-6) THROTTLE BODY (DF9.9B)(DF9.9BTH)(DF15A)(DF20A)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L01	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	13279-13G10	.ADJUSTER	1	
7	13295-29900	.O RING	1	
8	13365-89L00	.SPRING	1	
9	13606-47A00	.WASHER	1	
10	15211-91J00-130	HOSE, IAC	1	
11	09403-12406	CLAMP	1	
12	01550-0612C	BOLT	1	
13	01550-0620C	BOLT	2	

DF9.9B P01
DF9.9BTH P01
DF15A P01
DF20A P01
DF20A P40
DF20ATH P01



FIG.163B




FIG.163B (1-C-7) THROTTLE BODY (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13300-89L11	BODY ASSY, THROTTLE	1	
2	13420-16HA0	.SOLENOID ASSY	1	
3	13425-33G00	..O RING	1	
4	13326-89L00	.SCREW	2	
5	13421-89L00	.O RING, FLANGE	1	
6	13279-13G10	.ADJUSTER	1	
7	13295-29900	.O RING	1	
8	13365-89L00	.SPRING	1	
9	13606-47A00	.WASHER	1	
10	15211-91J00-130	HOSE, IAC	1	
11	01550-0620C	BOLT	2	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01



FIG.166A




FIG.166A (1-C-8) THROTTLE CONTROL (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13513-89L10	ROD, THROTTLE	1	
2	19120-99J11	LEVER, THROTTLE CONTROL	1	
3	19122-99J00	LEVER, INTERLINK THROTTLE NO.2	1	
4	19131-89L00	CONNECTOR	2	
5	19148-89L10	LEVER, INTERLINK THROTTLE NO.1	1	
6	19150-89L00	BRACKET, THROTTLE LEVER	1	
7	19185-99J00	SPRING, THROTTLE LEVER	1	
8	09160-06046	WASHER (6.5X20X1.5)	1	
9	01550-0612C	BOLT	1	
10	01550-0616C	BOLT	2	
11	67467-89J01	CONNECTOR	1	
12	09160-06055	WASHER (7X12X1)	1	
13	09385-06016	CLIP	1	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01



FIG.167A




FIG.167A (1-C-9) RECOIL STARTER (DF9.9B)(DF9.9BR)(DF15A)(DF15AR)(DF20A)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	

DF9.9B P01
DF9.9BR P01
DF15A P01
DF15AR P01
DF20A P01
DF20A P40
DF20AR P01

Diagram illustrating the exploded view of the FWD 167B car stereo unit, showing the main components and their assembly order:

- 1**: Main stereo unit.
- 2**: Front faceplate.
- 3**: Mounting bracket.
- 4**: Coiled antenna cable.
- 5**: Mounting screw.
- 6**: Mounting bracket (alternative view).
- 7**: Mounting plate.
- 8**: Antenna cable (coiled).
- 9**: Mounting screw.
- 10**: Antenna cable (straight).
- 11**: Mounting screw.
- 12**: Mounting screw.
- 13**: Mounting plate (alternative view).
- 14**: Mounting screw.
- 15**: Mounting bracket (alternative view).

Additional components shown include a warning symbol, a book icon, and a car icon.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	18100-94JN0	STARTER ASSY, RECOIL	1	
2	18121-94JL0	.REEL	1	
3	18130-93E01	.RATCHET SET	1	
4	18142-93E00	.SPRING, SPIRAL	1	
5	18132-89L00	.SCREW, TAPPING	1	
6	18210-95L00	.GRIP ASSY	1	
7	18280-93E00	.NSI SET	1	
8	99000-81158-50M	ROPE	1	OPT L:50000->1500
9	01550-0630C	BOLT	3	
10	18290-94J01	CABLE ASSY, NSI	1	
11	01550-0620C	BOLT	1	
12	69711-93E10	LABEL (S.I.G.P.)	1	
13	61472-97J00	LABEL, RECOIL STARTER	1	
14	09403-12415	CLAMP	1	
15	09403-12406	CLAMP	1	

DF20A_P01_019_167B
RECOIL STARTER

FIG.175A




FIG.175A (1-C-11) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-89L00	PUMP ASSY, OIL	1	
2	16510-45H10	FILTER, ENGINE OIL	1	
3	16512-99J00	CAP, OIL FILTER	1	
4	09280-13004	O RING (D:1.9,ID:13)	1	
5	09280-54001	O RING (D:2.4,ID:52.6)	1	
6	09440-18002	SPRING	1	
7	01550-0620C	BOLT	3	
8	01550-0612C	BOLT	1	
9	16910-89L01	GAUGE, OIL LEVEL	1	
10	16930-89L02	GUIDE, OIL LEVEL GAUGE	1	
11	09280-09008	O RING (D:2.1,ID:8.8)	1	
12	16431-89L00	BLOCK, OIL GALLERY	1	
13	59262-94J00	PIN, OIL PUMP	1	
14	02122-0630A	SCREW	3	

FIG.206A




FIG.206A (1-C-12) CLUTCH ROD (DF9.9B)(DF9.9BTH)(DF15A)(DF20A)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21111-89L01	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L00	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	1	
9	09116-06234	BOLT (6X35)	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-06094	WASHER (6.5X15X1.0)	1	
12	09164-14008	WASHER	2	
13	09180-06186	SPACER (6.2X12.6X21)	1	
14	09180-06362	SPACER (6.5X10.5X4)	1	
15	09260-12003	BALL	1	
16	09440-09041	SPRING	1	
17	01550-0612C	BOLT	1	
18	01550-0625C	BOLT	1	
19	02142-06207	SCREW	2	

DF9.9B P01
DF9.9BTH P01
DF15A P01
DF20A P01
DF20A P40
DF20ATH P01



FIG.206B




FIG.206B (1-C-13) CLUTCH ROD (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21110-89L10	LEVER, CLUTCH	1	
2	21120-89L00	LEVER, CLUTCH NOTCH	1	
3	21122-89L00	PLATE, CLUTCH NOTCH	1	
4	21210-89L01	SHAFT, CLUTCH LEVER	1	
5-1	23111-89L00	ROD, CLUTCH (S)	1	W/TRANSOM(S)
5-2	23111-89L10	ROD, CLUTCH (L)	1	W/TRANSOM(L) W/TRANSOM(X)
6	23115-89L10	LINK, CLUTCH LEVER	1	
7	23211-89L00	ARM, CLUTCH ROD	1	
8	09204-01002	PIN	2	
9	01550-0612C	BOLT	1	
10	09160-06046	WASHER (6.5X20X1.5)	1	
11	09160-05029	WASHER (5.5X12X0.8)	2	
12	09180-06362	SPACER (6.5X10.5X4)	1	
13	09260-12003	BALL	1	
14	09440-09041	SPRING	1	
15	01550-0612C	BOLT	1	
16	01550-0625C	BOLT	1	
17	02142-06207	SCREW	2	
18	67467-89J01	CONNECTOR	1	
19	09160-06055	WASHER (7X12X1)	1	
20	09385-06016	CLIP	1	
21	67340-89L10	HOLDER, R/CON CABLE	1	
22	01547-0616C	BOLT	2	
23	67345-89L10	PROTECTOR, R/CON CABLE HOLDER	1	
24	09409-10304-5ES	CLIP (BLACK)	1	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01

FIG.210A





FIG.210A (1-C-14) SHIFT ROD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	23311-95J00	CONNECTOR, CLUTCH ROD	1	
2-1	25111-99J01	ROD, SHIFT (S & L)	1	W/TRANSOM(S) W/TRANSOM(L)
2-2	25111-99J10	ROD, SHIFT (X)	1	W/TRANSOM(X)
3	25311-99J00	CAM, SHIFT	1	
4	09205-02004	SPRING PIN (2.5X12)	2	
5	25211-99JL0	GUIDE, SHIFT ROD	1	
6	25215-99J00	STOPPER, SHIFT ROD GUIDE	1	
7	29141-93J00	NUT, CLUTCH ROD (M6)	1	
8	09160-06082	WASHER (6.5X13X1.0)	1	
9	09280-06012	O RING (D:1.7,ID:5.8)	2	
10	09280-09012	O RING (D:2.3,ID:9)	1	
11	09289-06L02	DUST SEAL (5X17X3.5)	1	

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17024	WASHER (T:1.1)	1	REV
11-2	09160-17039	WASHER (T:1.2)	1	REV
11-3	09160-17025	WASHER (T:1.3)	1	REV
11-4	09160-17040	WASHER (T:1.4)	1	REV
11-5	09160-17026	WASHER (T:1.5)	1	REV
11-6	09160-17041	WASHER (T:1.6)	1	REV

FIG.220A



DF20A_P01_019_220A
TRANSMISSION

FIG.220A (1-D-2) TRANSMISSION (DF9.9B)(DF9.9BR)(DF15A)(DF15AR)(DF20A)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
11-7	09160-17027	WASHER (T:1.7)	1	REV	
11-8	09160-17042	WASHER (T:1.8)	1	REV	
11-9	09160-17028	WASHER (T:1.9)	1	REV	
12-1	09181-25160	SHIM (T:0.7)	2		
12-2	09181-25162	SHIM (T:0.8)	2		
12-3	09181-25164	SHIM (T:0.9)	2		
12-4	09160-25040	WASHER (T:1.0)	2		
12-5	09160-25041	WASHER (T:1.1)	2		
12-6	09160-25042	WASHER (T:1.2)	2		
12-7	09181-25181	SHIM (T:1.3)	2		
13	09181-15241	WASHER (15X22X2)	1	FWD	
14	57610-99JL0	SHAFT, PROPELLER	1		
15	57621-99J11	SHIFTER, CLUTCH DOG	1		
16	09202-04025	PIN (4X31)	1		
17	59441-94J00	SPRING, RETURN	1		
18	59441-99J00	SPRING, DOG	1		
19	57631-93901	ROD, PUSH	1		
20	57632-97L00	PIN, PUSH	1		
21	56130-99J30	HOUSING, DRIVE SHAFT	1		
22	09282-13L01	.OIL SEAL (12.5X25X7)	2		
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1		
24	09116-06229	BOLT (6X25)	2		

DF9.9B P01
DF9.9BR P01
DF15A P01
DF15AR P01
DF20A P01
DF20A P40
DF20AR P01

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	57100-90L40	SHAFT ASSY, DRIVE (S)	1	W/TRANSOM(S)
1-2	57100-90L30	SHAFT ASSY, DRIVE (L)	1	W/TRANSOM(L)
1-3	57100-90L50	SHAFT ASSY, DRIVE (X)	1	W/TRANSOM(X)
2	08110-60020	.BEARING	1	
3	09380-15001	.SNAP RING	1	
4	09160-20027	WASHER (20X35X2.75)	1	
5-1	09181-20251	SHIM (T:1.0)	1	
5-2	09160-20042	SHIM (T:1.1)	1	
5-3	09160-20043	SHIM (T:1.2)	1	
5-4	09160-20044	SHIM (T:1.3)	1	
5-5	09181-20244	SHIM (T:0.7)	1	
5-6	09181-20246	SHIM (T:0.8)	1	
5-7	09181-20248	SHIM (T:0.9)	1	
6	09160-21009	WASHER (21X35X2.75)	1	
7	09263-20024	BEARING (20X35X4.5)	1	
8	57311-99J10	PINION	1	
9	57510-99J11	GEAR, FORWARD (NT:25)	1	
10	57521-99J10	GEAR, REVERSE (NT:25)	1	
11-1	09160-17053	WASHER (T:1.1)	1	REV
11-2	09160-17054	WASHER (T:1.2)	1	REV
11-3	09160-17055	WASHER (T:1.3)	1	REV
11-4	09160-17056	WASHER (T:1.4)	1	REV
11-5	09160-17057	WASHER (T:1.5)	1	REV
11-6	09160-17058	WASHER (T:1.6)	1	REV
11-7	09160-17059	WASHER (T:1.7)	1	REV
11-8	09160-17060	WASHER (T:1.8)	1	REV

Exploded view diagram of a front wheel hub assembly. The diagram shows the main shaft assembly (1) with various seals (2, 3, 4, 5, 6, 7, 8), a bearing (9), a gear (10), a pin (11), a spring (12), a pin (13), a pin (14), a pin (15), a pin (16), a pin (17), a pin (18), a pin (19), a pin (20), a pin (21), a pin (22), a pin (23), and a pin (24). A 'FWD' arrow points to the left.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
11-9	09160-17061	WASHER (T:1.9)	1	REV
12-1	09181-25160	SHIM (T:0.7)	2	
12-2	09181-25162	SHIM (T:0.8)	2	
12-3	09181-25164	SHIM (T:0.9)	2	
12-4	09160-25040	WASHER (T:1.0)	2	
12-5	09160-25041	WASHER (T:1.1)	2	
12-6	09160-25042	WASHER (T:1.2)	2	
12-7	09181-25181	SHIM (T:1.3)	2	
13	09181-15241	WASHER (15X22X2)	1	FWD
14	57610-99JL0	SHAFT, PROPELLER	1	
15	57621-99J11	SHIFTER, CLUTCH DOG	1	
16	09202-04025	PIN (4X31)	1	
17	59441-94J00	SPRING, RETURN	1	
18	59441-99J00	SPRING, DOG	1	
19	57631-93901	ROD, PUSH	1	
20	57632-97L00	PIN, PUSH	1	
21	56130-99J30	HOUSING, DRIVE SHAFT	1	
22	09282-13L01	.OIL SEAL (12.5X25X7)	2	
23	56132-99J10	GASKET, DRIVE SHAFT BRG HSG	1	
24	09116-06229	BOLT (6X25)	2	

DF20A_P01_019

FIG.301A




FIG.301A (1-D-5) STARTING MOTOR (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-89L00	STARTING MOTOR	1	
2	31150-98L00	.CASE, GEAR	1	
3	31170-89L00	.HOUSING, REAR	1	
4	31173-98L00	.HOLDER ASSY, BRUSH	1	
5	31191-63J00	.LEVER ASSY	1	
6	31220-89L00	.SWITCH ASSY	1	
7	31311-63J00	ARMATURE	1	
8	31192-92J00	.SCREW SET	1	
9	31261-75F10	.BOLT, THROUGH	2	
10	31340-89L00	.CLUTCH SET, STARTER	1	
11	31313-86030	..STOPPER SET	1	
12	31320-89L00	..PINION	1	
13	31341-89L00	..SHAFT, PINION	1	
14	31343-63J00	..INTERNAL GEAR	1	
15	31344-63J00	..GEAR ASSY	3	
16	31912-89L00	BAND, STARTING MOTOR	1	
17	31918-92J01	DAMPER, LOWER	1	
18	01550-08207	BOLT	2	
19	01550-08307	BOLT	2	
20	08316-10087	NUT	1	

FIG.303A

FIG.303A (1-D-6) MAGNETO (MANUAL STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32120-89L10	COIL, STATOR & PULSER	1	
2	01547-0630A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L10	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	
11	08322-0106A	WASHER	3	
12	36615-96300	TERMINAL, RESIN	2	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40




FIG.303B

FIG.303B (1-D-7) MAGNETO (ELECTRIC STARTER)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	32120-89L00	COIL, STATOR & PULSER	1	UP TO PROD. 2018 DEC
1-2	32120-89L20	COIL, STATOR & PULSER	1	FROM PROD. 2019 JAN
2	01547-0625A	BOLT	3	
3	01550-05127	BOLT	2	
4	32102-89L00	FLYWHEEL	1	
5	09140-14008	NUT	1	
6	09160-15057	WASHER (15X27X4)	1	
7	08341-31039	KEY	1	
8	09407-14407	CLAMP (L:145)	8	
9	33220-84M10	SENSOR ASSY CMP	1	
10	01550-06167	BOLT	1	




FIG.310A




FIG.310A (1-D-8) RECTIFIER/IGNITION COIL (DF9.9B)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	W/ELECTRIC STARTER
11	01550-06167	BOLT	1	W/ELECTRIC STARTER
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16-1	33930-89L40	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
16-2	33930-89L50	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
19	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
20	09160-06168	WASHER (6X14X1)	1	

DF9.9B P01



FIG.310B




FIG.310B (1-D-9) RECTIFIER/IGNITION COIL (DF9.9BR)(DF9.9BT)(DF9.9BTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	
11	01550-06167	BOLT	1	
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16	33930-89L40	UNIT, ENGINE CONTROL	1	
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
19	38915-90J00	HOLDER, RELAY	1	
20	09160-06168	WASHER (6X14X1)	1	

DF9.9BR P01
DF9.9BT P01
DF9.9BTH P01

FIG.310C




FIG.310C (1-D-10) RECTIFIER/IGNITION COIL (DF15A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	W/ELECTRIC STARTER
11	01550-06167	BOLT	1	W/ELECTRIC STARTER
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16-1	33930-89L00	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
16-2	33930-89L10	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
19	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
20	09160-06168	WASHER (6X14X1)	1	

DF15A P01



FIG.310D




FIG.310D (1-D-11) RECTIFIER/IGNITION COIL (DF15AR)(DF15AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	
11	01550-06167	BOLT	1	
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16	33930-89L00	UNIT, ENGINE CONTROL	1	
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
19	38915-90J00	HOLDER, RELAY	1	
20	09160-06168	WASHER (6X14X1)	1	

DF15AR P01
DF15AT P01

FIG.310E




FIG.310E (1-D-12) RECTIFIER/IGNITION COIL (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	W/ELECTRIC STARTER
11	01550-06167	BOLT	1	W/ELECTRIC STARTER
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16-1	33930-89L20	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
16-2	33930-89L30	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
19	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
20	09160-06168	WASHER (6X14X1)	1	

DF20A P01

FIG.310F




FIG.310F (1-D-13) RECTIFIER/IGNITION COIL (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	W/ELECTRIC STARTER
2	32815-89L00	BRACKET, RECTIFIER	1	W/ELECTRIC STARTER
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	W/ELECTRIC STARTER
11	01550-06167	BOLT	1	W/ELECTRIC STARTER
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16-1	33930-89L60	UNIT, ENGINE CONTROL	1	W/ELECTRIC STARTER
16-2	33930-89L70	UNIT, ENGINE CONTROL	1	W/MANUAL STARTER
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	W/ELECTRIC STARTER
19	38915-90J00	HOLDER, RELAY	1	W/ELECTRIC STARTER
20	09160-06168	WASHER (6X14X1)	1	

DF20A P40

FIG.310G




FIG.310G (1-D-14) RECTIFIER/IGNITION COIL (DF20AR)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32800-89L01	RECTIFIER/REGULATOR ASSY	1	
2	32815-89L00	BRACKET, RECTIFIER	1	
3	09116-06517	BOLT (6X25)	1	
4	09116-06196	BOLT (6X20)	1	
5	32890-89L03	HOLDER, ELECTRIC PARTS	1	
6	09320-08056	CUSHION	1	
7	09169-06062	WASHER	1	
8	09169-06063	WASHER	1	
9	09320-08051	CUSHION	2	
10	01550-06207	BOLT	2	
11	01550-06167	BOLT	1	
12	33500-07H00	CAP, SPARK PLUG	2	
13	09408-00159	CLAMP	2	
14	33410-89L11	COIL, IGNITION	1	
15	01550-0630C	BOLT	2	
16	33930-89L20	UNIT, ENGINE CONTROL	1	
17	33925-89L00	CUSHION, ENGINE CONTROL UNIT	1	
18	38860-76F01	RELAY, ENGINE CONTROL UNIT	1	
19	38915-90J00	HOLDER, RELAY	1	
20	09160-06168	WASHER (6X14X1)	1	

DF20AR P01
DF20AT P01
DF20ATH P01



FIG.322A




FIG.322A (1-D-15) HARNESS (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L10	CABLE, STARTER	1	W/ELECTRIC STARTER
2	09407-14403	CLAMP (L:125)	1	W/ELECTRIC STARTER
3	09407-14407	CLAMP (L:145)	1	W/ELECTRIC STARTER
4	01547-0616C	BOLT	2	W/ELECTRIC STARTER
5-1	36610-89LB0	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
				UP TO PROD. 2018 DEC
5-2	36610-89LG0	HARNESS ASSY, WIRING	1	W/ELECTRIC STARTER
				FROM PROD. 2019 JAN
5-3	36610-89LC0	HARNESS ASSY, WIRING	1	W/MANUAL STARTER
6	09481-10501	.FUSE (10A)	1	W/ELECTRIC STARTER
7	09481-30501	.FUSE (30A)	1	W/ELECTRIC STARTER
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10-1	09407-14407	CLAMP (L:145)	4	W/ELECTRIC STARTER
10-2	09407-14407	CLAMP (L:145)	5	W/MANUAL STARTER
11	32916-89L00	COVER, CONNECTOR	1	W/ELECTRIC STARTER
12	36617-89L10	BRACKET, HARNESS	1	W/ELECTRIC STARTER
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L01	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00340	CLAMP	1	
18	09408-00252	CLAMP	1	
19	09408-00338	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40



FIG.322B




FIG.322B (1-E-2) HARNESS (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L10	CABLE, STARTER	1	
2-1	36610-89LD0	HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
2-2	36610-89LH0	HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L01	BRACKET, HARNESS	1	
10	36617-91J00	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00340	CLAMP	1	
13	09408-00339	CLAMP	1	
14	09408-00338	CLAMP	1	
15	01550-0612C	BOLT	2	
16	01550-06127	BOLT	1	
17	09407-14407	CLAMP (L:145)	1	
18-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT
18-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	L:2000 OPT
19	34923-96L00	UNIT, GATEWAY	1	L:3000 OPT
DF9.9BR P01				
DF15AR P01				
DF20AR P01				

FIG.322C




FIG.322C (1-E-3) HARNESS (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L10	CABLE, STARTER	1	
2-1	36610-89LF0	HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
2-2	36610-89LK0	HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
3	09481-10501	.FUSE (10A)	1	
4	09481-30501	.FUSE (30A)	1	
5	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
6	09407-14407	CLAMP (L:145)	4	
7	32916-89L00	COVER, CONNECTOR	1	
8	33634-96J00	CAP, SERVICE CONNECTOR	1	
9	36617-89L50	BRACKET, HARNESS	1	
10	36617-89L20	BRACKET, SWITCH LEAD	1	
11	09403-08404	CLAMP	1	
12	09408-00024	CLIP (ID:23)	1	
13	09408-00339	CLAMP	1	
14	09408-00338	CLAMP	1	
15	01550-0612C	BOLT	2	
16	01550-06127	BOLT	1	
17	36616-89L10	HOLDER, HARNESS	1	
18	02142-06167	SCREW	2	
19	09407-14407	CLAMP (L:145)	1	
20-1	36620-93J10	WIRE ASSY, REMOCON EXTENSION	1	OPT L:2000
20-2	36620-93J40	WIRE ASSY, REMOCON EXTENSION	1	OPT L:3000
21	34923-96L00	UNIT, GATEWAY	1	OPT

DF9.9BT P01
DF15AT P01
DF20AT P01

FIG.322D




FIG.322D (1-E-4) HARNESS (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33810-89L10	CABLE, STARTER	1	
2	09407-14403	CLAMP (L:125)	1	
3	09407-14407	CLAMP (L:145)	1	
4	01547-0616C	BOLT	2	
5-1	36610-89LE0	HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
5-2	36610-89LJ0	HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
6	09481-10501	.FUSE (10A)	1	
7	09481-30501	.FUSE (30A)	1	
8	36618-43410	.CAP, OIL PRESSURE SWITCH	1	
9	36615-96300	TERMINAL, RESIN	1	
10	09407-14407	CLAMP (L:145)	4	
11	32916-89L00	COVER, CONNECTOR	1	
12	36617-89L10	BRACKET, HARNESS	1	
13	33634-96J00	CAP, SERVICE CONNECTOR	1	
14	36617-89L50	BRACKET, HARNESS	1	
15	36617-91J00	BRACKET, SWITCH LEAD	1	
16	09403-08404	CLAMP	1	
17	09408-00340	CLAMP	1	
18	09408-00339	CLAMP	1	
19	09408-00338	CLAMP	1	
20	01550-0612C	BOLT	2	
21	01550-06127	BOLT	1	
22	36616-89L10	HOLDER, HARNESS	1	
23	02142-06167	SCREW	2	

DF9.9BTH P01
DF20ATH P01



FIG.327A




FIG.327A (1-E-5) PTT SWITCH (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J21	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-99E05	SWITCH ASSY, PTT	1	
4	09116-06517	BOLT (6X25)	2	
5	09169-06062	WASHER	2	

DF9.9BT P01
DF15AT P01
DF20AT P01



FIG.327B




FIG.327B (1-E-6) PTT SWITCH (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38410-93J21	RELAY ASSY, PTT	1	
2	38415-89L00	HOLDER, PTT RELAY	1	
3	37850-94JA3	SWITCH ASSY, PTT	1	
4	37852-94JA0	PLATE, PTT SWITCH	1	
5	09125-05046	SCREW (5X12)	2	
6	29103-93J00	BOLT, PTT SW BRACKET (6X12)	2	
7	09140-05005	NUT	2	
8	09116-06517	BOLT (6X25)	2	
9	09169-06062	WASHER	2	
10	37851-89L00	HOLDER, PTT SWITCH	1	

DF9.9BTH P01
DF20ATH P01

FIG.334A




FIG.334A (1-E-7) SENSOR/SWITCH (DF9.9B)(DF15A)(DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-89L00	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4-1	36367-89L00-YAY	LABEL, WARNING (BLACK)	1	
4-2	36367-89L00-Y5S	LABEL, WARNING (WHITE)	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L20	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L10	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

DF9.9B P01
DF15A P01
DF20A P01

FIG.334B




FIG.334B (1-E-8) SENSOR/SWITCH (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-89L00	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4	36367-89L00-YAY	LABEL, WARNING (BLACK)	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	W/ELECTRIC STARTER
6	37163-89L00	PLUG, STARTING SWITCH HOLE	1	W/MANUAL STARTER
7	37721-89L00	SWITCH ASSY, NEUTRAL	1	
8	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
9	01550-0616C	BOLT	1	
10	36616-89L20	HOLDER, CONNECTOR	1	
11	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
12	13650-52G00	SENSOR, INLET AIR TEMP	1	
13	13655-89L10	GROMMET, INLET AIR TEMP SENSOR	1	
14	18590-58M00	SENSOR, MAP	1	
15	01550-0620C	BOLT	1	

DF20A P40

FIG.334C (1-E-9) SENSOR/SWITCH (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF


DF20A_P01_019

FIG.334D

FIG.334D (1-E-10) SENSOR/SWITCH (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13640-32G20	SENSOR ENGINE, TEMP	1	
2	37820-89L00	SWITCH ASSY, OIL PRESSURE	1	
3	36360-99J10	INDICATOR, OIL PRESSURE	1	
4-1	36367-89L00-YAY	LABEL, WARNING (BLACK)	1	
4-2	36367-89L00-Y5S	LABEL, WARNING (WHITE)	1	
5	37161-89L02	SWITCH ASSY, STARTER MOTOR	1	
6	37721-89L00	SWITCH ASSY, NEUTRAL	1	
7	37726-89L00	BRACKET, NEUTRAL SWITCH	1	
8	01550-0616C	BOLT	1	
9	36616-89L20	HOLDER, CONNECTOR	1	
10	37725-89L01	ACTUATOR, NEUTRAL SWITCH	1	
11	13650-52G00	SENSOR, INLET AIR TEMP	1	
12	13655-89L10	GROMMET, INLET AIR TEMP SENSOR	1	
13	18590-58M00	SENSOR, MAP	1	
14	01550-0620C	BOLT	1	

DF9.9BTH P01
DF20ATH P01





FIG.335A




DF20A_P01_019_335A
CLAMP BRACKET

FIG.335A (1-E-11) CLAMP BRACKET (DF9.9B)(DF15A)(DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
2	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	59315-94J00	BUSH, RELEASE LEVER	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L01	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF9.9B P01
DF15A P01
DF20A P01

FIG.335B



DF20A_P01_019_335B
CLAMP BRACKET

FIG.335B (1-E-12) CLAMP BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-89L00-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-89L00-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-90L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	59315-94J00	BUSH, RELEASE LEVER	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L01	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF20A P40

FIG.335C




FIG.335C (1-E-13) CLAMP BRACKET (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-89L00-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-89L00-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-89L00-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-89L00-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	41211-99JL0	SCREW, CLAMP	2	
4	41212-91J00	HANDLE, CLAMP	2	
5	41213-94J01	PLATE, CLAMP	2	
6	09205-06021	SPRING PIN (6X25)	2	
7	41130-89L00	SHAFT, CLAMP BRACKET	1	
8	09159-22006	NUT	1	
9	09100-06178	BOLT (6X150)	1	
10	09160-06082	WASHER (6.5X13X1.0)	1	
11	09180-06366	SPACER (6.5X10.5X114)	1	
12	29141-93J00	NUT, CLAMP BRKT LOWER (M6)	1	
13	45261-89L00	LEVER, RELEASE	1	
14	59315-94J00	BUSH, RELEASE LEVER	2	
15	09100-08311	BOLT (8X90)	2	
16	09140-08023-XC0	NUT	2	
17	09160-08081	WASHER (8.5X23X1.5)	2	
18	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
19	45420-89L01	PIN, TILT LOCK	1	
20	45425-94J01	STOPPER, TILT LOCK PIN	1	
21	09441-17001	SPRING	1	
22	09160-08170	WASHER (8.5X16X2)	2	
23	45269-89L00	MARK, REVERSE LOCK	1	
24	69911-91J50	MARK, CLAMP BRACKET	1	
25	41210-99JL1	SCREW SET, CLAMP	1	OPT

DF9.9BR P01
DF15AR P01
DF20AR P01

FIG.335D




FIG.335D (1-E-14) CLAMP BRACKET (DF9.9BT)(DF9.9BTH)(DF15AT)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	41111-89LA0-YAY	BRACKET, CLAMP STBD (BLACK)	1	
1-2	41111-89LA0-Y5S	BRACKET, CLAMP STBD (WHITE)	1	
2-1	41121-89LA0-YAY	BRACKET, CLAMP PORT (BLACK)	1	
2-2	41121-89LA0-Y5S	BRACKET, CLAMP PORT (WHITE)	1	
3	09205-06021	SPRING PIN (6X25)	2	
4	41211-94L00	SCREW, CLAMP	2	
5	41212-91J00	HANDLE, CLAMP	2	
6	41213-94J01	PLATE, CLAMP	2	
7	41130-94JA1	SHAFT, CLAMP BRKT	1	
8	41135-93J11	WASHER, CLAMP BRKT SHAFT	1	
9	36894-87D00	LEAD, SWIVEL TO CLAMP	1	
10	36894-87D00	LEAD, PWR TILT TO CLAMP PORT	1	
11	36895-87D01	LEAD, PWR TILT TO CLAMP STBD	1	
12	09125-06063	SCREW (6X10)	5	
13	09159-22006	NUT	1	
14	41221-94JA0	KNOB, TILT STOPPER	1	
15	41222-94JA0	PIN, TILT STOPPER	1	
16	41226-94JA0	BUSH, TILT STOPPER	1	
17	45421-94JA0	PIN, TILT LOCK	2	
18	09116-08128	BOLT (8X40)	2	
19	09205-03004	SPRING PIN (3X20)	1	
20-1	55321-87J01	ANODE, PROTECTION	2	
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
21	09103-06281	BOLT (6X14)	2	
22	29162-93J10	WASHER, TRANSOM BOLT LOCK	2	
23	09160-08081	WASHER (8.5X23X1.5)	2	
24	09100-08311	BOLT (8X90)	2	
25	09140-08023-XC0	NUT	2	

FIG.335D




FIG.335D (1-E-15) CLAMP BRACKET (DF9.9BT)(DF9.9BTH)(DF15AT)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	09160-08170	WASHER (8.5X16X2)	2	
27	69911-91J50	MARK, CLAMP BRACKET	1	
28	41210-89LA0	SCREW SET, CLAMP	1	OPT

- DF9.9BT P01
- DF9.9BTH P01
- DF15AT P01
- DF20AT P01
- DF20ATH P01

FIG.336A





FIG.336A (1-F-2) SWIVEL BRACKET (DF9.9B)(DF15A)(DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L00-Y5S	BRACKET, SWIVEL (S) (WHITE)	1	W/TRANSOM(S)
2-3	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
2-4	43111-89L11-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J60-Y5S	BRACKET, STEERING (S) (WHITE)	1	W/TRANSOM(S)
4-3	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4-4	43750-99J70-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	

FIG.336A




DF20A_P01_019_336A
SWIVEL BRACKET

FIG.336A (1-F-3) SWIVEL BRACKET (DF9.9B)(DF15A)(DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	W/TRANSOM(X)
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L01	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

DF9.9B P01
DF15A P01
DF20A P01

FIG.336B



DF20A_P01_019_336B
SWIVEL BRACKET

FIG.336B (1-F-4) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L00-Y5S	BRACKET, SWIVEL (S) (WHITE)	1	W/TRANSOM(S)
2-3	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
				W/TRANSOM(X)
2-4	43111-89L11-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L)
				W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J60-Y5S	BRACKET, STEERING (S) (WHITE)	1	W/TRANSOM(S)
4-3	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
				W/TRANSOM(X)
4-4	43750-99J70-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L)
				W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	

DF20A_P01_019

FIG.336B





FIG.336B (1-F-5) SWIVEL BRACKET (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
24-1	45710-89L00	ARM, SHALLOW DRIVE	1	W/TRANSOM(S) W/TRANSOM(L)
24-2	45710-89L10	ARM, SHALLOW DRIVE	1	W/TRANSOM(X)
25	45722-94J11	SPRING, ARM	1	
26	09111-10067	BOLT (10X20.5)	2	
27	43411-89L00	LEVER, STEERING ADJUSTER	1	
28	43415-89L01	PLATE, STEERING ADJUSTER(H)	1	
29	43420-89L00	PLATE, STRG ADJ FRICTION	1	
30	43425-89L00	PLATE, STRG ADJ UPPER	1	
31	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
32	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
33	43516-89J00	WASHER, STEERING ADJUSTER	2	
34	43517-89L00	SPACER, STEERING ADJUSTER	1	
35	09116-06225	BOLT (6X15)	4	
36	09159-08L02	NUT	1	
37	09161-08019	WASHER (8.2X18X1.2)	1	

DF20A P40

FIG.336C




DF20A_P01_019_336C
SWIVEL BRACKET

FIG.336C (1-F-6) SWIVEL BRACKET (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	22511-99011	NIPPLE	3	
2-1	43111-89L00-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89L00-Y5S	BRACKET, SWIVEL (S) (WHITE)	1	W/TRANSOM(S)
2-3	43111-89L11-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L)
				W/TRANSOM(X)
2-4	43111-89L11-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L)
				W/TRANSOM(X)
3	43711-99J00	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J60-Y5S	BRACKET, STEERING (S) (WHITE)	1	W/TRANSOM(S)
4-3	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L)
				W/TRANSOM(X)
4-4	43750-99J70-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L)
				W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	41225-89L00	PIN, RELEASE ARM	1	
10	45212-89L00	SPRING, REVERSE LOCK ARM	2	
11	45231-89L00	ARM, REVERSE LOCK	1	
12	45241-89L00	LINK, REVERSE LOCK ARM	1	
13	09204-01002	PIN	1	
14	45247-99J00	PIN, REV LOCK ARM COTTER	1	
15	45250-89L03	LINK, RELEASE	1	
16	09200-06061	PIN	1	
17	09160-06082	WASHER (6.5X13X1.0)	1	
18	09200-05014	PIN	1	
19	43411-939L0	PLATE, STEERING ADJUSTER	1	
20	43412-93900	COVER, STEERING ADJUSTER	1	
21	29440-93J00	SPRING, STEERING ADJUSTER	1	
22	09160-08082	WASHER (8.5X16X1.2)	1	
23	09100-08232	BOLT (8X30)	1	

DF20A_P01_019

FIG.336C (1-F-7) SWIVEL BRACKET (DF9.9BR)(DF15AR)(DF20AR)



DF20A_P01_019

This exploded view diagram illustrates the assembly of a mechanical component, likely a bracket or support. The parts are numbered as follows:

- 1**: A small pin or clip located on the side of the main housing.
- 2**: The main vertical shaft or post.
- 3**: Two cylindrical sleeves or spacers that fit onto the shaft.
- 4**: A long, thin vertical rod or pin passing through the top of the assembly.
- 5**: A large circular flange or washer at the bottom.
- 6**: A smaller circular flange or washer above the bottom flange.
- 7**: Two large circular end caps or bushings, one at the top and one at the bottom of the shaft.
- 8**: A circular flange or washer located above the top end cap.
- 9**: A small rectangular block or spacer on the side of the shaft.
- 10**: A large hex nut.
- 11**: A large coil spring.
- 12**: A small spacer or pin between the spring and the nut.
- 13**: A long threaded rod or bolt passing through the spring and nut.
- 14**: A bracket or plate at the top of the assembly.
- 15**: A small pin or clip on the bracket.
- 16**: A small screw or bolt on the bracket.
- 17**: A small pin or clip on the bracket.
- 18**: A small hook or clip on the side of the shaft.
- 19**: A small screw or bolt on the side of the shaft.
- 20**: A small pin or clip on the side of the shaft.
- 21**: A small screw or bolt on the side of the shaft.

DF20A_P01_019_336D
SWIVEL BRACKET

FIG.336D (1-F-8) SWIVEL BRACKET (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LB0-Y5S	BRACKET, SWIVEL (S) (WHITE)	1	W/TRANSOM(S)
2-3	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
2-4	43111-89LA0-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J60-Y5S	BRACKET, STEERING (S) (WHITE)	1	W/TRANSOM(S)
4-3	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4-4	43750-99J70-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
15	09160-08082	WASHER (8.5X16X1.2)	2	
16	09108-08286	STUD BOLT	2	
17	09159-08059	NUT	2	
18	43759-89L00	HOLDER, DRAIN HOSE	1	
19	09116-06225	BOLT (6X15)	1	
20-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
20-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)

DF20A_P01_019

FIG.336D




FIG.336D (1-F-9) SWIVEL BRACKET (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

DF9.9BT P01
DF15AT P01
DF20AT P01

FIG.336E




FIG.336E (1-F-10) SWIVEL BRACKET (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	22511-99011	NIPPLE	3	W/TRANSOM(S)
1-2	22511-99011	NIPPLE	4	W/TRANSOM(L) W/TRANSOM(X)
2-1	43111-89LB0-YAY	BRACKET, SWIVEL (S) (BLACK)	1	W/TRANSOM(S)
2-2	43111-89LB0-Y5S	BRACKET, SWIVEL (S) (WHITE)	1	W/TRANSOM(S)
2-3	43111-89LA0-YAY	BRACKET, SWIVEL (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
2-4	43111-89LA0-Y5S	BRACKET, SWIVEL (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
3	43711-94JA0	BUSH, STEERING	2	
4-1	43750-99J60-YAY	BRACKET, STEERING (S) (BLACK)	1	W/TRANSOM(S)
4-2	43750-99J60-Y5S	BRACKET, STEERING (S) (WHITE)	1	W/TRANSOM(S)
4-3	43750-99J70-YAY	BRACKET, STEERING (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4-4	43750-99J70-Y5S	BRACKET, STEERING (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
5	09160-27012	WASHER (27.5X47X1)	1	
6	09282-27002	OIL SEAL (26X39X5)	1	
7	43211-87JL0	BUSH, SWIVEL BRACKET	2	
8	09160-27012	WASHER (27.5X47X1)	1	
9	43411-939L0	PLATE, STEERING ADJUSTER	1	
10	43412-93900	COVER, STEERING ADJUSTER	1	
11	29440-93J00	SPRING, STEERING ADJUSTER	1	
12	09160-08082	WASHER (8.5X16X1.2)	1	
13	09100-08232	BOLT (8X30)	1	
14	43411-89LA0	LEVER, STEERING ADJUSTER	1	
15	43415-89L01	PLATE, STEERING ADJUSTER(H)	1	
16	43420-89L00	PLATE, STRG ADJ FRICTION	1	
17	43425-89L00	PLATE, STRG ADJ UPPER	1	
18	43512-89L00	SHAFT, STRG ADJ THREAD(H)	1	
19	43515-88L00	WASHER, STRG ADJ FRICTIONPLATE	2	
20	43516-89J00	WASHER, STEERING ADJUSTER	2	
21	43517-89L00	SPACER, STEERING ADJUSTER	1	
22	09116-06225	BOLT (6X15)	4	
23	09159-08L02	NUT	1	
24	09161-08019	WASHER (8.2X18X1.2)	1	



FIG.336E




FIG.336E (1-F-11) SWIVEL BRACKET (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
25-1	55321-87J01	ANODE, PROTECTION	1	W/TRANSOM(L) W/TRANSOM(X)
25-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT W/TRANSOM(L) W/TRANSOM(X)
26	09103-06281	BOLT (6X14)	1	W/TRANSOM(L) W/TRANSOM(X)

DF9.9BTH P01
DF20ATH P01

FIG.338A




FIG.338A (1-F-12) TILT CYLINDER (DF9.9BT)(DF9.9BTH)(DF15AT)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	48000-89LA4	POWER TILT ASSY	1	
2	48864-89LA0	.MANUAL VALVE	1	
3	48681-87J11	.CIRCLIP	1	
4	48553-88L00	.SEAL WASHER	1	
5	48510-94600	.PUMP ASSY, GEAR	1	
6	48583-95E00	.JOINT, DRIVE	1	
7	31123-89J10	.O RING	1	
8	48572-94J00	.CAP	1	
9	48664-87D00	.O RING	1	
10	31193-94J00	.BAND	1	
11	31192-94J01	.SCREW	1	
12	31281-94J01	.BOLT	2	
13	48582-97E00	.FILTER	1	
14	38100-89LA3	.MOTOR ASSY, PTT	1	
15	48664-87D00	.O RING	2	
16	48121-94JA0	SHAFT, TILT CYL LOWER	1	
17	48321-97E01	SHAFT, TILT CYL UPPER	1	
18	48325-97E00	BUSH	4	
19-1	55321-87J01	ANODE	1	
19-2	55321-87J11	ANODE(MAGNESIUM)	1	OPT
20	09103-06281	BOLT (6X14)	1	
21	09116-08150	BOLT (8X27)	2	
22	09380-12002	SNAP RING	2	
23	09407-14407	CLAMP (L:145)	3	

DF9.9BT P01
DF9.9BTH P01
DF15AT P01
DF20AT P01
DF20ATH P01

FIG.340A




FIG.340A (1-F-13) PTT MOTOR (DF9.9BT)(DF9.9BTH)(DF15AT)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38100-89LA3	MOTOR ASSY, PTT	1	
2	31174-89LA1	..BRACKET	1	
3	31136-94J00	..BRAKER	1	
4	31133-94910	..BRUSH	1	
5	31123-94J01	..O RING	1	
6	33799-97E00	..OIL SEAL	1	
7	31135-94900	..SPRING	2	
8	09136-05041	..SCREW (5X20)	2	
9	31311-94J00	..ARMATURE	1	

DF9.9BT P01
DF9.9BTH P01
DF15AT P01
DF20AT P01
DF20ATH P01



FIG.401A

FIG.401A (1-F-14) ENGINE HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51110-89L03	HOLDER, ENGINE	1	
2	51211-89L00	GASKET, ENGINE HOLDER	1	
3	09116-08151	BOLT (8X30)	3	
4	09202-06023	PIN (6X10)	2	
5	09282-12L04	OIL SEAL (12X25X7)	1	
6	16515-89L10	HOSE, OIL	1	
7	54112-99J01	BOLT, UPR MOUNT (L:123)	2	
8	54113-99JM0	WASHER, UPPER MOUNT BOLT	2	
9	54127-89L00	MOUNT, UPRER SIDE	1	
10	54125-99J00	STOPPER, UPR REVERSE THRUST	2	
11	54130-89L00	MOUNT, UPPER	2	
12	54137-89L00	COVER, UPPER MOUNT	2	
13	09116-08137	BOLT (8X22)	4	
14	09140-10031	NUT	2	
15	01560-08307	BOLT	7	
16	09401-12413	CLIP	1	
17	16520-99J00	STRAINER, OIL	1	
18	09401-13424	CLIP	1	




FIG.405A




FIG.405A (1-F-15) DRIVE SHAFT HOUSING (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-89L20-YAY	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-89L20-Y5S	HOUSING, DRIVE SHAFT (S) (WHITE)	1	W/TRANSOM(S)
3-3	52110-89L30-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
3-4	52110-89L30-Y5S	HOUSING, DRIVE SHAFT (L) (WHITE)	1	W/TRANSOM(L) W/TRANSOM(X)
4	43112-94L01	.PIPE, EXHAUST	1	
5	61155-95J00	.TUBE, WATER INSPECTION	1	
6	52113-89L00	GASKET, DRIVE SHAFT HOUSING	1	
7	09116-08151	BOLT (8X30)	6	
8	09202-06023	PIN (6X10)	2	
9	09168-12017	GASKET (12X17X1)	1	
10	09248-12009	PLUG (12X18.65)	1	
11	54151-99J00	MOUNT, LOWER THRUST	1	
12	54167-99J01	MOUNT, LOWER SIDE	2	

FIG.405A




FIG.405A (1-G-2) DRIVE SHAFT HOUSING (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13-1	54211-99J01-YAY	COVER, LWR MOUNT STBD (BLACK)	1	
13-2	54211-99J01-Y5S	COVER, LWR MOUNT STBD (WHITE)	1	
14-1	54221-99J01-YAY	COVER, LWR MOUNT PORT (BLACK)	1	
14-2	54221-99J01-Y5S	COVER, LWR MOUNT PORT (WHITE)	1	
15	54213-93901	PIN, KNOCK	2	
16	09116-08154	BOLT (8X40)	2	
17-1	52131-89L00-YAY	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
17-2	52131-89L00-Y5S	CASE, EXTENSION (WHITE)	1	W/TRANSOM(X)
18	09116-08151	BOLT (8X30)	4	W/TRANSOM(X)
19	09320-13022	BUSH	1	W/TRANSOM(X)
20	09202-06023	PIN (6X10)	2	W/TRANSOM(X)

- DF9.9B P01
- DF9.9BR P01
- DF9.9BT P01
- DF9.9BTH P01
- DF15A P01
- DF15AR P01
- DF15AT P01
- DF20A P01
- DF20AR P01
- DF20AT P01
- DF20ATH P01

FIG.405B




FIG.405B (1-G-3) DRIVE SHAFT HOUSING (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17913-93J00	PLUG, WATER	1	
2	17914-93J00	GASKET, WATER PLUG	1	
3-1	52110-89L20-YAY	HOUSING, DRIVE SHAFT (S) (BLACK)	1	W/TRANSOM(S)
3-2	52110-89L30-YAY	HOUSING, DRIVE SHAFT (L) (BLACK)	1	W/TRANSOM(L) W/TRANSOM(X)
4	43112-94L01	.PIPE, EXHAUST	1	
5	61155-95J00	.TUBE, WATER INSPECTION	1	
6	52113-89L00	GASKET, DRIVE SHAFT HOUSING	1	
7	09116-08151	BOLT (8X30)	6	
8	09202-06023	PIN (6X10)	2	
9	09168-12017	GASKET (12X17X1)	1	
10	09248-12009	PLUG (12X18.65)	1	
11	54151-99J00	MOUNT, LOWER THRUST	1	
12	54167-99J01	MOUNT, LOWER SIDE	2	
13	54211-99J01-YAY	COVER, LWR MOUNT STBD (BLACK)	1	
14	54221-99J01-YAY	COVER, LWR MOUNT PORT (BLACK)	1	
15	54213-93901	PIN, KNOCK	2	
16	09116-08154	BOLT (8X40)	2	
17	52131-89L00-YAY	CASE, EXTENSION (BLACK)	1	W/TRANSOM(X)
18	09116-08151	BOLT (8X30)	4	W/TRANSOM(X)
19	09320-13022	BUSH	1	W/TRANSOM(X)
20	09202-06023	PIN (6X10)	2	W/TRANSOM(X)

DF20A P40

FIG.407A




FIG.407A (1-G-4) GEAR CASE (3 BLADE) (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
1-2	55100-99J40-Y5S	CASE, GEAR (WHITE)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10-1	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
10-2	56120-99J41-Y5S	HOUSING, PROPELLER SHAFT (WHITE)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	

FIG.407A




FIG.407A (1-G-5) GEAR CASE (3 BLADE) (P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15-3	58100-89L60-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L70-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-89L50-019	PROPELLER, 3X9-1/4X12 (M1201) (BLACK)	1	
15-6	58100-90L41-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-7	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-8	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55321-87J11	ANODE (MAGNESIUM)	1	OPT

- DF9.9B P01
- DF9.9BR P01
- DF9.9BT P01
- DF9.9BTH P01
- DF15A P01
- DF15AR P01
- DF15AT P01
- DF20A P01
- DF20AR P01
- DF20AT P01
- DF20ATH P01

FIG.407B




FIG.407B (1-G-6) GEAR CASE (3 BLADE) (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-89L00-019	PROPELLER, 3X9-1/4X7 (M701) (BLACK)	1	
15-2	58100-89L20-019	PROPELLER, 3X9-1/4X9 (M930) (BLACK)	1	
15-3	58100-89L60-019	PROPELLER, 3X9-1/4X10 (M1001) (BLACK)	1	
15-4	58100-89L70-019	PROPELLER, 3X9-1/4X11 (M1101) (BLACK)	1	
15-5	58100-89L50-019	PROPELLER, 3X9-1/4X12 (M1201) (BLACK)	1	
15-6	58100-90L41-019	PROPELLER, 3X9-1/4X8 (M821) (BLACK)	1	
15-7	58100-90L50-019	PROPELLER, 3X9-1/4X9 (M911) (BLACK)	1	
15-8	58100-90L60-019	PROPELLER, 3X9-1/4X10 (M1011) (BLACK)	1	
16	58120-89L00	.BUSH, PROPELLER	1	

FIG.407B





FIG.407B (1-G-7) GEAR CASE (3 BLADE) (P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF20A P40

FIG.407C




DF20A_P01_019_407C
GEAR CASE

FIG.407C (1-G-8) GEAR CASE (4 BLADE) (DF9.9B)(DF9.9BR)(DF9.9BT)(DF15A)(DF15AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
1-2	55100-99J40-Y5S	CASE, GEAR (WHITE)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10-1	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
10-2	56120-99J41-Y5S	HOUSING, PROPELLER SHAFT (WHITE)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15	58100-94JB1-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF9.9B P01
DF9.9BR P01
DF9.9BT P01
DF15A P01
DF15AR P01

FIG.407D




DF20A_P01_019_407D
GEAR CASE

FIG.407D (1-G-9) GEAR CASE (4 BLADE) (DF15AT)(DF20AR)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
1-2	55100-99J40-Y5S	CASE, GEAR (WHITE)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10-1	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
10-2	56120-99J41-Y5S	HOUSING, PROPELLER SHAFT (WHITE)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15	58100-94JB1-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF15AT P01
DF20AR P01
DF20AT P01
DF20ATH P01

FIG.407E



DF20A_P01_019_407E
GEAR CASE

FIG.407E (1-G-10) GEAR CASE (4 BLADE) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
1-2	55100-99J40-Y5S	CASE, GEAR (WHITE)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10-1	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
10-2	56120-99J41-Y5S	HOUSING, PROPELLER SHAFT (WHITE)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15	58100-94JB1-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF20A P01

DF20A_P01_019

FIG.407F





FIG.407F (1-G-11) GEAR CASE (4 BLADE) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15	58100-94JB1-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF20A P40

FIG.407G




DF20A_P01_019_407G
GEAR CASE

FIG.407G (1-G-12) GEAR CASE (4 BLADE) (DF9.9BTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	55100-99J40-YAY	CASE, GEAR (BLACK)	1	
1-2	55100-99J40-Y5S	CASE, GEAR (WHITE)	1	
2	09263-17048	.BEARING (17X24X27.5)	1	
3	09262-25003	.BEARING (25X52X15)	1	
4	09202-06023	PIN (6X10)	2	
5	09116-08151	BOLT (8X30)	4	
6	55321-87J01	ANODE, PROTECTION	1	
7	09103-06281	BOLT (6X14)	1	
8	59178-97J00	GASKET, DRAIN PLUG	2	
9	09248-08001	PLUG (8X7.5)	2	
10-1	56120-99J41-YAY	HOUSING, PROPELLER SHAFT (BLACK)	1	
10-2	56120-99J41-Y5S	HOUSING, PROPELLER SHAFT (WHITE)	1	
11	08110-60050	.BEARING	1	
12	09280-57002	.O RING (D:3.5,ID:65.2)	1	
13	09289-17L02	.OIL SEAL (17X30X6)	2	
14	09116-06227	BOLT (6X20)	2	
15-1	58100-94JA2-019	PROPELLER, 4X10X5 (BLACK)	1	
15-2	58100-94JB1-019	PROPELLER, 4X10X7 (BLACK)	1	
16	58120-94JA1	.BUSH, PROPELLER	1	
17	57632-94J00	STOPPER, PROPELLER BUSH	1	
18	09141-12005	NUT	1	
19	09160-12066	WASHER (12.5X22X2.5)	1	
20	09204-02004	PIN	1	
21	55331-99J10	CORE, EXHAUST SEAL	1	
22	55332-99J10	RUBBER, EXHAUST SEAL	1	
23	57633-93901	SPACER, PROPELLER NUT	1	
24	55321-87J11	ANODE (MAGNESIUM)	1	OPT

DF9.9BTH P01

FIG.410A



DF20A_P01_019_410A
SIDE COVER

FIG.410A (1-G-13) SIDE COVER (DF9.9B)(DF15A)(DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	FOR YAY
1-2	61810-89L20-Y5S	COVER, SIDE STBD (WHITE)	1	FOR Y5S
2-1	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	FOR YAY
2-2	61820-89L00-Y5S	COVER, SIDE PORT (WHITE)	1	FOR Y5S
3	09116-06523	BOLT (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6-1	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	FOR YAY
6-2	61831-89L00-Y5S	PANEL, FRONT (WHITE)	1	FOR Y5S
7	09320-11017	CUSHION	2	
8	09116-06522	BOLT (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04005	PIN, FASTENER LEVER	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF9.9B P01
DF15A P01
DF20A P01

This exploded view diagram illustrates the assembly of a motorcycle seat. The components are numbered as follows:

- 1**: Main seat shell (upright position)
- 2**: Main seat shell (tilted position)
- 3**: Bolt for seat shell attachment
- 4**: Seat cushion
- 5**: Seat base plate
- 6**: Bolt for seat base plate
- 7**: Bolt for seat base plate
- 8**: Washer for seat base plate
- 9**: Bolt for seat base plate
- 10**: Bolt for seat base plate
- 11**: Bolt for seat base plate
- 12**: Bolt for seat base plate
- 13**: Bolt for seat base plate
- 14**: Bolt for seat base plate
- 15**: Bolt for seat base plate
- 16**: Bolt for seat base plate
- 17**: Bolt for seat base plate
- 18**: Bolt for seat base plate
- 19**: Bolt for seat base plate
- 20**: Bolt for seat base plate
- 21**: Bolt for seat base plate
- 22**: Bolt for seat base plate

The diagram shows the seat shell (1) being attached to the base plate (5) using various bolts (3, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22). The seat cushion (4) is shown separately, and the seat base plate (5) is shown in two positions (upright and tilted) to illustrate the range of motion.

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	
2	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	
3	09116-06523	BOLT (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	
7	09320-11017	CUSHION	2	
8	09116-06522	BOLT (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04005	PIN, FASTENER LEVER	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF20A P40

FIG.410C




FIG.410C (1-G-15) SIDE COVER (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	61810-89L20-QGF	COVER, SIDE STBD (BLACK)	1	FOR YAY
1-2	61810-89L20-Y5S	COVER, SIDE STBD (WHITE)	1	FOR Y5S
2-1	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	FOR YAY
2-2	61820-89L00-Y5S	COVER, SIDE PORT (WHITE)	1	FOR Y5S
3	09116-06523	BOLT (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6-1	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	FOR YAY
6-2	61831-89L00-Y5S	PANEL, FRONT (WHITE)	1	FOR Y5S
7	09320-11017	CUSHION	2	
8	09116-06522	BOLT (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L50	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04005	PIN, FASTENER LEVER	1	
22	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF9.9BR P01
DF15AR P01
DF20AR P01

FIG.410D




FIG.410D (1-H-2) SIDE COVER (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	FOR YAY
1-2	61810-89L30-Y5S	COVER, SIDE STBD (WHITE)	1	FOR Y5S
2-1	61820-89L10-QGF	COVER, SIDE PORT (BLACK)	1	FOR YAY
2-2	61820-89L10-Y5S	COVER, SIDE PORT (WHITE)	1	FOR Y5S
3	09116-06523	BOLT (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6-1	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	FOR YAY
6-2	61831-89L00-Y5S	PANEL, FRONT (WHITE)	1	FOR Y5S
7	09320-11017	CUSHION	2	
8	09116-06522	BOLT (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L50	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04005	PIN, FASTENER LEVER	1	
22	09403-07308	CLAMP	2	
23	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF9.9BT P01
DF15AT P01
DF20AT P01

FIG.410E




FIG.410E (1-H-3) SIDE COVER (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61810-89L30-QGF	COVER, SIDE STBD (BLACK)	1	FOR YAY
1-2	61810-89L30-Y5S	COVER, SIDE STBD (WHITE)	1	FOR Y5S
2-1	61820-89L00-QGF	COVER, SIDE PORT (BLACK)	1	FOR YAY
2-2	61820-89L00-Y5S	COVER, SIDE PORT (WHITE)	1	FOR Y5S
3	09116-06523	BOLT (6X35)	8	
4	61112-89L10	RUBBER, SIDE COVER	1	
5	61134-89L00	SEAL, SIDE COVER	1	
6-1	61831-89L00-QGF	PANEL, FRONT (BLACK)	1	FOR YAY
6-2	61831-89L00-Y5S	PANEL, FRONT (WHITE)	1	FOR Y5S
7	09320-11017	CUSHION	2	
8	09116-06522	BOLT (6X17)	2	
9	61412-89L00	HOOK, FRONT PANEL	1	
10	61610-90L00	FASTENER	1	
11	61616-93EL0	PIN, LEVER	1	
12	09161-04012	WASHER (4.2X11X1)	1	
13	61124-89L40	GROMMET, CABLE	1	
14	61151-91J11	CUSHION, LOWER COVER HOLDER	1	
15	61827-89L00	HOLDER, SIDE COVER	1	
16	02142-0616C	SCREW	1	
17	54144-89L11	SEAL, UPPER MOUNT STBD	1	
18	54145-89L01	SEAL, UPPER MOUNT PORT	1	
19	09251-09007	CUSHION	2	
20	09229-04005	RIVET	2	
21	09385-04005	PIN, FASTENER LEVER	1	
22	09403-07308	CLAMP	2	
23	17917-87L00	CONNECTOR, FLUSH WATER	1	

DF9.9BTH P01
DF20ATH P01

FIG.420A




FIG.420A (1-H-4) ENGINE COVER (DF9.9B)(DF9.9BR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L10-YAY	MARK, EMBLEM REAR (9.9) (BLACK)	1	
11-2	61435-89L10-Y5S	MARK, EMBLEM REAR (9.9) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17	68110-89L01	COVER, WEATHER	1	OPT

DF9.9B P01
DF9.9BR P01

FIG.420B




FIG.420B (1-H-5) ENGINE COVER (DF9.9BT)(DF9.9BTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L10-YAY	MARK, EMBLEM REAR (9.9) (BLACK)	1	
11-2	61435-89L10-Y5S	MARK, EMBLEM REAR (9.9) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	

FIG.420B




FIG.420B (1-H-6) ENGINE COVER (DF9.9BT)(DF9.9BTH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17-1	61447-89L00-YAY	MARK, EMBLEM POWER TILT (BLACK)	1	
17-2	61447-89L00-Y5S	MARK, EMBLEM POWER TILT (WHITE)	1	
18	68110-89L01	COVER, WEATHER	1	OPT

DF9.9BT P01
DF9.9BTH P01

FIG.420C




FIG.420C (1-H-7) ENGINE COVER (DF15A)(DF15AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L20-YAY	MARK, EMBLEM REAR (15) (BLACK)	1	
11-2	61435-89L20-Y5S	MARK, EMBLEM REAR (15) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17	68110-89L01	COVER, WEATHER	1	OPT

DF15A P01
DF15AR P01

FIG.420D




FIG.420D (1-H-8) ENGINE COVER (DF15AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L20-YAY	MARK, EMBLEM REAR (15) (BLACK)	1	
11-2	61435-89L20-Y5S	MARK, EMBLEM REAR (15) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17-1	61447-89L00-YAY	MARK, EMBLEM POWER TILT (BLACK)	1	
17-2	61447-89L00-Y5S	MARK, EMBLEM POWER TILT (WHITE)	1	
18	68110-89L01	COVER, WEATHER	1	OPT

DF15AT P01

FIG.420E




FIG.420E (1-H-9) ENGINE COVER (DF20A P01)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L30-YAY	MARK, EMBLEM REAR (20) (BLACK)	1	
11-2	61435-89L30-Y5S	MARK, EMBLEM REAR (20) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17	68110-89L01	COVER, WEATHER	1	OPT

DF20A P01
DF20AR P01

FIG.420F




FIG.420F (1-H-10) ENGINE COVER (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
9	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11	61435-89L30-YAY	MARK, EMBLEM REAR (20) (BLACK)	1	
12	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17	68110-89L01	COVER, WEATHER	1	OPT

DF20A P40

FIG.420G




FIG.420G (1-H-11) ENGINE COVER (DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	61400-89L40-YAY	COVER ASSY, ENGINE (BLACK)	1	
1-2	61400-89L40-Y5S	COVER ASSY, ENGINE (WHITE)	1	
2	61433-89L01	.COVER, AIR INTAKE INNER	1	
3	03542-05169	.SCREW	4	
4	61622-90L00	.SEAL, RECOIL STARTER	1	
5	61619-89L00	.CUSHION, FASTENER	1	
6	61631-99J00	.HOOK, ENGINE COVER	1	
7	09229-04005	.RIVET	1	
8-1	61443-97L00-YAY	STRIPE, ENGINE COVER STBD (BLACK)	1	
8-2	61443-97L00-Y5S	STRIPE, ENGINE COVER STBD (WHITE)	1	
9-1	61453-97L00-YAY	STRIPE, ENGINE COVER PORT (BLACK)	1	
9-2	61453-97L00-Y5S	STRIPE, ENGINE COVER PORT (WHITE)	1	
10	77811-54GB0-0PG	EMBLEM, "S" (CHROME)	1	
11-1	61435-89L30-YAY	MARK, EMBLEM REAR (20) (BLACK)	1	
11-2	61435-89L30-Y5S	MARK, EMBLEM REAR (20) (WHITE)	1	
12-1	61446-89L10-YAY	DECAL, EFI (BLACK)	1	
12-2	61446-89L10-Y5S	DECAL, EFI (WHITE)	1	
13	61458-89L30	LABEL, ENGINE COVER	1	
14	61471-89L00	DECAL, LEAN BURN	1	
15	59800-89L10	TOOL ASSY	1	
16	99011-89L70-055	MANUAL, OWNER'S	1	
17-1	61447-89L00-YAY	MARK, EMBLEM POWER TILT (BLACK)	1	
17-2	61447-89L00-Y5S	MARK, EMBLEM POWER TILT (WHITE)	1	
18	68110-89L01	COVER, WEATHER	1	OPT

DF20AT P01
DF20ATH P01

FIG.432A




FIG.432A (1-H-12) FUEL TANK

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-89L10	TANK ASSY, FUEL (12L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65831-95D00	.FILTER, OUTLET	1	
5	65890-99100	.OUTLET	1	
6	65892-95D00	.O RING	1	
7	65740-95D01	.PLUG, FUEL CONNECTOR	1	
8	65700-89L30	HOSE, FUEL	1	
9	65750-87J11	.SOCKET, FUEL HOSE	1	
10	65750-95500	.SOCKET, FUEL HOSE	1	
11	65770-89L00	.PUMP, SQUEEZE	1	
12	65781-98500	.CLIP	4	
13	65720-986L0	PLUG, FUEL CONNECTOR	1	
14	09103-06237	BOLT (6X12.5)	1	
15	09160-06085	WASHER (6.5X15X1)	1	

FIG.442A




FIG.442A (1-H-13) DRAG LINK (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01



FIG.444A




FIG.444A (1-H-14) TILLER HANDLE (DF9.9B)(DF9.9BTH)(DF15A)(DF20A P01)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	63111-89L01-YAY	HANDLE, TILLER (BLACK)	1	
1-2	63111-89L01-Y5S	HANDLE, TILLER (WHITE)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5-1	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
5-2	63121-99J00-Y5S	COVER, TILLER HANDLE (WHITE)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24-1	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
24-2	63131-99J11-Y5S	BRACKET, TILLER HANDLE (WHITE)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	

FIG.444A




FIG.444A (1-H-15) TILLER HANDLE (DF9.9B)(DF9.9BTH)(DF15A)(DF20A P01)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05145	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L10	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J01	.NUT	1	
35-1	37835-91J00-YAY	LABEL, STOP (BLACK)	1	
35-2	37835-91J00-Y5S	LABEL, STOP (WHITE)	1	
36-1	21131-94J00-YAY	MARK, CLUTCH SHIFT (BLACK)	1	
36-2	21131-94J00-Y5S	MARK, CLUTCH SHIFT (WHITE)	1	

DF9.9B P01
DF9.9BTH P01
DF15A P01
DF20A P01
DF20ATH P01

FIG.444B




FIG.444B (1-I-2) TILLER HANDLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-89L01-YAY	HANDLE, TILLER (BLACK)	1	
2	63115-99J10	BUSH, TILLER HANDLE NO.1	1	
3	63115-99J00	BUSH, TILLER HANDLE NO.2	1	
4	63116-99J00	RUBBER, FRICTION	1	
5	63121-99J00-YAY	COVER, TILLER HANDLE (BLACK)	1	
6	63210-89L11	GRIP, HANDLE	1	
7	63220-89L00	ROD, HANDLE	1	
8	63225-98601	PLATE, HANDLE ROD ADJUSTER	1	
9	63225-93200	BUSH, HANDLE ROD	1	
10	63240-94J10	ADJUSTER SET, HANDLE	1	
11	63241-986B0	.SUPPORT, ROD	1	
12	63244-94J00	.KNOB, ADJUSTER	1	
13	09148-06008	NUT	1	
14	63610-89L00	CABLE ASSY, THROTTLE	1	
15	63610-89L10	CABLE ASSY, THROTTLE	1	
16	09116-08151	BOLT (8X30)	2	
17	09126-06015	SCREW (6X23)	1	
18	09136-05041	SCREW (5X20)	2	
19	09163-06001	LOCK WASHER	1	
20	09440-12027	SPRING	1	
21	33833-91J00	TUBE, THROTTLE CABLE	1	L:250->50
22	63114-99J01	PLATE, WARNING INDICATOR	1	
23	63122-99J00	PROTECTOR, HANDLE COVER	1	
24	63131-99J11-YAY	BRACKET, TILLER HANDLE (BLACK)	1	
25	63133-89L00	GROMMET, TILLER HANDLE BRACKET	1	

FIG.444B





FIG.444B (1-1-3) TILLER HANDLE (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	65793-89L00	HOLDER, FUEL HOSE	1	
27	09116-06225	BOLT (6X15)	1	
28	09116-08155	BOLT (8X45)	2	
29	09125-05145	SCREW (5X10)	1	
30	09250-12006	CAP (OD:20)	1	
31	63215-93110	MARK, HANDLE GRIP	1	
32	37830-89L10	SWITCH ASSY, EMERGENCY	1	
33	37823-97J00	.PLATE, LOCK	1	
34	37826-97J01	.NUT	1	
35	37835-91J00-YAY	LABEL, STOP (BLACK)	1	
36	21131-94J00-YAY	MARK, CLUTCH SHIFT (BLACK)	1	

DF20A P40

FIG.450A



DF20A_P01_019_450A
REMOTE CONTROL

FIG.450A (1-I-4) REMOTE CONTROL (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	.GROMMET, WIRING HARNESS	1	
3	37110-94J02	.SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY SWITCH LOCK	1	
9	37826-92J00	..NUT	1	
10	37859-90J00	.SPACER	1	
11	37864-94J10	.CAP, PTT SW	1	
12	38500-93J00	.BUZZER ASSY, WARNING	1	
13	67212-95600	.WASHER	1	
14	67214-92E00	.SCREW (5X20)	1	
15	67220-95630	.PLATE ASSY	1	
16	67223-99E10	.KNOB, BRAKE ADJUST	1	

FIG.450A




FIG.450A (1-I-5) REMOTE CONTROL (DF9.9BR)(DF15AR)(DF20AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	

[illegible]

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	
52	36620-89L00	WIRE ASSY,REMOTE CONTROL	1	
53	09481-10501	.FUSE (10A)	1	
54	36615-96300	TERMINAL	5	

DF20A_P01_019_450A
REMOTE CONTROL

DF20A_P01_019

FIG.450B




FIG.450B (1-I-7) REMOTE CONTROL (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-93J51	REMOTE CONTROL ASSY	1	
2	36646-93J01	..WIRE ASSY, PTT SW ADAPTER	1	
3	36628-92E00	..GROMMET, WIRE HARNESS	1	
4	37110-93J11	..SWITCH ASSY, IGNITION	1	
5-1	37141-99E00	..KEY (931)	2	
5-2	37141-99E10	..KEY (932)	2	
5-3	37141-99E20	..KEY (933)	2	
5-4	37141-99E30	..KEY (934)	2	
5-5	37141-99E40	..KEY (935)	2	
5-6	37141-99E50	..KEY (936)	2	
5-7	37141-99E60	..KEY (937)	2	
5-8	37141-99E70	..KEY (938)	2	
5-9	37141-99E80	..KEY (939)	2	
5-10	37141-99E90	..KEY (940)	2	
5-11	37141-99EA0	..KEY (941)	2	
5-12	37141-99EB0	..KEY (942)	2	
6	37143-99E00	..CAP, KEY	2	
7	37149-93J00	..CAP CYLINDER BODY	1	
8	37721-93J91	..SWITCH, NEUTRAL	1	
9	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
10	37823-92E01	..PLATE	1	
11	37826-92J00	..NUT	1	
12	37850-90J06	..SWITCH ASSY, PTT	1	
13	38500-93J90	..BUZZER	1	
14	67212-95600	..WASHER	1	
15	67296-92E11	..SCREW, NEUTRAL SW	2	
16	67220-95630	..PLATE ASSY	1	
17	67223-99E10	..KNOB, BRAKE ADJ	1	

FIG.450B




FIG.450B (1-I-8) REMOTE CONTROL (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
18	67229-95600	.ROLLER	1	
19	67232-95600	.BUSH	1	
20	67238-87D00	.GEAR, DRIVE	1	
21	67241-99E10	.LEVER, FREE THROTTLE	1	
22	67243-95600	.BUSH	1	
23	67244-95600	.WASHER, WAVE	1	
24	67245-95600	.DRUM, FREE THROTTLE	1	
25	67251-99E20	.LEVER, HANDLE	1	
26	67252-95600	.BUSH	2	
27	67253-95600	.WASHER	1	
28	67255-99E10	.ARM, LOCK	1	
29	67256-95600	.HOLDER, NEUT LOCK	1	
30	67257-99E10	.CAP, LEVER	1	
31	67258-99E00	.BRACKET, LOCK ARM	1	
32	67259-87D00	.SPRING, NEUTRAL ARM	1	
33	67261-99E10	.GRIP	1	
34	67296-94310	.SCREW	1	
35	67264-95600	.WASHER	1	
36	67267-93J00	.COVER, WIRE	1	
37	67273-95600	.SPACER	1	
38	67275-95600	.END, CABLE	2	
39	67292-94300	.E RING	3	
40	67294-95600	.SPACER	3	
41	67296-90J10	.SCREW	5	
42	67296-94300	.SCREW	2	
43	67296-95600	.SCREW	3	
44	67296-95610	.SCREW	2	
45	67297-95600	.WASHER	2	

FIG.450B




FIG.450B (1-I-9) REMOTE CONTROL (DF9.9BT)(DF15AT)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
46	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
47	09100-08232	.BOLT (8X30)	1	
48	09126-05003	.SCREW (5X12)	2	
49	09140-06020	.NUT	3	
50	09160-06104	.WASHER (6.5X24X2)	3	
51	37859-90J00	.SPACER	1	
52	67282-94L00	.DECAL, REMOCON SIDE	1	
53	67284-94L00	.MARK, HANDLE LEVER	1	
54	36620-89L00	WIRE ASSY, REMOTE CONTROL	1	
55	09481-10501	.FUSE (10A)	1	
56	36615-96300	TERMINAL	5	

DF9.9BT P01
DF15AT P01
DF20AT P01

FIG.501A




FIG.501A (1-I-10) OPT:METER (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF20AT)				Q'TY	REMARKS
REF NO.	PART NO.	DESCRIPTION			
1-1	34500-93J02	METER ASSY, HOUR		1	BLACK
1-2	34500-93J13	METER ASSY, HOUR		1	WHITE
2	09471-12103	.BULB (12V,3W,T6.5)		1	
3-1	34600-93J02	METER ASSY, VOLTAGE		1	BLACK
3-2	34600-93J13	METER ASSY, VOLTAGE		1	WHITE
4	09471-12103	.BULB (12V,3W,T6.5)		1	
5-1	34100-93J22	SPEEDOMETER ASSY		1	MAX 80KM/H BLACK
5-2	34100-93J33	SPEEDOMETER ASSY		1	MAX 80KM/H WHITE
5-3	34100-93J42	SPEEDOMETER ASSY		1	MAX 45KNOTS BLACK
5-4	34100-93J53	SPEEDOMETER ASSY		1	MAX 45KNOTS WHITE
6	09471-12028	.BULB (12V3.4W,T10)		1	
7	34191-92E00	.TUBE		1	
8	09407-14407	.CLAMP (L:145)		2	
9	36615-96300	.TERMINAL, RESIN		2	
10	34190-95500	SENDER ASSY, SPEEDOMETER		1	
11	03112-0630B	.SCREW		2	
12	34190-87D00	SENDER ASSY, SPEEDOMETER		1	
13-1	34200-93J22	TACHOMETER ASSY		1	BLACK
13-2	34200-93J34	TACHOMETER ASSY		1	WHITE
14	09471-12028	.BULB (12V3.4W,T10)		1	
15-1	34300-93J02	GAUGE ASSY, FUEL		1	BLACK
15-2	34300-93J13	GAUGE ASSY, FUEL		1	WHITE
16	34310-92E00	.LEAD, FUEL GAUGE		1	
17	34360-92E00	.ADAPTER, FUEL GAUGE		1	
18	09471-12103	.BULB (12V,3W,T6.5)		1	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01

FIG.508A




FIG.508A (1-I-11) OPT:REMOTE CONTROL (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-94J20	REMOTE CONTROL ASSY	1	
2	36628-92E00	..GROMMET, WIRING HARNESS	1	
3	37110-94J02	..SWITCH ASSY, IGNITION	1	
4-1	37141-99E00	..KEY (931)	2	
4-2	37141-99E10	..KEY (932)	2	
4-3	37141-99E20	..KEY (933)	2	
4-4	37141-99E30	..KEY (934)	2	
4-5	37141-99E40	..KEY (935)	2	
4-6	37141-99E50	..KEY (936)	2	
4-7	37141-99E60	..KEY (937)	2	
4-8	37141-99E70	..KEY (938)	2	
4-9	37141-99E80	..KEY (939)	2	
4-10	37141-99E90	..KEY (940)	2	
4-11	37141-99EA0	..KEY (941)	2	
4-12	37141-99EB0	..KEY (942)	2	
5	37143-99E00	..CAP, KEY	2	
6	37149-93J00	..CAP, CYLINDER BODY	1	
7	37820-93J04	..SWITCH ASSY, EMERGENCY	1	
8	37823-92E01	..PLATE ASSY, EMERGENCY	1	
9	37826-92J00	SWITCH LOCK	1	
10	37859-90J00	..NUT	1	
11	37864-94J10	..SPACER	1	
12	38500-93J00	..CAP, PTT SW	1	
13	67212-95600	..BUZZER ASSY, WARNING	1	
14	67214-92E00	..WASHER	1	
15	67220-95630	..SCREW (5X20)	1	
		..PLATE ASSY	1	

FIG.508A




FIG.508A (1-I-12) OPT:REMOTE CONTROL (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
16	67223-99E10	.KNOB, BRAKE ADJUST	1	
17	67229-95600	.ROLLER	1	
18	67232-95600	.BUSH	1	
19	67238-87D00	.GEAR, DRIVE	1	
20	67241-99E10	.LEVER, FREE THROTTLE	1	
21	67243-95600	.BUSH	1	
22	67244-95600	.WAVE WASHER	1	
23	67245-95600	.DRUM, FREE THROTTLE	1	
24	67251-99E20	.LEVER, HANDLE	1	
25	67252-95600	.BUSH	2	
26	67253-95600	.WASHER	1	
27	67255-99E10	.ARM, LOCK	1	
28	67256-95600	.HOLDER, NEUTRAL LOCK	1	
29	67257-99E10	.CAP, LEVER	1	
30	67258-99E00	.BRACKET	1	
31	67259-87D00	.SPRING, NEUTRAL ARM	1	
32	67261-99E10	.GRIP	1	
33	67296-94310	.SCREW	1	
34	67264-95600	.WASHER	1	
35	67267-93J00	.COVER, WIRE	1	
36	67273-95600	.SPACER	1	
37	67275-95600	.END, CABLE	2	
38	67282-94L00	.DECAL, REMOCON SIDE	1	
39	67284-94L00	.MARK, HANDLE LEVER	1	
40	67292-94300	.E RING	3	
41	67294-95600	.SPACER	3	
42	67296-90J10	.SCREW, REAR COVER	5	

FIG.508A




FIG.508A (1-I-13) OPT:REMOTE CONTROL (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
43	67296-94300	.SCREW (4X10)	2	
44	67296-95600	.SCREW	3	
45	67296-95610	.SCREW	2	
46	67297-95600	.WASHER	2	
47	77811-54GB0-0PG	.EMBLEM, REAR MARK S (CHROME)	1	
48	09100-08232	.BOLT (8X30)	1	
49	09126-05003	.SCREW (5X12)	2	
50	09140-06020	.NUT	3	
51	09160-06104	.WASHER (6.5X24X2)	3	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40

FIG.513A




FIG.513A (1-I-14) OPT:REMOTE CONTROL PARTS (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	67130-89L10	PARTS SET, R/CON	1	UP TO PROD. 2018 DEC
1-2	67130-89L20	PARTS SET, R/CON	1	FROM PROD. 2019 JAN
2	13513-89L10	.ROD, THROTTLE	1	
3	19120-99J11	.LEVER, THROTTLE CONTROL	1	
4	19122-99J00	.LEVER, INTERLINK THROTTLE	1	
5	19131-89L00	.CONNECTOR	2	
6	19148-89L10	.LEVER, INTERLINK THROTTLE	1	
7	19150-89L00	.BRACKET, THROTTLE LEVER	1	
8	19185-99J00	.SPRING, THROTTLE LEVER	1	
9	21110-89L10	.LEVER, CLUTCH	1	
10	23115-89L10	.LINK, CLUTCH LEVER	1	
11-1	36610-89LD0	.HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
11-2	36610-89LH0	.HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
12	36618-43410	..CAP, OIL PRESSURE SWITCH	1	
13	09481-10501	..FUSE (10A)	1	
14	09481-30501	..FUSE (30A)	1	
15	37163-89L00	.PLUG, STARTING SWITCH HOLE	1	
16	41130-89L00	.SHAFT, CLAMP BRACKET	1	
17	43755-99J00	ATTACHMENT, STEERING BRACKET	1	
18	43759-89L00	.HOLDER, DRAIN HOSE	1	
19	09204-01002	.PIN	2	
20	09160-08082	.WASHER (8.5X16X1.2)	2	
21	61124-89L50	.GROMMET, R/CON CABLE	1	
22	67340-89L10	.HOLDER, R/CON CABLE	1	
23	67467-89J01	.CONNECTOR	2	
24	09108-08286	.STUD BOLT	2	
25	09116-06225	.BOLT (6X15)	1	
26	09159-08059	.NUT	2	

FIG.513A




FIG.513A (1-1-15) OPT:REMOTE CONTROL PARTS (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	09159-22006	.NUT	1	
28	09160-05029	.WASHER (5.5X12X0.8)	2	
29	09160-06046	.WASHER (6.5X20X1.5)	2	
30	09160-06055	.WASHER (7X12X1)	2	
31	09385-06012	.CLIP	2	
32	09407-14407	.CLAMP (L:145)	13	
33	01547-06167	.BOLT	2	
34	01550-06127	.BOLT	2	
35	01550-06167	.BOLT	2	
36	32851-93J00	.CUSHION, LEAD WIRE	1	
37	36616-89L30	.HOLDER, CONNECTOR	1	
38	67345-89L10	.PROTECTOR, R/CON CABLE HOLDER	1	
39	09409-10304-5ES	.CLIP (BLACK)	1	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40

FIG.515A




FIG.515A (1-J-2) OPT:REMOCON CABLE (DF9.9B)(DF9.9BR)(DF9.9BT)(DF15A)(DF15AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

- DF9.9B P01
- DF9.9BR P01
- DF9.9BT P01
- DF15A P01
- DF15AR P01
- DF15AT P01




FIG.515B




FIG.515B (1-J-3) OPT:REMOCON CABLE (DF20A)(DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67140-95600	ATTACHMENT, TWIN REMOCON KIT	1	
2	67294-95600	.SPACER	3	
3	67296-95621	.SCREW (L:165)	3	
4-1	67320-93J00	CABLE, REMOCON 8F (2.4M)	1	
4-2	67320-93J10	CABLE, REMOCON 10F (3.1M)	1	
4-3	67320-93J20	CABLE, REMOCON 12F (3.7M)	1	
4-4	67320-93J30	CABLE, REMOCON 14F (4.2M)	1	
4-5	67320-93J40	CABLE, REMOCON 16F (4.8M)	1	
4-6	67320-93J50	CABLE, REMOCON 18F (5.4M)	1	
4-7	67320-93J60	CABLE, REMOCON 20F (6.1M)	1	
4-8	67320-93J70	CABLE, REMOCON 22F (6.7M)	1	
4-9	67320-93J80	CABLE, REMOCON 24F (7.3M)	1	

DF20A P01
DF20A P40
DF20AR P01
DF20AT P01





FIG.521A

FIG.521A (1-J-4) OPT:HARNESS (DF9.9BTH)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36990-87D00	TERMINAL & SLEEVE SET	1	

DF9.9BTH P01
DF20ATH P01



This exploded view diagram illustrates the assembly of a car horn. The components are numbered as follows:

- 1**: Main horn housing
- 2**: Horn button
- 3**: Horn button pin
- 4**: Horn button cap
- 5**: Horn button spring
- 6**: Horn button mounting plate
- 7**: Horn button gasket
- 8**: Horn button screw
- 9**: Horn button screw
- 10**: Horn button spring
- 11**: Horn button pin
- 12**: Horn button cap
- 13**: Horn button mounting plate
- 14**: Horn button screw
- 15**: Horn button mounting plate
- 16**: Horn button mounting plate
- 17**: Horn button mounting plate
- 18**: Horn button mounting plate
- 19**: Horn button mounting plate
- 20**: Horn button mounting plate
- 21**: Horn button mounting plate
- 22**: Horn button mounting plate
- 23**: Horn button mounting plate
- 24**: Horn button mounting plate
- 25**: Horn button mounting plate
- 26**: Horn button mounting plate
- 27**: Horn button mounting plate
- 28**: Horn button mounting plate

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	37100-96J00	PANEL ASSY, IGNITION SW	1	
2	37110-93J01	.SWITCH ASSY, IGNITION	1	
3-1	37141-99E00	..KEY (931)	2	
3-2	37141-99E10	..KEY (932)	2	
3-3	37141-99E20	..KEY (933)	2	
3-4	37141-99E30	..KEY (934)	2	
3-5	37141-99E40	..KEY (935)	2	
3-6	37141-99E50	..KEY (936)	2	
3-7	37141-99E60	..KEY (937)	2	
3-8	37141-99E70	..KEY (938)	2	
3-9	37141-99E80	..KEY (939)	2	
3-10	37141-99E90	..KEY (940)	2	
3-11	37141-99EA0	..KEY (941)	2	
3-12	37141-99EB0	..KEY (942)	2	
4	37143-99E00	..CAP, KEY	1	
5	37149-93J00	..CAP, CYLINDER BODY	1	
6	37139-99E00	.PANEL, IGNITION SW	1	
7	38500-93J90	.BUZZER ASSY, WARNING	1	
8	09407-08401	.CLAMP (L:80)	1	
9	37803-93J05	PANEL ASSY, EMERGENCY SW	1	
10	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
11	37823-92E01	..PLATE	1	
12	37826-92J10	..NUT	1	
13	37825-99E10	.PANEL, EMERGENCY SW	1	
14	03122-05165	.SCREW	4	

FIG.530A




FIG.530A (1-J-6) OPT:SWITCH (DF9.9BR)(DF9.9BT)(DF15AR)(DF15AT)(DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
15	37210-93J00	PANEL ASSY, LIGHTING SW	1	
16	37212-93J00	.PANEL, LIGHTING SW	1	
17	37100-96J25	PANEL ASSY, ENGINE SW	1	
18	37110-93J01	.SWITCH ASSY, IGNITION	1	
19-1	37141-99E00	..KEY (931)	2	
19-2	37141-99E10	..KEY (932)	2	
19-3	37141-99E20	..KEY (933)	2	
19-4	37141-99E30	..KEY (934)	2	
19-5	37141-99E40	..KEY (935)	2	
19-6	37141-99E50	..KEY (936)	2	
19-7	37141-99E60	..KEY (937)	2	
19-8	37141-99E70	..KEY (938)	2	
19-9	37141-99E80	..KEY (939)	2	
19-10	37141-99E90	..KEY (940)	2	
19-11	37141-99EA0	..KEY (941)	2	
19-12	37141-99EB0	..KEY (942)	2	
20	37143-99E00	..CAP, KEY	1	
21	37149-93J00	..CAP, CYLINDER BODY	1	
22	37139-99E40	.PANEL, IGNITION SWITCH	1	
23	37820-93J10	.SWITCH ASSY, EMERGENCY	1	
24	37823-92E01	..PLATE ASSY, EMERGENCY	1	
25	37826-92J10	..NUT	1	
26	03121-0516A	.SCREW	4	
27	38500-93J90	.BUZZER ASSY, WARNING	1	
28	09407-08401	.CLAMP (L:80)	1	

DF9.9BR P01
DF9.9BT P01
DF15AR P01
DF15AT P01
DF20AR P01
DF20AT P01

FIG.544A




FIG.544A (1-J-7) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF9.9B)(DF9.9BR)(DF9.9B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG (SINGLE)	1	
8	68111-88L00	.EMBLEM, MARK (S)	1	
9	67257-88L00	.CAP, LEVER	1	
10	67281-88L00	.DECAL (SINGLE)	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95600	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	
17	67211-88L00	.COVER (SINGLE)	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, REMOCON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT	4	
25	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF9.9B P01
DF9.9BR P01
DF9.9BT P01
DF15A P01

FIG.544B




FIG.544B (1-J-8) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF15AR)(DF15AT)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG (SINGLE)	1	
8	68111-88L00	.EMBLEM, MARK (S)	1	
9	67257-88L00	.CAP, LEVER	1	
10	67281-88L00	.DECAL (SINGLE)	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95600	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	
17	67211-88L00	.COVER (SINGLE)	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, REMOCON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT	4	
25	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF15AR P01
DF15AT P01
DF20A P01
DF20A P40

FIG.544C




FIG.544C (1-J-9) OPT:REMOTE CONTROL ASSY SINGLE (1) (DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY, SINGLE	1	
2	67261-88L10	.GRIP, REMOCON NO.2	1	
3	67261-88L00	.GRIP, REMOCON NO.1	1	
4	37850-88L00	.SWITCH ASSY, PTT	1	
5	67296-88L00	.SCREW	3	
6	67288-92E20	.WASHER	3	
7	67212-88L00	.COVER, PLUG (SINGLE)	1	
8	68111-88L00	.EMBLEM, MARK (S)	1	
9	67257-88L00	.CAP, LEVER	1	
10	67281-88L00	.DECAL (SINGLE)	1	
11	67296-92E60	.SCREW	2	
12	67288-92E60	.WASHER	2	
13	67253-92E00	.WASHER	1	
14	67275-95600	.END, CABLE	2	
15	67273-95600	.SPACER	1	
16	67271-88L10	.COVER, REMOCON LEVER LOWER	1	
17	67211-88L00	.COVER (SINGLE)	1	
18	67264-88L00	.COVER, LEVER DESIGN	1	
19	67264-88L10	.COVER, LEVER PLATING	1	
20	67251-88L00	.LEVER, HANDLE	1	
21	67500-88L00	KIT, REMOCON SPACER SINGLE	1	
22	09125-05135	.SCREW (5X65)	4	
23	09160-05029	.WASHER (5.5X12X0.8)	4	
24	09140-05005	.NUT	4	
25	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF20AR P01
DF20AT P01

FIG.545A




FIG.545A (1-J-10) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B)(DF9.9BR)(DF9.9E)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY	1	
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L00	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT	3	
20	67230-88L00	.ARM ASSY, SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	

FIG.545A




FIG.545A (1-J-11) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF9.9B)(DF9.9BR)(DF9.9BT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	67237-92E01	.SPRING	5	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	67238-88L00	.GEAR, DRIVE	1	
32	67231-88L00	.GEAR, SHIFT	1	
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, FREE ACCEL	1	
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHIFT, REMOCON DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER, REMOCON DRIVE SHAFT	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE (SINGLE)	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT	4	
47	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF9.9B P01
DF9.9BR P01
DF9.9BT P01
DF15A P01

FIG.545B




FIG.545B (1-J-12) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR)(DF15AT)(DF20A

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY	1	
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L00	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT	3	
20	67230-88L00	.ARM ASSY, SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	

FIG.545B




FIG.545B (1-J-13) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF15AR)(DF15AT)(DF20A

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	67237-92E01	.SPRING	5	
29	67269-92E00	.BRACKET	1	
30	67296-88D10	.SCREW	1	
31	67238-88L00	.GEAR, DRIVE	1	
32	67231-88L00	.GEAR, SHIFT	1	
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, FREE ACCEL	1	
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHIFT, REMOCON DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER, REMOCON DRIVE SHAFT	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE (SINGLE)	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT	4	
47	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF15AR P01
DF15AT P01
DF20A P01
DF20A P40

FIG.545C




FIG.545C (1-J-14) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	67200-88L00	REMOTE CONTROL ASSY	1	
2	67222-92E00	.DUAL PLATE	1	
3	67223-92E00	.BRAKE ADJUST	1	
4	67288-92E00	.WASHER	1	
5	67292-94300	.E RING	4	
6	67272-88L00	.GOM SEAL, WATERPROOF	1	
7	67291-92E00	.SNAP RING	1	
8	67221-92E00	.SHIFT ASSY	1	
9	67224-92E00	.BRAKE ARM ASSY	1	
10	09140-06020	.NUT	2	
11	37721-88L00	.SWITCH ASSY, NEUTRAL	1	
12	67236-92E00	.ROLLER	1	
13	67296-88D10	.SCREW (5X16)	2	
14	67296-92E20	.SCREW	2	
15	67226-92E00	.BOLT, STOPPER FRONT	1	
16	67226-92E10	.BOLT, STOPPER REAR	1	
17	67240-92E00	.ARM ASSY, THROTTLE	1	
18	67228-92E00	.WASHER	1	
19	67286-92E00	.BOLT	3	
20	67230-88L00	.ARM ASSY, SHIFT	1	
21	09125-05042	.SCREW (5X10)	10	
22	67234-88L00	.CASE, GEAR	1	
23	67245-92E00	.LEVER ASSY, THROTTLE	1	
24	67227-92E00	.STOPPER	1	
25	09126-06006	.SCREW (6X20)	2	
26	67233-92E00	.SPRING	1	
27	67235-92E00	.PLATE, SHIFT LOCK	1	
28	67237-92E01	.SPRING	5	
29	67269-92E00	.BRACKET	1	

FIG.545C




FIG.545C (1-J-15) OPT:REMOTE CONTROL ASSY SINGLE (2) (DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	67296-88D10	.SCREW	1	
31	67238-88L00	.GEAR, DRIVE	1	
32	67231-88L00	.GEAR, SHIFT	1	
33	67232-88L00	.BUSH, SHIFT GEAR	1	
34	67241-88L00	.ROD, FREE ACCEL	1	
35	67239-92E00	.PIN	1	
36	67246-88L00	.SHIFT, REMOCON DRIVE	1	
37	67291-92E10	.SNAP RING	1	
38	67243-92E00	.CAP, HOLE	1	
39	67252-88L00	.BUSH, REMOCON DRIVE SHAFT	1	
40	67253-88L00	.WASHER, REMOCON DRIVE SHAFT	1	
41	67239-92E10	.PLATE, SHIFT PIN	1	
42	67274-88L00	.FLANGE, COVER BASE (SINGLE)	2	
43	67296-95610	.SCREW	4	
44	67296-92E30	.SCREW	4	
45	09160-05024	.WASHER (5.5X16X1.5)	4	
46	67287-92E00	.NUT	4	
47	67273-88L00	.GROMMET, REMOCON (SINGLE)	1	

DF20AR P01
DF20AT P01

FIG.546A





FIG.546A (1-K-2) OPT:REMOCON CABLE (ELECTRIC STARTER) (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36620-89L00	WIRE ASSY, REMOTE CONTROL	1	
2	09481-10501	.FUSE (10A)	1	
3	36990-87D00	TERMINAL & SLEEVE SET	1	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32000-89L01	KIT,BATTERY CHARGING	1	
2	32801-89L01	..RECTIFIER & REGULATOR SET	1	
3	32800-94J11	..RECTIFIER/REGULATOR ASSY	1	
4	32815-89L10	..BRACKET, RECTIFILER	1	
5	01550-08207	..BOLT	2	
6	01550-06207	..BOLT	2	
7	09407-14407	..CLAMP (L:145)	3	
8	09408-00184	..CLAMP	1	
9	39600-89L00	..RECEPTACLE SET	1	
10	36740-94J00	..CASE ASSY, FUSE	1	
11	37801-98300	..LEAD RECEPTACLE GROUND	1	
12	39601-95D00	..RECEPTACLE ASSY, LIGHTING	1	
13	36634-93910	...CAP	1	
14	39602-93900	..PLUG, RECEPTACLE	1	
15	09407-14403	..CLAMP (L:125)	2	
16	09407-14407	..CLAMP (L:145)	3	
17	36990-87D00	TERMINAL & SLEEVE SET	1	

DF20A_P01_019

FIG.561A




FIG.561A (1-K-4) OPT:STARTING MOTOR (MANUAL STARTER) (DF9.9B)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L20	STARTER SET, ELECTRIC	1	
2	31101-89L10	.MOTOR SET, STARTING	1	
3	31100-89L00	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5-1	32120-89L00	.COIL, STATOR & PULSER	1	UP TO PROD. 2018 DEC
5-2	32120-89L20	.COIL, STATOR & PULSER	1	FROM PROD. 2019 JAN
6	32800-89L01	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L10	.CABLE SET, STARTER	1	
13	33810-89L10	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19-1	36610-89LB0	.HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
19-2	36610-89LG0	.HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	12	
23	12700-89L21	.CAMSHAFT ASSY	1	
24	33930-89L40	UNIT, ENGINE CONTROL	1	

DF9.9B P01

FIG.561B




FIG.561B (1-K-5) OPT:STARTING MOTOR (MANUAL STARTER) (DF15A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L20	STARTER SET, ELECTRIC	1	
2	31101-89L10	.MOTOR SET, STARTING	1	
3	31100-89L00	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5-1	32120-89L00	.COIL, STATOR & PULSER	1	UP TO PROD. 2018 DEC
5-2	32120-89L20	.COIL, STATOR & PULSER	1	FROM PROD. 2019 JAN
6	32800-89L01	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L10	.CABLE SET, STARTER	1	
13	33810-89L10	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19-1	36610-89LB0	.HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
19-2	36610-89LG0	.HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	12	
23	12700-89L21	.CAMSHAFT ASSY	1	
24	33930-89L00	UNIT, ENGINE CONTROL	1	

DF15A P01

FIG.561C




FIG.561C (1-K-6) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P01)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L20	STARTER SET, ELECTRIC	1	
2	31101-89L10	.MOTOR SET, STARTING	1	
3	31100-89L00	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5-1	32120-89L00	.COIL, STATOR & PULSER	1	UP TO PROD. 2018 DEC
5-2	32120-89L20	.COIL, STATOR & PULSER	1	FROM PROD. 2019 JAN
6	32800-89L01	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L10	.CABLE SET, STARTER	1	
13	33810-89L10	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19-1	36610-89LB0	.HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
19-2	36610-89LG0	.HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	12	
23	12700-89L21	.CAMSHAFT ASSY	1	
24	33930-89L20	UNIT, ENGINE CONTROL	1	

DF20A P01

FIG.561D




FIG.561D (1-K-7) OPT:STARTING MOTOR (MANUAL STARTER) (DF20A P40)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31000-89L20	STARTER SET, ELECTRIC	1	
2	31101-89L10	.MOTOR SET, STARTING	1	
3	31100-89L00	..MOTOR ASSY, STARTING	1	
4	32102-89L00	.FLYWHEEL, MAGNETO	1	
5-1	32120-89L00	.COIL, STATOR & PULSER	1	UP TO PROD. 2018 DEC
5-2	32120-89L20	.COIL, STATOR & PULSER	1	FROM PROD. 2019 JAN
6	32800-89L01	.RECTIFIER/REGULATOR ASSY	1	
7	32815-89L00	.BRACKET, RECTIFIER	1	
8	01550-06167	.BOLT	1	
9	01550-06207	.BOLT	2	
10	01547-0625A	.BOLT	3	
11	09408-00184	.CLAMP	1	
12	33800-89L10	.CABLE SET, STARTER	1	
13	33810-89L10	..CABLE, STARTER	1	
14	36617-89L10	..BRACKET, HARNESS	1	
15	37161-89L02	..SWITCH ASSY, STARTER	1	
16	09407-14403	..CLAMP (L:125)	1	
17	01547-06167	..BOLT	2	
18	09407-14407	..CLAMP (L:145)	1	
19-1	36610-89LB0	.HARNESS ASSY, WIRING	1	UP TO PROD. 2018 DEC
19-2	36610-89LG0	.HARNESS ASSY, WIRING	1	FROM PROD. 2019 JAN
20	38860-76F01	.RELAY ASSY	1	
21	38915-90J00	.HOLDER, RELAY	1	
22	09407-14407	.CLAMP (L:145)	12	
23	12700-89L21	.CAMSHAFT ASSY	1	
24	33930-89L60	UNIT, ENGINE CONTROL	1	

DF20A P40

FIG.575A




FIG.575A (1-K-8) OPT:DRAG LINK (DF9.9B)(DF15A)(DF20A)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41161-94400	SEAL, STEERING CABLE	1	
2	67701-99J02	LINK ASSY, DRAG	1	
3	67721-93E10	.SPACER	1	
4	67725-96J00	.BOLT	1	
5	67726-99E00	.NUT	2	
6	67728-99E00	.WASHER	4	

DF9.9B P01
DF15A P01
DF20A P01
DF20A P40



FIG.583A




FIG.583A (1-K-9) OPT:FUEL TANK (DF9.9B)(DF9.9BR)(DF9.9BT)(DF9.9BTH)(DF15A)(DF15AR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65700-87J16	HOSE, FUEL	1	
6	65750-87J11	.SOCKET, FUEL HOSE	1	
7	65750-95500	.SOCKET, FUEL HOSE	1	
8	65770-90J12	.PUMP, SQUEEZE	1	
9	65781-98500	.CLIP	4	

DF9.9B P01
DF9.9BR P01
DF9.9BT P01
DF9.9BTH P01
DF15A P01
DF15AR P01

FIG.583B




FIG.583B (1-K-10) OPT:FUEL TANK (DF15AT)(DF20A)(DF20AR)(DF20AT)(DF20ATH)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	65000-94L10	TANK ASSY, FUEL (25L)	1	
2	65520-99100	.CAP ASSY, FUEL TANK	1	
3	65561-95D00	.GASKET, TANK CAP	1	
4	65740-95D01	.PLUG, FUEL CONNECTOR	1	
5	65700-87J16	HOSE, FUEL	1	
6	65750-87J11	.SOCKET, FUEL HOSE	1	
7	65750-95500	.SOCKET, FUEL HOSE	1	
8	65770-90J12	.PUMP, SQUEEZE	1	
9	65781-98500	.CLIP	4	

DF15AT P01
DF20A P01
DF20A P40
DF20AR P01
DF20AT P01
DF20ATH P01

DF20A_P01_019_600A
OPT:MULTI FUNCTION GAUGE



REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	34000-96L43	KIT, SINGLE GAUGE MECH	1	
2	34011-96L13	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L30	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36001-88L00	SET, WIRE	1	
10	36662-88L10	.WIRE, 2 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36664-88L00	.CONNECTOR, BRANCH	1	
13	36665-88L00	.UNIT, RESISTOR FEMALE	1	
14	36665-88L10	.UNIT, RESISTOR MALE	1	
15	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
16	36662-88L10	WIRE, 2 EXTENSION	1	
17	36662-88L20	WIRE, 6 EXTENSION	1	
18	36662-88L30	WIRE, 15 EXTENSION	1	
19	36662-88L00	WIRE, 25 EXTENSION	1	
20	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
21	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
22	36665-88L00	UNIT, RESISTOR FEMALE	1	
23	36665-88L10	UNIT, RESISTOR MALE	1	
24	36664-88L00	CONNECTOR, BRANCH	1	
25	36660-89L02	SET, ENG TO INTERFACE WIRE	1	
26	29404-93J10	.CLAMP	1	
27	09407-14407	.CLAMP (L:145)	4	

FIG.600A




FIG.600A (1-K-12) OPT:MULTI FUNCTION GAUGE (DF9.9BR)(DF9.9BT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	36667-96L20	WIRE, GAUGE EXT	1	
29	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
30	36990-87D00	TERMINAL / SLEEVE SET	1	

DF9.9BR P01
DF9.9BT P01

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	34000-96L43	KIT, SINGLE GAUGE MECH	1	
2	34011-96L13	.SET, MULTI GAUGE	1	
3	34112-96L00	..NUT, GAUGE	1	
4	34193-96L00	..BEZEL, GAUGE	1	
5	34211-96L00	..COVER, GAUGE	1	
6	34825-96L00	..PACKING, GAUGE	1	
7	36661-96L30	.ADAPTER, GAUGE	1	
8	36615-96300	..TERMINAL	5	
9	36001-88L00	SET, WIRE	1	
10	36662-88L10	.WIRE, 2 EXTENSION	1	
11	36663-88L00	.HARNESS ASSY, NETWORK POWER	1	
12	36664-88L00	.CONNECTOR, BRANCH	1	
13	36665-88L00	.UNIT, RESISTOR FEMALE	1	
14	36665-88L10	.UNIT, RESISTOR MALE	1	
15	34190-88L00	SENSOR ASSY, PAD WHEEL	1	
16	36662-88L10	WIRE, 2 EXTENSION	1	
17	36662-88L20	WIRE, 6 EXTENSION	1	
18	36662-88L30	WIRE, 15 EXTENSION	1	
19	36662-88L00	WIRE, 25 EXTENSION	1	
20	39950-88L02	MODULE ASSY, GPS RECEIVER	1	
21	36663-88L00	HARNESS ASSY, NETWORK POWER	1	
22	36665-88L00	UNIT, RESISTOR FEMALE	1	
23	36665-88L10	UNIT, RESISTOR MALE	1	
24	36664-88L00	CONNECTOR, BRANCH	1	
25	36660-89L02	SET, ENG TO INTERFACE WIRE	1	
26	29404-93J10	.CLAMP	1	
27	09407-14407	.CLAMP (L:145)	4	

FIG.600B





FIG.600B (1-K-14) OPT:MULTI FUNCTION GAUGE (DF15AR)(DF15AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	36667-96L20	WIRE, GAUGE EXT	1	
29	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
30	36990-87D00	TERMINAL / SLEEVE SET	1	

DF15AR P01
DF15AT P01

DF20A_P01_019_600C
OPT:MULTI FUNCTION GAUGE



DF20A_P01_019

FIG.600C




FIG.600C (1-L-2) OPT:MULTI FUNCTION GAUGE (DF20AR)(DF20AT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	36667-96L20	WIRE, GAUGE EXT	1	
29	36682-92E00	WIRE, TRIM METER EXT (L:6500)	1	
30	36990-87D00	TERMINAL / SLEEVE SET	1	

DF20AR P01
DF20AT P01

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		121B-8		334C-12	
		12915-94J50		121A-9	334D-12
		121B-9		146A-1	
		12921-89L00		121A-10	146B-1
		121B-10		13710-89L00	126C-6
11110-89L01	111A-1	121A-11		13811-89L10	126A-5
11115-93E00-001	111A-19	121B-11		126B-5	
11141-89L00	111A-2	121A-12		126C-5	
11162-89L00	111A-14	121B-12		13820-89L00	126B-9
11170-89L00	111A-13	12933-71C00		13820-89L10	126A-9
11174-89L00	111A-16	121B-13		13831-89L00	126A-11
11261-93J00	111A-5	126A-1		126B-11	
11291-91B50	113A-6	126B-1		126C-11	
11300-89L03	113A-1	126C-1		13832-89L00	126C-7
11382-93E00	111A-10	126A-8		15100-89L10	146B-24
12100-89L30-050	116A-10	126B-8		15100-89L20	146A-24
12111-89L10-0B0	116A-1	126C-10		15191-89L00	146A-25
12140-89L10	116A-2	126A-2		146B-25	
12140-89L10-050	116A-11	126B-2		15192-89L01	146A-26
12151-89L00	116A-3	126C-2		146B-26	
12160-89L11	116A-5	13279-13G10		15192-89L10	146A-27
12163-89L02	116A-6	163B-6		146B-27	
12220-89L00	116A-7	13295-29900		163B-7	
12341-89L10	116A-8	163A-7		15192-89L21	146A-28
12625-89L10	120A-11	163B-7		146B-28	
12631-89L10	120A-1	13300-89L01		146A-29	
12635-89L00	120A-2	13300-89L11		146B-29	
12636-89L00	120A-3	13326-89L00		15192-89L40	146A-30
12637-89L00	120A-4	163B-4		146B-30	
12638-89L00	120A-5	13365-89L00		146A-31	
12700-89L01	121A-1	163A-8		146B-31	
12700-89L21	121B-1	163B-8		15194-89L00	146A-32
	561A-23	163A-2		146B-32	
	561B-23	13421-89L00		15200-89L10	146A-2
	561C-23	163B-5		146B-2	
	561D-23	13425-33G00		163A-3	163A-10
12741-89L00	120A-6	163B-3		163B-10	
12744-89L00	120A-17	13513-89L10		166A-1	146A-3
12761-93EL0	120A-16	513A-2		146B-3	
12840-93E01	121A-3	13606-47A00		146B-4	146A-4
	121B-3	163B-9		146B-4	
12842-49201	121A-4	13640-32G20		334A-1	146A-33
	121B-4	334B-1		334B-1	146B-33
12843-27A00	121A-5	334C-1		334C-1	146A-35
	121B-5	334D-1		334D-1	146B-35
12861-89L00	121A-6	13650-52G00		334A-12	146A-36
	121B-6	334B-12		334B-12	146B-36
12891-94J00	121A-7	334C-11		334C-11	146A-37
	121B-7	334D-11		334D-11	146B-37
12911-94J01	121A-8	13655-89L10		334A-13	146A-5
		334B-13		334B-13	146B-5

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
15629-89L00	146A-8	160B-9		513A-6	
	146B-8	160A-18		166A-6	
15676-89L00	146A-44	160B-18		513A-7	
	146B-44	17631-99J20		166A-7	
15681-89L00	144A-1	160A-10		166A-7	
15685-89L00	146A-38	160B-10		513A-8	
	146B-38	17632-99J30		160A-11	
15690-89L02	146A-6	160B-11			
	146B-6	17670-91J01		162A-1	
15710-50M00	144A-2	17680-89L00		162A-2	
15716-65D10	144A-3	17685-89L00		162A-7	
15734-89L00	144A-4	17712-89L02		162A-5	
15735-89L00	144A-5	17712-89L11		162A-4	
15751-89L00	144A-6	17913-93J00		405A-1	
15770-89L02	146A-7			405B-1	
	146B-7	17914-93J00		405A-2	
15790-89L00	146A-9			405B-2	
	146B-9	17917-87L00		410A-22	
16400-89L00	175A-1			410B-22	
16431-89L00	175A-12			410C-22	
16440-11D00	113A-5			410D-23	
16510-45H10	175A-2	18100-94JN0		410E-23	
16512-99J00	175A-3			167A-1	
16515-89L10	401A-6	18121-94JL0		167B-1	
16520-99J00	401A-17			167A-2	
16910-89L01	175A-9			167B-2	
16930-89L02	175A-10	18130-93E01		167B-3	
17400-99J02	160A-19			167B-4	
17400-99J12	160B-19	18132-89L00		167A-5	
17411-94J00	160A-1			167B-5	
	160B-1	18142-93E00		167A-4	
17413-94J00	160A-2			167B-4	
17413-94J10	160B-2	18210-95L00		167A-6	
17461-939M0	160A-3			167B-6	
	160B-3	18280-93E00		167A-7	
17471-99J00	160A-4			167B-7	
17471-99J10	160B-4	18290-94J01		167A-10	
17472-99J00	160A-5			167B-10	
	160B-5	18498-87JB1		146A-10	
17473-94J00	160A-6			146B-10	
	160B-6	18590-58M00		334A-14	
17561-99J00	160A-7-1			334B-14	
	160B-7-1			334C-13	
17561-99J10	160A-7-2			334D-13	
	160B-7-2	19120-99J11		166A-2	
17561-99J20	160A-7-3			513A-3	
	160B-7-3	19122-99J00		166A-3	
17563-94J00	160A-8			513A-4	
	160B-8	19131-89L00		166A-4	
17564-99J00	160A-9			513A-5	
		19148-89L10		166A-5	

20000

21110-89L10	206B-1
	513A-9
21111-89L01	206A-1
21120-89L00	206A-2
	206B-2
21122-89L00	206A-3
	206B-3
21131-94J00-Y5S	444A-36-2
21131-94J00-YAY	444A-36-1
	444B-36
21210-89L01	206A-4
	206B-4
22511-99011	336A-1
	336B-1
	336C-1
	336D-1-1
	336D-1-2
	336E-1-1
	336E-1-2
23111-89L00	206A-5-1
	206B-5-1
23111-89L10	206A-5-2
	206B-5-2
23115-89L00	206A-6
23115-89L10	206B-6
	513A-10
23211-89L00	206A-7
	206B-7
23311-95J00	210A-1
25111-99J01	210A-2-1
25111-99J10	210A-2-2
25211-99JL0	210A-5
25215-99J00	210A-6
25311-99J00	210A-3
29103-93J00	327B-6
29141-93J00	160A-13
	160B-13
	210A-7
	335A-12
	335B-12

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
29162-93J10	335C-12	31311-94J00	340A-9	32815-89L10	561D-7
	335A-18	31313-86030	301A-11		553A-4
	335B-18	31320-89L00	301A-12		334C-15
	335C-18	31340-89L00	301A-10		513A-36
29404-93J10	335D-22	31341-89L00	301A-13	32890-89L03	310A-5
	600A-26	31343-63J00	301A-14		310B-5
	600B-26	31344-63J00	301A-15		310C-5
	600C-26	31912-89L00	301A-16		310D-5
29440-93J00	336A-21	31918-92J01	301A-17	32916-89L00	310E-5
	336B-21	32000-89L01	553A-1		310F-5
	336C-21	32102-89L00	303B-4		310G-5
	336D-11		561A-4		322A-11
	336E-11		561B-4		322B-7
			561C-4		322C-7
			561D-4		322D-11
			303A-4		303A-9
30000		32102-89L10	303B-1-1	33220-84M10	303B-9
		32120-89L00	561A-5-1		310A-14
			561B-5-1		310B-14
			561C-5-1		310C-14
31000-89L20	561A-1		561D-5-1		310D-14
	561B-1	32120-89L10	303A-1		310E-14
	561C-1	32120-89L20	303B-1-2		310F-14
	561D-1		561A-5-2		310G-14
31100-89L00	301A-1		561B-5-2	33500-07H00	310A-12
	561A-3		561C-5-2		310B-12
	561B-3	32800-89L01	561D-5-2		310C-12
	561C-3		310A-1		310D-12
31101-89L10	561D-3		310B-1	33634-96J00	310E-12
	561A-2		310C-1		310F-12
	561B-2		310D-1		310G-12
	561C-2		310E-1		322A-13
31123-89J10	561D-2		310F-1		322B-8
	338A-7		310G-1		322C-8
	340A-5		561A-6		322D-13
	340A-4		561B-6	33799-97E00	340A-6
31135-94900	340A-7		561C-6		561A-12
31136-94J00	340A-3		561D-6		561B-12
31150-98L00	301A-2	32800-94J11	553A-3		561C-12
31170-89L00	301A-3	32801-89L01	553A-2	33810-89L10	561D-12
31173-98L00	301A-4	32815-89L00	310A-2		322A-1
31174-89LA1	340A-2		310B-2		322B-1
31191-63J00	301A-5		310C-2		322C-1
31192-92J00	301A-8		310D-2		322D-1
31192-94J01	338A-11		310E-2		561A-13
31193-94J00	338A-10		310F-2		561B-13
31220-89L00	301A-6		310G-2		561C-13
31261-75F10	301A-9		561A-7	33833-91J00	561D-13
31281-94J01	338A-12		561B-7		444A-21
31311-63J00	301A-7		561C-7		444B-21

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
33925-89L00	310A-17	34300-93J13	501A-15-2		501A-9
	310B-17	34310-92E00	501A-16		600A-8
	310C-17	34360-92E00	501A-17		600B-8
	310D-17	34500-93J02	501A-1-1		600C-8
	310E-17	34500-93J13	501A-1-2	36616-89L10	322C-17
	310F-17	34600-93J02	501A-3-1		322D-22
	310G-17	34600-93J13	501A-3-2		334A-10
	310C-16-1	34825-96L00	600A-6		334B-10
33930-89L00	310D-16		600B-6	36616-89L20	334D-9
	561B-24		600C-6		334C-9
	310C-16-2	34923-96L00	322B-19		513A-37
	310E-16-1		322C-21		322A-14
33930-89L10	310G-16	36001-88L00	600A-9	36617-89L01	322B-9
33930-89L20	561C-24		600B-9		322A-12
	310E-16-2		600C-9		322D-12
	310A-16-1	36360-99J10	334A-3		561A-14
33930-89L30	310B-16		334B-3		561B-14
	561A-24		334C-3		561C-14
	310A-16-2		334D-3		561D-14
	310F-16-1	36367-89L00-Y5S	334A-4-2		322C-10
33930-89L60	561D-24		334C-4-2	36617-89L50	322C-9
	310F-16-2		334D-4-2		322D-14
	600A-1	36367-89L00-YAY	334A-4-1		322A-15
	600B-1		334B-4		322B-10
34000-96L43	600C-1		334C-4-1	36617-91J00	322D-15
	600A-2		334D-4-1		322A-8
	600B-2	36610-89LB0	322A-5-1		322B-5
	600C-2		561A-19-1		322C-5
34100-93J22	501A-5-1		561B-19-1	36620-89L00	322D-8
	501A-5-2		561C-19-1		513A-12
	501A-5-3		561D-19-1		450A-52
	501A-5-4	36610-89LC0	322A-5-3		450B-54
34100-93J53	600A-3	36610-89LD0	322B-2-1	36620-93J10	546A-1
	600B-3		513A-11-1		322B-18-1
	600C-3		322D-5-1		322C-20-1
	501A-12	36610-89LE0	322C-2-1		322B-18-2
34190-87D00	600A-15	36610-89LF0	322A-5-2	36620-93J40	322C-20-2
	600B-15	36610-89LG0	561A-19-2		36628-92E00
	600C-15		561B-19-2		450A-2
	501A-10		561C-19-2		450B-3
34190-95500	501A-7		561D-19-2	36634-93910	508A-2
	600A-4	36610-89LH0	322B-2-2		553A-13
	600B-4		513A-11-2		450B-2
	600C-4	36610-89LJ0	322D-5-2		600A-25
34200-93J22	501A-13-1	36610-89LK0	322C-2-2	36660-89L02	600B-25
	501A-13-2		303A-12		600C-25
	600A-5	36615-96300	322A-9		600A-7
	600B-5		322D-9		600C-7
34211-96L00	600C-5		450A-54	36662-88L00	600A-19
	501A-15-1		450B-56		600B-19
34300-93J02					

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
36662-88L10	600C-19		600A-30		530A-3-8
	600A-10		600B-30		530A-19-8
	600A-16		600C-30	37141-99E80	450A-4-9
	600B-10	37100-96J00	530A-1		450B-5-9
	600B-16	37100-96J25	530A-17		508A-4-9
36662-88L20	600C-10	37110-93J01	530A-2		530A-3-9
	600C-16		530A-18		530A-19-9
	600A-17	37110-93J11	450B-4	37141-99E90	450A-4-10
	600B-17	37110-94J02	450A-3		450B-5-10
	600C-17		508A-3		508A-4-10
36662-88L30	600A-18	37139-99E00	530A-6		530A-3-10
	600B-18	37139-99E40	530A-22		530A-19-10
	600C-18	37141-99E00	450A-4-1	37141-99EA0	450A-4-11
36663-88L00	600A-11		450B-5-1		450B-5-11
	600A-21		508A-4-1		508A-4-11
	600B-11		530A-3-1		530A-3-11
36664-88L00	600B-21	37141-99E10	530A-19-1	37141-99EB0	530A-19-11
	600C-11		450A-4-2		450A-4-12
	600C-21		450B-5-2		450B-5-12
	600A-12		508A-4-2		508A-4-12
	600A-24		530A-3-2		530A-3-12
36665-88L00	600B-12	37141-99E20	530A-19-2		530A-19-12
	600B-24		450A-4-3	37143-99E00	450A-5
	600C-12		450B-5-3		450B-6
	600C-24		508A-4-3		508A-5
	600A-13		530A-3-3		530A-4
36665-88L10	600A-22	37141-99E30	530A-19-3	37149-93J00	530A-20
	600B-13		450A-4-4		450A-6
	600B-22		450B-5-4		450B-7
	600C-13		508A-4-4		508A-6
	600C-22		530A-3-4		530A-5
36667-96L20	600A-14	37141-99E40	530A-19-4	37161-89L02	530A-21
	600A-23		450A-4-5		334A-5
	600B-14		450B-5-5		334B-5
	600B-23		508A-4-5		334D-5
	600C-14		530A-3-5		561A-15
36682-92E00	600C-23	37141-99E50	530A-19-5	37163-89L00	561B-15
	600A-28		450A-4-6		561C-15
	600B-28		450B-5-6		561D-15
36740-94J00	600C-28		508A-4-6		334A-6
	600A-29		530A-3-6		334B-6
	600B-29		530A-19-6		334C-5
36894-87D00	600C-29	37141-99E60	450A-4-7	37210-93J00	513A-15
	553A-10		450B-5-7		530A-15
	335D-9		508A-4-7	37212-93J00	530A-16
36895-87D01	335D-10		530A-3-7	37721-88L00	545A-11
	335D-11		530A-19-7		545B-11
	36990-87D00	37141-99E70	450A-4-8		545C-11
	546A-3		450B-5-8	37721-89L00	334A-7
	553A-17		508A-4-8		334B-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	334C-6	37859-90J00	450A-10	41111-89L00-Y5S	335B-1-2
	334D-6		450B-51		335C-1-2
37721-93J91	450B-8		508A-10	41111-89L00-YAY	335A-1
37725-89L01	334A-11	37864-94J10	450A-11		335B-1-1
	334B-11		508A-11		335C-1-1
	334C-10	38100-89LA3	338A-14	41111-89LA0-Y5S	335D-1-2
	334D-10		340A-1	41111-89LA0-YAY	335D-1-1
37726-89L00	334A-8	38410-93J21	327A-1	41121-89L00-Y5S	335B-2-2
	334B-8		327B-1		335C-2-2
	334C-7	38415-89L00	327A-2	41121-89L00-YAY	335A-2
	334D-7		327B-2		335B-2-1
37801-98300	553A-11	38500-93J00	450A-12		335C-2-1
37803-93J05	530A-9		508A-12	41121-89LA0-Y5S	335D-2-2
37820-89L00	334A-2	38500-93J90	450B-13	41121-89LA0-YAY	335D-2-1
	334B-2		530A-7		335C-7
	334C-2		530A-27	41130-89L00	513A-16
	334D-2	38860-76F01	310A-18	41130-90L00	335A-7
37820-93J04	450A-7		310B-18		335B-7
	450B-9		310C-18	41130-94JA1	335D-7
	508A-7		310D-18	41135-93J11	335D-8
37820-93J10	530A-10		310E-18	41161-94400	442A-1
	530A-23		310F-18		575A-1
37823-92E01	450A-8		310G-18	41210-89LA0	335D-28
	450B-10		561A-20	41210-99JL1	335A-25
	508A-8		561B-20		335B-25
	530A-11		561C-20		335C-25
	530A-24	38915-90J00	561D-20	41211-94L00	335D-4
37823-97J00	444A-33		310A-19	41211-99JL0	335A-3
	444B-33		310B-19		335B-3
37825-99E10	530A-13		310C-19		335C-3
37826-92J00	450A-9		310D-19	41212-91J00	335A-4
	450B-11		310E-19		335B-4
	508A-9		310F-19		335C-4
37826-92J10	530A-12		310G-19		335D-5
	530A-25		561A-21	41213-94J01	335A-5
37826-97J01	444A-34		561B-21		335B-5
	444B-34		561C-21		335C-5
37830-89L10	444A-32		561D-21		335D-6
	444B-32	39600-89L00	553A-9	41221-94JA0	335D-14
37835-91J00-Y5S	444A-35-2	39601-95D00	553A-12	41222-94JA0	335D-15
37835-91J00-YAY	444A-35-1	39602-93900	553A-14	41225-89L00	336A-9
	444B-35	39950-88L02	600A-20		336B-9
37850-88L00	544A-4		600B-20		336C-9
	544B-4		600C-20	41226-94JA0	335D-16
	544C-4			43111-89L00-Y5S	336A-2-2
37850-90J06	450B-12				336B-2-2
37850-94JA3	327B-3				336C-2-2
37850-99E05	327A-3	40000		43111-89L00-YAY	336A-2-1
37851-89L00	327B-10				336B-2-1
37852-94JA0	327B-4				336C-2-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
43111-89L11-Y5S	336A-2-4 336B-2-4 336C-2-4	43517-89L00	336B-33 336E-20 336A-34	45261-89L00	336C-15 335A-13 335B-13
43111-89L11-YAY	336A-2-3 336B-2-3 336C-2-3		336B-34 336E-21 336D-3	45269-89L00	335C-13 335A-23 335B-23
43111-89LA0-Y5S	336D-2-4 336E-2-4 336D-2-3	43711-94JA0	336E-3 336A-3 336B-3	45420-89L01	335C-23 335A-19 335B-19
43111-89LA0-YAY	336E-2-3 336D-2-2 336E-2-2	43711-99J00	336C-3 336A-4-2 336B-4-2		335C-19 335D-17 335A-20
43111-89LB0-Y5S	336D-2-1 336E-2-1 405A-4	43750-99J60-Y5S	336C-4-2 336D-4-2 336E-4-2	45421-94JA0	335B-20 335B-20 335C-20
43111-89LB0-YAY	405B-4 336A-7 336B-7	43750-99J60-YAY	336C-4-1 336D-4-1 336E-4-1	45425-94J01	336A-24-1 336B-24-1 336C-24-1
43112-94L01	336C-7 336C-7 336D-7		336A-4-1 336B-4-1 336C-4-1	45710-89L00	336B-24-2 336C-24-2 336D-24-2
43211-87JL0	336E-7 336A-27 336B-27		336A-4-4 336B-4-4 336C-4-4	45710-89L10	336A-25 336B-25 336C-25
43411-89L00	336E-14 336A-19 336B-19	43750-99J70-Y5S	336D-4-4 336E-4-4 336A-4-3	45722-94J11	338A-1 338A-16 338A-17
43411-89LA0	336C-19 336D-9 336E-9	43750-99J70-YAY	336B-4-3 336C-4-3 336D-4-3	48000-89LA4	338A-18 338A-5 338A-4
43411-939L0	336A-20 336B-20 336C-20		336E-4-3 336C-27 336D-14	48121-94JA0	338A-8 338A-13 338A-6
43412-93900	336D-10 336E-10 336A-28		513A-17 336C-31 336D-18	48321-97E01	338A-17 338A-18 338A-5
43415-89L01	336B-28 336E-15 336A-29	43755-99J00	336C-10 336A-11 336B-11	48510-94600	338A-18 338A-5 338A-4
43420-89L00	336B-29 336E-16 336A-30	43759-89L00	336C-10 336A-11 336B-11	48553-88L00	338A-8 338A-13 338A-6
43425-89L00	336B-30 336E-17 336A-31	45212-89L00	336C-11 336B-12 336C-12	48572-94J00	338A-9 338A-15 338A-3
43512-89L00	336B-31 336E-18 336A-32	45231-89L00	336C-12 336A-14 336B-14	48664-87D00	338A-2 338A-15 338A-3
43515-88L00	336B-32 336E-19 336A-33	45241-89L00	336C-12 336A-14 336B-14	48681-87J11	338A-2 338A-15 338A-3
43516-89J00		45247-99J00	336C-14 336A-15 336B-15	48864-89LA0	338A-2 338A-15 338A-3

50000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
52110-89L30-Y5S	405A-3-4 405A-3-3 405B-3-2		336D-20-1 336E-25-1 338A-19-1	57100-90L30	220B-23 220A-1-2 220B-1-2
52110-89L30-YAY	405A-6 405B-6 405B-6		407A-6 407B-6 407C-6	57100-90L40	220A-1-1 220B-1-1 220A-1-3
52113-89L00	405A-17-2 405B-17 401A-7		407D-6 407E-6 407F-6	57311-99J10	220B-1-3 220A-8 220B-8
52131-89L00-Y5S	401A-8 401A-10 401A-9	55321-87J11	407G-6 335D-20-2 336D-20-2	57510-99J11	220A-9 220B-9 220A-10
52131-89L00-YAY	401A-11 401A-12 410A-17		336E-25-2 338A-19-2 407A-23	57521-99J10	220B-10 220B-10 220A-14
54112-99J01	410B-17 410C-17 410D-17		407B-23 407C-24 407D-24	57610-99JL0	220B-14 220A-15 220B-15
54113-99J00	410E-17 410A-18 410B-18		407E-24 407F-24 407G-24	57621-99J11	220B-19 220B-19 220B-19
54125-99J00	410C-18 410D-18 410E-18	55331-99J10	407A-21 407B-21 407C-21	57632-94J00	407A-17 407B-17 407C-17
54127-89L00	405A-11 405B-11 405A-12		407D-21 407E-21 407F-21		407D-17 407E-17 407F-17
54130-89L00	405B-12 405A-13-2 405A-13-1		407G-21 407A-22 407B-22		407G-17 57632-97L00 220A-20
54137-89L00	405B-15 405A-14-2 405A-14-1	55332-99J10	407C-22 407D-22 407E-22	57633-93901	220B-20 407C-23 407D-23
54144-89L11	405B-14 407A-1-2 407C-1-2		407F-22 407G-22 407A-10-2		407E-23 407F-23 407G-23
54145-89L01	407D-1-2 407E-1-2 407A-1-1	56120-99J41-Y5S	407D-22 407E-10-2 407G-10-2	58100-89L00-019	407A-15-1 407B-15-1 407A-15-2
54151-99J00	407B-1 407C-1-1 407D-1-1		407A-10-1 407B-10 407C-10-1	58100-89L20-019	407B-15-2 407A-15-5 407B-15-5
54167-99J01	407E-1-1 407F-1 407G-1-1	56120-99J41-YAY	407D-10-1 407E-10-1 407F-10	58100-89L50-019	407A-15-3 407B-15-3 407A-15-4
54211-99J01-Y5S	111A-7 335D-20-1		407G-10-1 407A-15-6 407B-15-6	58100-89L70-019	407A-15-7 407B-15-7 407A-15-8
54211-99J01-YAY		56130-99J30	220A-21 220B-21 220A-23	58100-90L41-019	407A-15-8 407B-15-8 407G-15-1
54213-93901		56132-99J10		58100-90L60-019	
54221-99J01-Y5S				58100-90L50-019	
54221-99J01-YAY				58100-90L60-019	
55100-99J40-Y5S				58100-90L70-019	
55100-99J40-YAY				58100-90L80-019	
55321-87J01				58100-90L90-019	

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
58100-94JB1-019	407C-15	61134-89L00	513A-21	61435-89L30-YAY	420E-11-1
	407D-15		410A-5		420F-11
	407E-15		410B-5		420G-11-1
	407F-15		410C-5		420A-8-2
	407G-15-2		410D-5		420B-8-2
58120-89L00	407A-16	61151-91J11	410E-5	61443-97L00-Y5S	420C-8-2
58120-94JA1	407B-16		146A-43		420D-8-2
	407C-16		146B-43		420E-8-2
	407D-16		410A-14		420G-8-2
	407E-16		410B-14		420A-8-1
	407F-16	410C-14	420B-8-1		
59178-97J00	407G-16	61155-95J00	410D-14	61443-97L00-YAY	420C-8-1
	407A-8		410E-14		420D-8-1
	407B-8		405A-5		420E-8-1
	407C-8		405B-5		420F-8
	407D-8		420A-1-2		420G-8-1
	407E-8	61400-89L40-Y5S	420B-1-2	61446-89L10-Y5S	420A-12-2
	407F-8		420C-1-2		420B-12-2
	407G-8		420D-1-2		420C-12-2
			420E-1-2		420D-12-2
	59262-94J00		175A-13		420G-1-2
59315-94J00	335A-14	61400-89L40-YAY	420A-1-1	61446-89L10-YAY	420G-12-2
	335B-14		420B-1-1		420A-12-1
59441-94J00	335C-14		420C-1-1		420B-12-1
	220A-17		420D-1-1		420C-12-1
59441-99J00	220B-17		420E-1-1		420D-12-1
59800-89L10	220A-18	61412-89L00	420F-1	61447-89L00-YAY	420E-12-1
	220B-18		420G-1-1		420F-12
	420A-15		410A-9		420G-12-1
	420B-15		410B-9		420B-17-2
	420C-15		410C-9		420D-17-2
	420D-15	61433-89L01	410D-9	61453-97L00-Y5S	420G-17-2
	420E-15		410E-9		420B-17-1
	420F-15		420A-2		420D-17-1
	420G-15		420B-2		420G-17-1
			420C-2		420A-9-2
60000		61435-89L10-Y5S	420D-2	61453-97L00-YAY	420B-9-2
			420E-2		420C-9-2
			420F-2		420D-9-2
			420G-2		420E-9-2
			420A-11-2		420G-9-2
61112-89L10	410A-4	61435-89L10-YAY	420B-11-2	61458-89L30	420A-9-1
	410B-4		420A-11-1		420B-9-1
	410C-4		420B-11-1		420C-9-1
	410D-4		420C-11-2		420D-9-1
	410E-4		420D-11-2		420E-9-1
	61124-89L40	410A-13	61435-89L20-YAY	420C-11-1	61458-89L30
	410B-13	420D-11-1		420G-9-1	
	410E-13	420E-11-2		420A-13	
	410C-13	420G-11-2		420B-13	
	410D-13				

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420C-13	61810-89L20-Y5S	410C-1-1	63210-89L11	444B-25
	420D-13		410A-1-2		444A-6
	420E-13		410C-1-2		444B-6
	420F-13		410D-1-1		444A-31
	420G-13		410E-1-1		444B-31
61471-89L00	420A-14	61810-89L30-QGF	410D-1-2	63220-89L00	444A-7
	420B-14		410E-1-2		444B-7
	420C-14		410A-2-1		444A-9
	420D-14		410B-2		444B-9
	420E-14		410C-2-1		444A-8
61472-97J00	420F-14	61820-89L00-QGF	410E-2-1	63225-93200	444B-8
	420G-14		410A-2-2		444A-10
	167A-13		410C-2-2		444B-10
	167B-13		410E-2-2		444A-11
61494-89L10	126A-12	61820-89L10-QGF	410D-2-1	63244-94J00	444B-11
	126B-12		410D-2-2		444A-12
	126C-13		410A-15		444B-12
	410A-10		410B-15		444A-14
	410B-10		410C-15		444B-14
61610-90L00	410C-10	61827-89L00	410D-15	63610-89L10	444A-15
	410D-10		410E-15		444B-15
	410E-10		410A-6-1		65000-89L10
	410A-11		410B-6		432A-1
	410B-11		410C-6-1		65000-94L10
61616-93EL0	410C-11	61831-89L00-QGF	410D-6-1	65520-99100	583A-1
	410D-11		410E-6-1		583B-1
	410E-11		410A-6-2		583A-2
	420A-5		410C-6-2		583B-2
	420B-5		410D-6-2		583B-3
61619-89L00	420C-5	63111-89L01-Y5S	410E-6-2	65561-95D00	432A-3
	420D-5		444A-1-2		583A-5
	420E-5		444A-1-1		583B-5
	420F-5		444B-1		65700-89L30
	420G-5		444A-22		432A-8
61622-90L00	444B-22	63114-99J01	444B-22	65720-986L0	432A-13
	420A-4				432A-7
	420B-4		63115-99J00		583A-4
	420C-4		444A-3		583B-4
	420D-4		444B-3		583A-6
61631-99J00	420E-4	63115-99J10	444A-2	65750-87J11	432A-9
	420F-4		444B-2		583A-6
	420G-4		444A-4		583B-6
	420A-6		444B-4		432A-10
	420B-6		444A-5-2		583A-7
61810-89L20-QGF	420C-6	63121-99J00-Y5S	444A-5-1	65770-89L00	583B-7
	420D-6		444B-5		432A-11
	420E-6		444A-23		65770-90J12
	420F-6		444B-23		583A-8
	420G-6		444A-24-2		583B-8
	410A-1-1	63131-99J11-Y5S	444A-24-1	65781-98500	432A-12
	410B-1		444B-24		583A-9
			444A-25		583B-9
					65793-89L00
					444A-26

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
65831-95D00	444B-26		545B-16	67240-92E00	545A-17
65890-99100	432A-4		545C-16		545B-17
65892-95D00	432A-5	67227-92E00	545A-24		545C-17
67130-89L10	432A-6		545B-24	67241-88L00	545A-34
67130-89L20	513A-1-1		545C-24		545B-34
67140-95600	513A-1-2	67228-92E00	545A-18		545C-34
	515A-1		545B-18	67241-99E10	450A-20
	515B-1		545C-18		450B-21
67200-88L00	544A-1	67229-95600	450A-17		508A-20
	544B-1		450B-18	67243-92E00	545A-38
	544C-1		508A-17		545B-38
	545A-1	67230-88L00	545A-20		545C-38
	545B-1		545B-20	67243-95600	450A-21
	545C-1		545C-20		450B-22
67200-93J51	450B-1	67231-88L00	545A-32		508A-21
67200-94J20	450A-1		545B-32	67244-95600	450A-22
	508A-1		545C-32		450B-23
67211-88L00	544A-17	67232-88L00	545A-33		508A-22
	544B-17		545B-33	67245-92E00	545A-23
	544C-17		545C-33		545B-23
67212-88L00	544A-7	67232-95600	450A-18		545C-23
	544B-7		450B-19	67245-95600	450A-23
	544C-7		508A-18		450B-24
67212-95600	450A-13	67233-92E00	545A-26		508A-23
	450B-14		545B-26	67246-88L00	545A-36
	508A-13		545C-26		545B-36
67214-92E00	450A-14	67234-88L00	545A-22		545C-36
	508A-14		545B-22	67251-88L00	544A-20
67220-95630	450A-15		545C-22		544B-20
	450B-16	67235-92E00	545A-27		544C-20
	508A-15		545B-27	67251-99E20	450A-24
67221-92E00	545A-8		545C-27		450B-25
	545B-8	67236-92E00	545A-12		508A-24
	545C-8		545B-12	67252-88L00	545A-39
67222-92E00	545A-2		545C-12		545B-39
	545B-2	67237-92E01	545A-28		545C-39
	545C-2		545B-28	67252-95600	450A-25
	545A-3		545C-28		450B-26
67223-92E00	545B-3	67238-87D00	450A-19		508A-25
	545C-3		450B-20	67253-88L00	545A-40
67223-99E10	450A-16		508A-19		545B-40
	450B-17	67238-88L00	545A-31		545C-40
	508A-16		545B-31	67253-92E00	544A-13
67224-92E00	545A-9		545C-31		544B-13
	545B-9	67239-92E00	545A-35		544C-13
	545C-9		545B-35	67253-95600	450A-26
67226-92E00	545A-15		545C-35		450B-27
	545B-15	67239-92E10	545A-41		508A-26
	545C-15		545B-41	67255-99E10	450A-27
67226-92E10	545A-16		545C-41		450B-28

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	508A-27		545B-47		545A-5
67256-95600	450A-28		545C-47		545B-5
	450B-29	67273-95600	545A-36		545C-5
	508A-28		450B-37	67294-95600	450A-41
67257-88L00	544A-9		508A-36		450B-40
	544B-9		544A-15		508A-41
	544C-9		544B-15		515A-2
67257-99E10	450A-29		544C-15		515B-2
	450B-30	67274-88L00	545A-42		545A-13
	508A-29		545B-42		545A-30
67258-99E00	450A-30		545C-42		545B-13
	450B-31	67275-95600	450A-37		545B-30
	508A-30		450B-38		545C-13
67259-87D00	450A-31		508A-37		545C-30
	450B-32		544A-14	67296-88L00	544A-5
	508A-31		544B-14		544B-5
67261-88L00	544A-3		544C-14		544C-5
	544B-3	67281-88L00	544A-10		450A-42
	544C-3		544B-10		450B-41
67261-88L10	544A-2		544C-10		508A-42
	544B-2	67282-94L00	450A-38		450B-15
	544C-2		450B-52	67296-92E20	545A-14
67261-99E10	450A-32		508A-38		545B-14
	450B-33	67284-94L00	450A-39		545C-14
	508A-32		450B-53	67296-92E30	545A-44
67264-88L00	544A-39		508A-39		545B-44
	544B-18	67286-92E00	545A-19		545C-44
	544C-18		545B-19	67296-92E60	544A-11
67264-88L10	544A-19		545C-19		544B-11
	544B-19	67287-92E00	545A-46		544C-11
	544C-19		545B-46	67296-94300	450A-43
67264-95600	450A-34		545C-46		450B-42
	450B-35	67288-92E00	545A-4		508A-43
	508A-34		545B-4	67296-94310	450A-33
67267-93J00	450A-35		545C-4		450B-34
	450B-36	67288-92E20	544A-6		508A-33
	508A-35		544B-6	67296-95600	450A-44
67269-92E00	545A-29		544C-6		450B-43
	545B-29	67288-92E60	544A-12		508A-44
	545C-29		544B-12	67296-95610	450A-45
67271-88L10	544A-16		544C-12		450B-44
	544B-16	67291-92E00	545A-7		508A-45
	544C-16		545B-7		545A-43
67272-88L00	545A-6		545C-7		545B-43
	545B-6	67291-92E10	545A-37		545C-43
	545C-6		545B-37	67296-95621	515A-3
67273-88L00	544A-25		545C-37		515B-3
	544B-25	67292-94300	450A-40		450A-46
	544C-25		450B-39		450B-45
	545A-47		508A-40		508A-46

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
67320-93J00	515A-4-1	69911-91J50	335A-24		561B-10
	515B-4-1		335B-24		561C-10
67320-93J10	515A-4-2		335C-24		561D-10
	515B-4-2		335D-27	01547-0630A	303A-2
67320-93J20	515A-4-3			01550-05127	303A-3
	515B-4-3				303B-3
67320-93J30	515A-4-4			01550-06127	322A-21
	515B-4-4				322B-16
67320-93J40	515A-4-5				322C-16
	515B-4-5				322D-21
67320-93J50	515A-4-6	77811-54GB0-0PG	420A-10		513A-34
	515B-4-6		420B-10	01550-0612C	163A-12
67320-93J60	515A-4-7		420C-10		166A-9
	515B-4-7		420D-10		175A-8
67320-93J70	515A-4-8		420E-10		206A-17
	515B-4-8		420F-10		206B-9
67320-93J80	515A-4-9		420G-10		206B-15
	515B-4-9		450A-47		322A-20
67340-89L10	206B-21		450B-46		322B-15
	513A-22		508A-47		322C-15
67345-89L10	206B-23				322D-20
	513A-38			01550-06167	303A-10
67467-89J01	166A-11				303B-10
	206B-18				310A-11
	513A-23				310B-11
67500-88L00	544A-21	99000-81158-50M	167A-8		310C-11
	544B-21		167B-8		310D-11
	544C-21	99011-89L70-055	420A-16		310E-11
67701-99J02	442A-2		420B-16		310F-11
	575A-2		420C-16		310G-11
67721-93E10	442A-3		420D-16		513A-35
	575A-3		420E-16		561A-8
67725-96J00	442A-4		420F-16		561B-8
	575A-4		420G-16		561C-8
67726-99E00	442A-5				561D-8
	575A-5			01550-0616C	146A-20
67728-99E00	442A-6				146B-20
	575A-6				166A-10
68110-89L01	420A-17				334A-9
	420B-18				334B-9
	420C-17	01547-06167	513A-33		334C-8
	420D-18		561A-17		334D-8
	420E-17		561B-17	01550-06207	310A-10
	420F-17		561C-17		310B-10
	420G-18		561D-17		310C-10
68111-88L00	544A-8	01547-0616C	206B-22		310D-10
	544B-8		322A-4		310E-10
	544C-8		322D-4		310F-10
69711-93E10	167A-12	01547-0625A	303B-2		310G-10
	167B-12		561A-10		553A-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	561A-9	02142-0616C	410A-16		450A-48
	561B-9		410B-16		450B-47
	561C-9		410C-16		508A-48
	561D-9		410D-16	09100-08311	335A-15
01550-0620C	111A-15		410E-16		335B-15
	146A-21	02142-06207	206A-19		335C-15
	146B-21		206B-17		335D-24
	162A-3	03112-0630B	501A-11	09103-06237	432A-14
	163A-13	03121-0516A	530A-26	09103-06267	120A-7
	163B-11	03122-05165	530A-14	09103-06281	111A-8
	167A-11	03142-04169	160A-12		335D-21
	167B-11		160B-12		336D-21
	175A-7	03542-05169	420A-3		336E-26
	334A-15		420B-3		338A-20
	334B-15		420C-3		407A-7
	334C-14		420D-3		407B-7
01550-0625C	334D-14		420E-3		407C-7
	120A-13		420F-3		407D-7
	146A-11		420G-3		407E-7
	146A-22	03542-06209	146A-23		407F-7
	146B-11		146B-23		407G-7
	146B-22	04211-09149	120A-12	09108-06141	160A-14
	206A-18	04211-11129	111A-12		160B-14
	206B-16		113A-4	09108-08286	336C-29
01550-0630C	167A-9	04221-05109	126A-4		336D-16
	167B-9		126B-4		513A-24
	310A-15		126C-4	09111-10067	336A-26
	310B-15	08110-60020	220A-2		336B-26
	310C-15		220B-2		336C-26
	310D-15	08110-60050	407A-11	09116-06196	310A-4
	310E-15		407B-11		310B-4
	310F-15		407C-11		310C-4
01550-06357	310G-15		407D-11		310D-4
	113A-2		407E-11		310E-4
	120A-14		407F-11		310F-4
01550-0650C	144A-9		407G-11		310G-4
01550-08207	113A-7	08316-10087	301A-20	09116-06225	336A-35
	301A-18	08322-0106A	303A-11		336B-35
	553A-5	08341-31039	120A-9		336C-32
01550-0820C	111A-9		120A-10		336D-19
01550-08307	301A-19		303A-7		336E-22
01560-08307	401A-15		303B-7		444A-27
01560-08757	113A-3	09100-06178	335A-9		444B-27
01580-08407	126A-3		335B-9		513A-25
	126B-3		335C-9	09116-06227	407A-14
	126C-3	09100-08232	336A-23		407B-14
02122-04127	120A-15		336B-23		407C-14
02122-0630A	175A-14		336C-23		407D-14
02142-06167	322C-18		336D-13		407E-14
	322D-23		336E-13		407F-14

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09116-06229	407G-14	09119-08L02	111A-3	09159-08L02	513A-26
	220A-24	09125-05042	545A-21		336A-36
	220B-24		545B-21		336B-36
09116-06234	206A-9		545C-21		336E-23
09116-06517	126A-7	09125-05046	327B-5	09159-22006	335A-8
	126B-7	09125-05135	544A-22		335B-8
	126C-9		544B-22		335C-8
	146A-12		544C-22		335D-13
	146B-12	09125-05145	444A-29		513A-27
	310A-3		444B-29	09160-05024	545A-45
	310B-3	09125-06063	335D-12		545B-45
	310C-3	09126-05003	450A-49		545C-45
	310D-3		450B-48	09160-05029	206B-11
	310E-3		508A-49		513A-28
	310F-3	09126-06006	545A-25		544A-23
	310G-3		545B-25		544B-23
	327A-4		545C-25		544C-23
09116-06522	327B-8	09126-06015	444A-17	09160-06046	166A-8
	410A-8		444B-17		206A-10
	410B-8	09136-05041	340A-8		206B-10
	410C-8		444A-18		513A-29
	410D-8		444B-18	09160-06055	166A-12
	410E-8	09140-05005	327B-7		206B-19
09116-06523	410A-3		544A-24		513A-30
	410B-3		544B-24	09160-06082	160A-15
	410C-3		544C-24		160B-15
	410D-3	09140-06020	450A-50		210A-8
	410E-3		450B-49		335A-10
09116-08128	335D-18		508A-50		335B-10
09116-08137	401A-13		545A-10		335C-10
09116-08150	338A-21		545B-10		336A-17
09116-08151	401A-3	09140-08023-XC0	545C-10		336B-17
	405A-7		335A-16		336C-17
	405A-18		335B-16	09160-06085	432A-15
	405B-7		335C-16	09160-06094	206A-11
	405B-18		335D-25	09160-06104	450A-51
	407A-5	09140-10031	401A-14		450B-50
	407B-5	09140-14008	303A-5		508A-51
	407C-5		303B-5	09160-06168	310A-20
	407D-5	09141-12005	407A-18		310B-20
	407E-5		407B-18		310C-20
	407F-5		407C-18		310D-20
	407G-5		407D-18		310E-20
	444A-16		407E-18		310F-20
	444B-16		407F-18		310G-20
09116-08154	405A-16		407G-18	09160-06171	120A-8
	405B-16	09148-06008	444A-13	09160-08081	335A-17
09116-08155	444A-28		444B-13		335B-17
	444B-28	09159-08059	336C-30		335C-17
09119-08L01	111A-4		336D-17		335D-23

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09160-08082	336A-22		220B-12-4	09160-25041	206A-14
	336B-22		220A-12-5		206B-12
	336C-22		220B-12-5		335A-11
	336C-28	09160-25042	220A-12-6		335B-11
	336D-12		220B-12-6		335C-11
	336D-15	09160-27012	336A-5	09160-27012	220A-13
	336E-12		336A-8		220B-13
09160-08170	513A-20		336B-5		220A-5-5
	335A-22		336B-8	09181-20244	220B-5-5
	335B-22		336C-5	09181-20246	220A-5-6
	335C-22		336C-8		220B-5-6
	335D-26		336D-5	09181-20248	220A-5-7
09160-12066	407A-19		336D-8		220B-5-7
	407B-19		336E-5	09181-20251	220A-5-1
	407C-19		336E-8		220B-5-1
	407D-19	09161-04012	410A-12	09181-25160	220A-12-1
	407E-19		410B-12		220B-12-1
	407F-19		410C-12	09181-25162	220A-12-2
	407G-19		410D-12		220B-12-2
09160-15057	303A-6		410E-12	09181-25164	220A-12-3
	303B-6	09161-08019	336A-37		220B-12-3
	220A-11-1		336B-37	09181-25181	220A-12-7
09160-17024	220A-11-3		336E-24		220B-12-7
09160-17026	220A-11-5	09163-06001	444A-19	09200-05014	336A-18
09160-17027	220A-11-7		444B-19		336B-18
09160-17028	220A-11-9	09164-14008	206A-12		336C-18
09160-17039	220A-11-2	09168-12017	405A-9	09200-06061	336A-16
09160-17040	220A-11-4		405B-9		336B-16
09160-17041	220A-11-6	09169-06062	126A-6		336C-16
09160-17042	220A-11-8		126B-6	09202-04008	160A-17
09160-17053	220B-11-1		126C-8		160B-17
09160-17054	220B-11-2		146A-13	09202-04025	220A-16
09160-17055	220B-11-3		146B-13		220B-16
09160-17056	220B-11-4		310A-7	09202-06023	401A-4
09160-17057	220B-11-5		310B-7		405A-8
09160-17058	220B-11-6		310C-7		405A-20
09160-17059	220B-11-7		310D-7		405B-8
09160-17060	220B-11-8		310E-7		405B-20
09160-17061	220B-11-9		310F-7		407A-4
09160-20027	220A-4		310G-7		407B-4
	220B-4		327A-5		407C-4
09160-20042	220A-5-2		327B-9		407D-4
	220B-5-2	09169-06063	310A-8		407E-4
	220A-5-3		310B-8		407F-4
09160-20043	220B-5-3		310C-8		407G-4
09160-20044	220A-5-4		310D-8	09204-01002	206A-8
	220B-5-4		310E-8		206B-8
	220A-6		310F-8		336A-13
09160-21009	220B-6		310G-8		336B-13
	220A-12-4	09180-06186	206A-13		336C-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09204-02004	513A-19	09263-17048	407E-3	09320-08056	310B-9
	407A-20		407F-3		310C-9
	407B-20		407G-3		310D-9
	407C-20		407A-2		310E-9
	407D-20		407B-2		310F-9
09205-02004	407E-20	09263-20024	407C-2	09320-08062	310G-9
	407F-20		407D-2		310A-6
	407G-20		407E-2		310B-6
	210A-4		407F-2		310C-6
	09205-03004		407G-2		310D-6
09205-06021	335D-19	09280-06012	220A-7	09320-09052	310E-6
	335A-6		220B-7		310F-6
	335B-6		210A-9		310G-6
	335C-6		175A-11		144A-7
	335D-3		09280-09012		126A-10
09229-04005	410A-20	09280-13004	210A-10	09320-11017	126B-10
	410B-20		175A-4		126C-12
	410C-20		111A-11		146A-15
	410D-20		09280-17003		146B-15
	410E-20		09280-22019		410A-7
09248-08001	420A-7	09280-26005	146A-39	09320-13022	410B-7
	420B-7		175A-5		410C-7
	420C-7		09280-54001		410D-7
	420D-7		09280-57002		410E-7
	420E-7		407A-12		405A-19
09248-12009	420F-7	09282-12L04	407B-12	09321-08022	405B-19
	420G-7		407C-12		146A-16
	407A-9		407D-12		146B-16
	407B-9		407E-12		146A-17
	407C-9		407F-12		146B-17
09248-12009	407D-9	09282-13L01	407G-12	09352-50823-600	338A-22
	407E-9		401A-5		220A-3
	407F-9		220A-22		220B-3
	407G-9		220B-22		116A-4
	405A-10		336A-6		410A-21
09250-12006	405B-10	09282-27002	336B-6	09380-12002	410B-21
	444A-30		336C-6		410C-21
	444B-30		336D-6		410D-21
	146A-14		336E-6		410E-21
	146B-14		121A-2		513A-31
09251-05006	146A-14	09283-32048	121B-2	09380-15001	166A-13
	146B-14		116A-9		206B-20
	410A-19		09289-05012		146A-18
	410B-19		121A-14		146B-18
	410C-19		121B-14		162A-6
09251-09007	410D-19	09289-06L02	210A-11	09385-06012	146A-19
	410E-19		407A-13		146B-19
	206A-15		407B-13		146A-34
	206B-13		407C-13		146A-40
	407A-3		407D-13		146B-34
09260-12003	407B-3	09289-17L02	407E-13	09401-08412	146A-34
	407C-3		407F-13		146A-40
	407D-3		407G-13		146B-34
	407D-3		310A-9		
	09262-25003		09320-08051		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09401-11425	146B-40	09401-12413	561D-18	09401-13423	322D-6
	144A-8		561D-22		450A-53
	111A-17		600A-27		450B-55
	401A-16		600B-27		513A-13
	146A-41		600C-27		546A-2
09401-13424	146B-41	09401-13424	322C-12	09401-13424	322A-7
	401A-18		162A-8		322B-4
	410D-22		310A-13		322C-4
	410E-22		310B-13		322D-7
	322A-16		310C-13		513A-14
09403-07308	322B-11	09403-08404	310D-13	09403-08404	111A-18
	322C-11		310E-13		
	322D-16		310F-13		
	146A-42		310G-13		
	146B-42		553A-8		
09403-11320	163A-11	09403-12406	561A-11	09403-12406	
	167B-15		561B-11		
	167A-14		561C-11		
	167B-14		561D-11		
	530A-8		322A-18		
09407-08401	530A-28	09407-14403	322A-19	09407-14403	
	322A-2		322B-14		
	322D-2		322C-14		
	553A-15		322D-19		
	561A-16		322E-13		
09407-14407	561B-16	09407-14407	322F-13	09407-14407	
	561C-16		322G-13		
	561D-16		322H-13		
	303A-8		322I-13		
	303B-8		322J-13		
09409-10304-5ES	322A-3	09409-10304-5ES	206B-24	09409-10304-5ES	
	322A-10-1		513A-39		
	322A-10-2		160A-16		
	322B-6		160B-16		
	322B-17		206A-16		
09420-03009	322C-6	09420-03009	206B-14	09420-03009	
	322C-19		444A-20		
	322D-3		444B-20		
	322D-10		175A-6		
	338A-23		09441-17001		
09440-18002	501A-8	09440-18002	335B-21	09440-18002	
	513A-32		335C-21		
	553A-7		501A-6		
	553A-16		501A-14		
	561A-18		501A-2		
09471-12028	561A-22	09471-12028	501A-4	09471-12028	
	561B-18		501A-18		
	561B-22		322A-6		
	561C-18		322B-3		
	561C-22		322C-3		

SUZUKI DF9.9B/15A/20A PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material Development Group, Service Engineering Department
300 Takatsuka, Minami, Hamamatsu, Japan

Copyright © SUZUKI MOTOR CORPORATION 2018 All Rights Reserved

SUZUKI MOTOR CORPORATION